

AD-A144 019


IMPROVEMENTS TO IBMPIC(U) NAVAL POSTGRADUATE SCHOOL
MONTEREY CA D A MILTON MAR 84


1/3

UNCLASSIFIED

F/G 9/2

NL





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963-A

②

NAVAL POSTGRADUATE SCHOOL

Monterey, California

AD-A144 019



THESIS

IMPROVEMENTS TO IBMPIP

by

Dale A. Milton

March 1984

Thesis Advisor:

R. E. Ball

DTIC

AUG 03 1984

E

DTIC FILE COPY

Approved for public release; distribution unlimited.

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER	2. GOVT ACCESSION NO. 10 4144 019	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) Improvements to IBMPIP		5. TYPE OF REPORT & PERIOD COVERED Master's Thesis March 1984
		6. PERFORMING ORG. REPORT NUMBER
7. AUTHOR(s) Dale A. Milton		8. CONTRACT OR GRANT NUMBER(s)
9. PERFORMING ORGANIZATION NAME AND ADDRESS Naval Postgraduate School Monterey, California 93943		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS
11. CONTROLLING OFFICE NAME AND ADDRESS Naval Postgraduate School Monterey, California 93943		12. REPORT DATE March 1984
		13. NUMBER OF PAGES 197
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)		15. SECURITY CLASS. (of this report) Unclassified
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release; distribution unlimited.		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Aircraft Survivability Interactive Graphics		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) Two batch air defense programs named POOL and MICE reside on the Naval Postgraduate School IBM 3033 computer. The programs compute the probability of kill of an aircraft by defensive weapons. Data is fed to the programs by an interactive preprocessing program named IBMPIP. Improvements to IBMPIP are proposed to enhance existing capabilities or provide new capabilities. Areas addressed are: introduction of user friendliness, enhancement of graphics capabilities, improvement in the accuracy of results, and a suggested philosophy for evolutionary improvements.		

DD FORM 1 JAN 73 1473

EDITION OF 1 NOV 65 IS OBSOLETE
S/N 0102-LF-014-6601

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

Approved for public release; distribution unlimited.

Improvements to IBMPIP

by

Dale A. Milton
Lieutenant, United States Navy
B.M.E., Auburn University, 1976

Submitted in partial fulfillment of the
requirements for the degree of

MASTER OF SCIENCE IN AERONAUTICAL ENGINEERING

from the

NAVAL POSTGRADUATE SCHOOL
March 1984

Author:

DAMilton

Approved by:

Walt E. Ball

Thesis Advisor

Donald M. Layton

Second Reader

Donald M. Layton

Chairman, Department of Aeronautics

JM Dyer

Dean of Science and Engineering

ABSTRACT

Two batch air defense programs named P001 and MICE reside on the Naval Postgraduate School IBM 3033 computer. The programs compute the probability of kill of an aircraft by defensive weapons. Data is fed to the programs by an interactive pre-processing program named IBMPIP. Improvements to IBMPIP are proposed to enhance existing capabilities or provide new capabilities. Areas addressed are:

- introduction of user friendliness
- enhancement of graphics capabilities
- improvement in the accuracy of results
- a suggested philosophy for evolutionary improvements

Accession For	
NTIS GFA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Avail and/or	
Dist	Special
A-1	



TABLE OF CONTENTS

I.	HISTORY AND INTRODUCTION	8
II.	USER FRIENDLINESS	13
III.	SUMMARY OF COMMONALITY BETWEEN PROGRAMS	13
IV.	SUMMARY OF CURRENT IBMPIP	21
V.	INTRODUCTION OF THE PROPOSED METHOD	33
	A. OVERVIEW	33
	B. BIGCAL LEVEL SUBROUTINES	36
	C. THIRD LAYER SUBROUTINES	57
VI.	NCN-BIGCAL IBMPIP SUBROUTINES	65
	A. INTRODUCTION	65
	B. SUBROUTINES	65
	C. GRAPHIC CALLS	69
VII.	STATUS OF PROPOSED IBMPIP AND SUMMARY	72
	APPENDIX A: USER'S MANUAL FOR CURRENT IBMPIP.	75
	APPENDIX B: DERIVATION OF EQUATIONS USED IN TEXT	95
	APPENDIX C: FLIGHT DYNAMICS AND COORDINATE TRANSFORMATIONS	102
	APPENDIX D: CONSOLIDATED COMMON LISTING	112
	APPENDIX E: EXECs USED TO DRIVE FORTRAN PROGRAMS	114
	APPENDIX F: CLEANED UP JOHNS VERSION IBMPIP	115
	APPENDIX G: PROPOSED IBMPIP LISTING	142

APPENDIX H: FLIGHTPATH GENERATOR WITHOUT THE	
GRAPHICS	181
LIST OF REFERENCES	188
INITIAL DISIRIBUTION LIST	197

LIST OF FIGURES

2.1	Continuous Flightpath Trace From Present	
	IBMPIP	15
3.1	Elements Comprising Forward and Normal	
	Acceleration	19
4.1	Invariants of the Current Trajectory	21
4.2	Spatial Components	22
4.3	Velocity Components	23
4.4	Angular Displacements	23
4.5	Computation of Spatial Components	24
4.6	Computation of Average Velocity (Speed)	25
4.7	Computation of Average Velocity Components	26
4.8	Computation of Average Acceleration	
	Components	27
4.9	Components Required for Average Heading	
	Vector	28
4.10	Transformation of Acceleration Components	29
5.1	Comparison of Schemes	34
5.2	Establishment of Move Vectors	38
5.3	Delta Vectors to the Temporary Point	41
5.4	Sense for Horizontal Turns	46
5.5	Sense for Pitch Above/Below the Horizon	47
5.6	Definition of Positive Rotations	49
5.7	Aircraft Rotational Velocities	52
5.8	Unrealistic Scenario	64
7.1	A Situation Not Addressed By Subroutine	
	ACACC	72
C.1	The Map Coordinate System	102
C.2	The Aerodynamicist's Coordinate System	102

C.3	Components of the Equations of Motion	105
C.4	First Rotation	106
C.5	Second Rotation	107
C.6	Third Rotation	108
C.7	Finite Rotations Do Not Act As Vectors	109
C.8	Transformation of (ω)	110

I. HISTORY AND INTRODUCTION

There are two batch processor air defense simulation programs implemented at Naval Postgraduate School. These programs take a user-defined aircraft flight path, compare it to various defensive positions and return the probability of having killed the aircraft. The first program is the Air Force Armament Laboratory's Anti-Aircraft Artillery (AAA) Simulation. Its shorthand name is P001. The second program is the Air Force ASD surface-to-air missile (SAM) engagement simulation. Its shorthand name is MICE II. The programs satisfy MIL-STD-2069 and are used in industry as a design aid.

A drawback to these programs is the fact that the amount of input data submitted to the programs is large and the format requirements are rigid. The process of direct submission of data to the programs, is therefore time consuming and tedious. Humans are inefficient at performing time consuming, tedious tasks and errors are a result.

A first step improvement in the method of inputting data to P001 occurred in 1978. A pre-processing program named P001 Input Processor, or PIP for short, was created. Like the processors, PIP was a batch program. However, input requirements were reduced to just spatial coordinates of flightpath milestones, an initial speed, and control indicators for the type of output desired.

PIP had its shortcomings, too. Because of the batch implementation, the entire flightpath of milestones had to be submitted as a unit. The user learned of violations of aircraft structural/performance limitations and mission rules by experiencing failed runs. Corrections consisted of repeated tinkering with the milestones until a successful

run emerged. A further drawback to PIP is the requirement for the user to plot the desired route, pick off numeric data and then get the numeric data into FORTRAN format.

The next generation improvement was introduced at Naval Postgraduate School in 1982 by Lt. Eric R. Johns. Recognizing the inherent limitations of a batch processor, Johns converted PIP into an interactive program suitable for use on time shared computer systems. In so doing, he realized the following benefits:

1. The user could be notified "immediately" of a milestone entry that violated predefined aircraft structural or performance limitations.
2. The user could be given the opportunity of making a correction before proceeding.
3. An interactive graphics capability could be introduced which eliminated the necessity of manually converting and coding data from a map into the computer.

As a secondary effort, transportability through modular programming was introduced to permit easy dissemination of the pre-processor to interested government agencies and industries. The version in use on the Naval Postgraduate School IBM 3033 computer is named IBMPIP.

While acknowledging the importance of IBMPIP as a great evolutionary step forward in the convenient use of P001 and MICE, it quickly became apparent that still more improvements could be realized, which would increase the convenience of the data generating aspect, improve the accuracy of the results from P001 and MICE and broaden the capabilities of the IBMPIP-P001/MICE combination in two areas: design decision making and tactics. The purpose of this thesis is to make some of those improvements.

Rather than rename IBMPIP, this thesis proposes an improved version of IBMPIP by installation of specific modules which are to be discussed. Physically, the introduction of the new modules required extensive changes to the existing modules.

Before developing the discussion for the proposed modules, it will be instructive to examine the use of IBMPIP-P001/MICE at Naval Postgraduate School. This acts as a first step toward developing an overall philosophy within which future modifications will fit in a logical sequence.

IBMPIP-P001/MICE is incorporated in a course titled Aircraft Combat Survivability (AE 3251) and is used as a teaching aid in developing an understanding of the factors affecting aircraft survivability in a hostile AAA and SAM environment. In a game environment, student teams "fly" a bombing mission against a target defended by seven AAA and one SAM locations. There are game restrictions on the location of some of the defensive positions. There are also game restrictions on the performance of the pseudo-aircraft. Each team is responsible for generating one defensive and one offensive data file. When each team is satisfied with their parameters, the data files are exchanged in such a manner that each team's flight path is compared to the other team's defense. Implicit in this method is the understanding that each team has no knowledge of what the incoming data files will look like. The comparisons, then, approach arbitrariness. P001 and MICE act as the judge, in that the team with the lowest probability of kill for their flightpath is named winner.

To ensure comparability of scores, the performance of the aircraft is fixed for the game, although IBMPIP presently has the capability of permitting performance and flight profile changes OF THE ONE aircraft described in it. This is an important point to note.

What is left as variables at the disposal of the teams then, are defensive positioning and the specific flightpath of the aircraft. This leads the students directly to the concept of tactics as a method of lowering probability of kill (Increasing chances of survival). This is good. What would be better would be for the student to reach the conclusion that reduction of vulnerability and susceptibility flaws in the aircraft will lead to a probability of survival exceeding that which can be accomplished by tactics alone. There are several modifications to IBMPIP that would accomplish this goal.

As stated earlier, P001 and MICE are used by industry to make design decisions. This fact leads to the demand that the data on the position of the aircraft be at least as accurate as the detect and track capability of the defensive devices programmed into P001 and MICE. Such is not presently the case. The original version of IBMPIP uses an assumed quadratic flightpath between the current milestone and the two previous milestones. The aircraft accelerations are computed at the center of these three milestones based on the velocity between the third and center milestones and the velocity between the center and current milestones. If the accelerations at the center milestone are acceptable, the current milestone is accepted. P001 and MICE assume a straight line between these milestones. Because the user is free to define milestones thousands of meters apart there can be a significant lateral error in the computed aircraft position at the mid-points between the milestones.

A last area to be discussed is the output from P001 and MIC2. At present, it is difficult to obtain rapid correlation between the "aircraft" and where it is being subjected to attack. The output from both P001 and MICE are in the form of long tables of time-space-attitude information of the aircraft, probability of kills for each defensive

device and the cumulative probability of kill based on the sum of all of the defense. The user must then graph by hand the location of the "aircraft" at the time it is threatened or being damaged, to draw any conclusions on its susceptibility and to a lesser extent, its survivability.

By way of summary then, a statement is made as to what would constitute an ideal IBMPIP-P001/MICE implementation to satisfy all the above mentioned shortfalls. IBMPIP-P001/MICE should be:

- interactive to permit feed back of pertinent operating information to the user
- user friendly to diminish the requirement for specialized operating procedures and to avoid fatal errors
- approaching real time in ability to compute and present results
- graphics oriented to enhance the convenient generation of input data AND presentation of results
- accurate to the extent of the systems being modelled
- flexible through incorporation of a selectable range of different aircraft and defensive weapons
- transportable, as accomplished through modular programming techniques

In conclusion, two of the above points are addressed by this thesis and will be discussed. They are incorporation of user friendliness and a more representative flightpath. The most difficult task has been the convenient generation of an accurate, representative flight path.

II. USER FRIENDLINESS

A generally accepted meaning of "user friendliness" is to structure a program in such a fashion that the user cannot "do" anything to cause an unplanned halt in execution. The simplest version of the above concept is to prevent the user from entering data upon which the program is not structured to act. The following example is taken from the original IBMPIP.

```
50    WRITE (6,600)
      READ (5,*) IGUN
600   FORMAT('GUNS: 0=DISK FILE,1=TERMINAL,2=PRESET')
```

It is clear that the only correct responses are 0, 1, and 2. It is also clear that any integer number would satisfy the READ statement. To prevent unplanned events from taking place in the program, the following change is made:

```
50    WRITE (6,600)
      READ (5,*) IGUN
      IF(IGUN.NE.0.AND.IGUN.NE.1.AND.IGUN.NE.2)
        *GOTO 50
600   FORMAT(' 0=DISK FILE,1=TERMINAL,2=PRESET')
```

The user is now prevented from progressing beyond this point in the program until an acceptable input is made. The user is encouraged to try again by having the prompt message repeat on the screen.

If the definition of user friendliness is broadened to include "convenience" to the user, then there are many schemes which could profitably be incorporated. For example, in the current version of IBMPIP, once a map has been successfully created on the graphics screen, all further data is entered through a graphics buffer. The reason for this method is to allow the user to see a continuous trace (see figure 2.1) of the trajectory that will be submitted to P001/MICE. However, if a game parameter or an aircraft limitation is violated, the program suspends execution and queries the user for a selection of one of two options:

1. Accept the data point, which violates a parameter or,
2. Substitute a data point which does not.

This can turn into an iterative process between the user and the program.

It is a contention of this thesis that parameter violations which do not affect the overall outcome of the survivability of the "aircraft" should be corrected automatically by the computer. At most, for these kind of errors, the user should see an advisory statement that does not require a response. The following example is offered in support (to improve readability, some of the variables are renamed to simpler mnemonics).

One of the game parameters that must be satisfied is that during the enroute portion of the "flight", the "aircraft" may not descend below 60 meters altitude, as denoted by the variable HTMIN. Presented, then, is the original program flow for a violation of this parameter.




Figure 2.1 Continuous Flightpath Trace From Present IBMPIP.

```

1      ==>graphically input Z1
      ALT=Z1 (where Z1 is the altitude in meters
            -- call it 50 meters)
      IF(ALT.GE.HTMIN) proceed
            otherwise
            -ERROR=3
            GOTO (1,2,3,...),ERROR
3      WRITE (6,603)
603    FORMAT('ALTITUDE TOO LOW')
      WRITE (6,650)
      READ (5,*) ICOR
650    FORMAT('DO YOU WISH TO CORRECT ERROR,
            *1=YES,2=NO)
      IF(ICOR.EQ.1) GOTO 1

```

Positional parameters such as this are easily violated because the graphic setup constrains the "altimeter" to 200 meter increments and it is difficult to discern where 50 meters falls. If the user violated this parameter, it was obviously with the intent to go as low as possible without violating the parameter. It would seem reasonable, then, to modify the program in the following fashion:

```
ALT=Z1
IF(ALT.GE.HTMIN) proceed
    otherwise
        ALT=HTMIN
        WRITE(6,100)
100  FORMAT('USER VIOLATES MINIMUM ALT RESTRICTION:
        *COMPUTER CORRECTS; EXECUTION CONTINUES')
```

The following kind of situation is particularly frustrating, as there is no clue given to the user as to what is the problem. The statement is found in a passage that is reading in data from a pre-established disk file.

```
308  IF(MNUM.EQ.1.AND.LTR.EQ.83) STOP
```

MNUM..EQ.1 represents the first data point entered into the program. LTR is a control variable, and code 83 is that used to signify that "aircraft" milestone entry is complete. Unless the user happens to have access to the program listing, there is nothing to indicate that s/he is attempting to read in a flawed data set; yet selection of code 83 is permitted on the first data point entry when setting up the disk file.

The solution here is to simply route the program flow to a message informing the user of the difficulty.

```
308  IF(MNUM.EQ.1.AND.LTR.EQ.83) GOTO 100
100  FORMAT('INPUT DATA IS FATALLY FLAWED,
          *PROGRAM UNABLE TO CONTINUE, PROGRAM TERMINATES')
      STOP
```

In conclusion, user friendliness using concepts as stated above are incorporated into the improved version of IBMPIF. It is anticipated that as the scope of the users increases, more changes will become apparent.

III. SUMMARY OF COMMONALITY BETWEEN PROGRAMS

The current and proposed methods of generating a flight path share a common objective:

Accurately model the trajectory of a flight of a fixed-wing aircraft. Make the model realistic by subjecting the trajectory to the performance limitations of the real aircraft.

The aircraft performance limitations for both programs are:

1. acceleration along the longitudinal axis of the aircraft
2. acceleration normal to the longitudinal axis ("g" loading)

The forward acceleration is composed of components from:

1. engine thrust
2. aerodynamic drag
3. gravity

The normal acceleration is composed of components from:

1. lift
2. drag
3. gravity




Figure 3.1 Elements Comprising Forward and Normal Acceleration.

Figure 3.1 illustrates the components making up forward and normal accelerations. There are ten parameters of the trajectory which must be determined for subsequent use by P001 and MICE. They are:

1. spatial components (x, y, z)
2. velocity components (u, v, w)
3. attitudinal components (heading angle (ψ), pitch angle (θ), and roll angle (ϕ))
4. elapsed time

The overall method by which the components are generated in the two programs are the same:

1. The ten components representing translation/rotation from one input milestone (x,y,z and velocity) to the next are computed in the earth-fixed (inertial) coordinate system.
2. The accelerations resulting from the displacement in the earth-fixed coordinate systems are transformed into the aircraft-fixed (rotational) coordinate system.
3. The thrust and g-load on the aircraft are computed.
4. If the thrust and g-loading fall within predefined limits, the 10 components are accepted, written to file and the program re-initialized to accept the user's next milestone.

One difference between the current and the proposed program occurs in the treatment of the conditions of over-thrust and over-g-load. The current program halts the execution and requests a user fix to the milestone. The proposed program adjusts the parameters internally until thrust and g-limitations are met.

IV. SUMMARY OF CURRENT IBMPIP

The current method is described below. Three milestones are used to compute average values of heading, climb and velocity components of the middle milestone. The flight path is always expressed as a straight line between two points. With this system, the invariables are the spatial coordinates of the milestones and the "aircraft" speed at




Figure 4.1 Invariants of the Current Trajectory.

the waypoints. As the trace in figure 4.1 is generated, two tasks are accomplished:

1. The user gets a "feel" for where the aircraft is going on the map.
2. Data is computed on the ten aircraft parameters, which at the completion of a run of IBJPIP, will be submitted to the batch programs P001 and/or MICE.

The data required by P001 and MICE are presented pictorially in the following figures.




Figure 4.2 Spatial Components.




Figure 4.3 Velocity Components.




Figure 4.4 Angular Displacements.

The method used to generate the above data will now be presented in the following figures. To make viewing convenient, all diagrams will occupy the X-Y plane with the understanding that the discussion applies to the three-dimensional case.




Figure 4.5 Computation of Spatial Components.

$$\begin{aligned} DX1 &= (X2 - X1) & DX2 &= (X3 - X2) \\ DY1 &= (Y2 - Y1) & DY2 &= (Y3 - Y2) \\ DZ1 &= (Z2 - Z1) & DZ2 &= (Z3 - Z2) \\ DIST1 &= \text{SQRT}(DX1**2 + DY1**2 + DZ1**2) \\ DIST2 &= \text{SQRT}(DX2**2 + DY2**2 + DZ2**2) \end{aligned}$$




Figure 4.6 Computation of Average Velocity (Speed).

$$VAVG1 = (V2 - V1) / 2$$

$$VAVG2 = (V3 - V2) / 2$$

The elapsed time for the leg and total to the milestone are computed as follows:

$$DT1 = DIST1 / VAVG1$$

$$DT2 = DIST2 / VAVG2$$

$$T2 = T1 + DT1$$

$$T3 = T2 + DT2$$




Figure 4.7 Computation of Average Velocity Components.

$$VX1 = VAVG1 * (DX1 / DIST1)$$

$$VY1 = VAVG1 * (DY1 / DIST1)$$

$$VZ1 = VAVG1 * (DZ1 / DIST1)$$

$$VX2 = VAVG2 * (DX2 / DIST2)$$

$$VY2 = VAVG2 * (DY2 / DIST2)$$

$$VZ2 = VAVG2 * (DZ2 / DIST2)$$




Figure 4.8 Computation of Average Acceleration Components.

$$\text{DELTAT} = (T3 - T1) / 2$$

$$\text{AX1} = (\text{VX2} - \text{VX1}) / \text{DELTAT}$$

$$\text{AY1} = (\text{VY2} - \text{VY1}) / \text{DELTAT}$$

$$\text{AZ1} = (\text{VZ2} - \text{VZ1}) / \text{DELTAT}$$

When at milestone two, the aircraft is presumed to have an attitude which is an average of the attitude at milestone one (MS1) and the attitude at milestone two (MS2). Unit vectors are generated at MS2 using the following weighting scheme.




Figure 4.9 Components Required for Average Heading Vector.

$$HDGAVG = DIST2 / (DIST1 + DIST2)$$

$$TDX = ((VX2 / VAVG2) - (VX1 / VAVG1)) * HDGAVG + VX1 / VAVG1$$

$$TDY = ((VY2 / VAVG2) - (VY1 / VAVG1)) * HDGAVG + VY1 / VAVG1$$

$$TDZ = ((VZ2 / VAVG2) - (VZ1 / VAVG1)) * HDGAVG + VZ1 / VAVG1$$

The vectors are converted to direction cosines:

$$UNIT = \sqrt{TDX^2 + TDY^2 + TDZ^2}$$

$$TDX = TDX / UNIT$$

$$TDY = TDY / UNIT$$

$$TDZ = TDZ / UNIT$$

Rotational angles can now be defined:

$$HDG = ATAN(TDY/TDX)$$

$$CA = ATAN(TDZ/SQRT(TDX**2+TDY**2))$$

Computation of the roll angle is temporarily deferred. The accelerations in the earth-fixed coordinate system must be transformed to the rotational coordinate system (see figure 4.10) below.




Figure 4.10 Transformation of Acceleration Components.

The coordinate transformations are given without development [Ref. 1]

$$TMD = \begin{Bmatrix} \cos(HDG) * \cos(CA) \\ \sin(HDG) * \cos(CA) \\ \sin(CA) \end{Bmatrix}^T \begin{Bmatrix} AX1 \\ AY1 \\ AZ1 + GEE \end{Bmatrix}$$

$$PH = \begin{Bmatrix} \sin(HDG) \\ \cos(HDG) \\ 0 \end{Bmatrix}^T \begin{Bmatrix} AX1 \\ AY1 \\ AZ1 + GEE \end{Bmatrix}$$

$$PP = \begin{Bmatrix} \cos(HDG) * \sin(CA) \\ \sin(HDG) * \sin(CA) \\ \cos(CA) \end{Bmatrix}^T \begin{Bmatrix} AX1 \\ AY1 \\ AZ1 + GEE \end{Bmatrix}$$

TMD= acceleration along the aircraft's longitudinal axis

PH= acceleration in the direction of the aircraft's right wing

PP= acceleration in the direction of the top of the aircraft

GEE=acceleration due to the earth's gravity (9.82 m/s²)

The roll angle of the aircraft with respect to the earth-fixed coordinate system is written:

$$RA = -\text{ATAN}(PH/PP)$$

The total aircraft lift is the vector sum of the accelerations normal to forward translation and is normal to the roll angle:

$$ACLIFT = \text{SQRT}(PH^{**2} + PP^{**2})$$

Both the forward translation acceleration and the lift or normal acceleration are non-dimensionalized by the gravity term:

$$TMD1 = TMD / GEE$$

$$ACLIFT1 = ACLIFT / GEE$$

The above is based upon the concept of force divided by weight:

$$THRUST / WEIGHT = m(TMD) / mg = TMD / GEE = TMD1$$

Now aerodynamic drag on the airframe must be accounted for. Drag is computed using conventional aerodynamic equations. Computation of air density as a function of altitude:

$$RHO = .256 * EXP(-.103 * Z2 / 1000)$$

Z2 = absolute altitude of milestone 2 in meters

This equation is in the non-standard dimensions (lbf-sec²/ft²-meter²) and is therefore unacceptable. It will be supplanted in the following chapter.

Computation of the coefficient of lift

$$CL = 2 * ACLIFT / (RHO * V2 ** 2 / WL)$$

WL = wing loading in lbf/ft²

Computation of drag (non-dimensional):

$$D_W = ((C_{D0} + C_{DK} * CL^2 / CL) * A_{CLIFT})$$

C_{D0} = coefficient of drag at zero angle of attack

$C_{DK} * CL^2$ = drag due to lift

Net longitudinal acceleration factor:

$$T_W = T_{MD} + D_W$$

Speed brakes are accounted for by adding a surface area factor to the drag equation:

$$D_W(s.b.) = ((0.05 + C_{D0} + C_{DK} * CL^2) / CL) * A_{CLIFT}$$

0.05 = 5% of the wing surface area

The limiting parameters are then:

1. T_W
2. A_{CLIFT}

V. INTRODUCTION OF THE PROPOSED METHOD

A. OVERVIEW

The proposed trajectory modules were written to satisfy the following goals:

1. Retain user friendliness features. This is defined in the following fashion: once a user enters a waypoint (we are here renaming milestones) through the graphics, the computer should fit a flight path to that waypoint without any further action on the part of the user. Interpret this to mean the user cannot enter a fatal waypoint.
2. The trajectory should closely match an actual aircraft's in spatial coordinates, linear velocities, and attitudinal rotations from the inertial coordinate system.

Observe figure 5.1 for a comparison between the two systems.

Under the proposed system the following gross events take place:

1. The aircraft is defined at a beginning waypoint which is named "old".
2. The user enters a next-waypoint, defined as "new".
3. Linear acceleration components are computed from "old" to "new".
4. Using the accelerations and an invariant increment of time, the aircraft is moved from "old" to a new point defined as "temp".




Figure 5.1 Comparison of Schemes.

5. Knowing the displacement vectors that got us to "temp", velocity components at "temp" are computed.
6. Knowing the displacement vectors that got us to "temp", angular displacements are computed
7. Knowing the time increment, rotational velocities are computed.
8. The linear AND rotational accelerations at "temp" are transformed into aircraft-fixed coordinates.
9. The transformed accelerations are fed into the left hand side (LHS) of the Aircraft Equations of Motion.

10. If thrust and g-load limitations are not exceeded, "temp" becomes an accepted point, the parameters are written to file, the map is updated by one time increment and "temp" becomes new "old".
11. The process is repeated until "old" becomes "new".
12. The user is queried for the next waypoint.

The new features are:

1. The computer flight path is now a discretized version of an actual flightpath and hence is more realistic model.
2. Rotational accelerations are accounted for. They are not accounted for in the present program. Thus, the present aircraft performance is artificially better than the performance of the real aircraft being modeled. Survivability data is too optimistic.

Imposed on the above events is an iteration that does two things:

1. If accelerations resulting from the user input lead to "aircraft" thrust and g-loadings less than the maximum defined, the accelerations are increased until thrust or g-loading hits maximum (whichever occurs first).
2. If thrust or g-loading are too great, either the user input velocity is adjusted downward or the "new" waypoint is moved in a straight line away from the "old" waypoint, until thrust AND g-load fall within limitations.

Number one was included under the philosophy that a pilot flying an aircraft which is being shot at will not be flying at less than the maximum available. A drawback to the current system is the user has no way of knowing (except by

exceeding limitations) whether the aircraft is at maximum performance or not. Number two was included in keeping with the desire to model the real aircraft as closely as possible. The hierarchy is based upon informal interviews with attack pilots attending NPS.

The rest of the Chapter contains a detailed examination of the subroutines and an explanation of the variables related to flightpath generation. All equations in the examinations are either dimensionless or in SI units. The subsequent Chapter reviews the remaining subroutines of IBMPIP. The final Chapter summarizes the current status of the proposed IBMPIP.

B. BIGCAL LEVEL SUBROUTINES

1. BIGCAL

- a. expanded name: Big Call
- b. function: Big Call acts as a driver for the rest of the subroutines involved with flight trajectory generation.
- c. equations/calls:

```
10      CALL TRNFRM
        CALL NEWOLD
        CALL MVELOS
        CALL MVDOTS
        CALL DELVEC
        CALL TMPPNT
        CALL TMPVEL
        CALL INRTRM
        CALL VECTOR
        CALL ANGLES
        CALL ROTRAT
        CALL ACTRM1
        CALL ACTRM2
```

CALL ACTRM3
 CALL ACRVEL
 CALL ACACC
 CALL ACLMTS
 CALL XCHNGE
 CALL WAYPNT
 CALL FILE
 CALL GRAFIX

- d. comments: The two advantages in this approach are the ability to treat all the flight trajectory subroutines as a single package and having this package accessed by a single call from the main program of IENPIP.

2. TRNFRM

- a. expanded name: Transform
 b. function: Transform takes the user defined values which are acquired from the graphics buffer and loads them into variables peculiar to the aircraft trajectory package.
 c. equations/calls:

XNEW= X1
 YNEW= Y1
 ZNEW= Z1
 VELCN=V1

- d. comments: The above is done to permit "in-house" manipulation of the waypoint values without affecting the non-BIGCAL subroutines found elsewhere in IBMPIP. Note that in effect, this is the definition of waypoint "new" for the trajectory package.

3. NEWCLD

- a. expanded name: from Old to New
- b. function: The generation of shorter variable names for the convenience of the programmer.
- c. equations/calls:

```
AG1=XNEW-XOLD  
AH1=YNEW-YOLD  
AI1=ZNEW-ZOLD  
AJ1=SQRT(AG1**2+AH1**2+AI1**2)  
AJ2=SQRT(AG1**2+AH1**2)
```




Figure 5.2 Establishment of Move Vectors.

d. comments: See figure 5.2. Note that AJ2 is the shadow of AJ1 on the x-y plane.

4. MVELOS

- a. expanded name: Map Coordinate Velocity Components
- b. function: Generates orthogonal velocity components for the user supplied speed at waypoint "new".
- c. equations/calls:

```
IF(N.GT.0) GOTO 10
      UNEW=VELON*(AG1/AJ1)
      VNEW=VELON*(AH1/AJ1)
      WNEW=VELON*(AI1/AJ1)
10    CONTINUE
      N=1
```

d. comments: The components are based upon the direction cosines from "old" to "new". As the "aircraft" moves from "old" to "new" in the subsequent programs, the direction cosines can change, sometimes drastically. Those changes are taking place along a temporary path which is "fuzzy" at first. It is fatal to the program for this "fuzziness" to be allowed to influence the endpoint velocity components (located at "new"). Therefore, the computation of the velocity components is restricted to one iteration between any given "old" and "new". There are some well defined exceptions will be discussed downstream.

5. MVDCTS

- a. expanded name: Map Coordinate Velocity-Dot Components
- b. function: Establish the linear accelerations between waypoint "old" and "new".
- c. equations/calls:

$$ACC = (VELON**2 - VELOO**2) / (2*AJ1)$$

$$UDOT = ACC * (AG1/AJ1)$$

$$VDOT = ACC * (AH1/AJ1)$$

$$WDOT = ACC * (AI1/AJ1)$$

- d. comments: Again the components are based upon the direction cosines. The derivation of the equation

$$ACC = (VEICN**2 - VELOO**2) / (2*AJ1)$$

is given in appendix B.

6. DELVEC

- a. expanded name: Delta Vectors
- b. function: Compute the components of a ds vector in preparation of a move of the "aircraft" from "old" to a location "temp". "Temp" is a point along a curvilinear trace with the defined endpoints "old" and "new". Establishment of the points "temp" define the curvilinear trace.
- c. equations/calls:

$$DELX = UOLD * DELTEE + .5 * UDOT * DELTEE**2$$

$$DELY = VOLD * DELTEE + .5 * VDOT * DELTEE**2$$

$$DELZ = WOLD * DELTEE + .5 * WDOT * DELTEE**2$$

$$IF (ABS(DELX) .GT. ABS(AG1)) DELX = AG1$$

$$IF (ABS(DELY) .GT. ABS(AH1)) DELY = AH1$$

$$IF (ABS(DELZ) .GT. ABS(AI1)) DELZ = AI1$$

- d. comments: The equations

$$DELX = UOLD * DELTEE + .5 * UDOT * DELTEE**2$$

$$DELY = VOLD * DELTEE + .5 * VDOT * DELTEE**2$$

$$DELZ = WOLD * DELTEE + .5 * WDOT * DELTEE**2$$

are conventional dynamic equations and are derived in appendix 2. The term DELTEE is an invariant increment of time and is set for the program. The current value is one second and is set in READ DATA. Thus for a time increment of one second, the




Figure 5.3 Delta Vectors to the Temporary Point.

aircraft is moved forward from "old" toward "new" by DEL amounts in the three orthogonal directions, utilizing the velocities and accelerations just computed. See figure 5.3. The logic statements

```
IF (ABS(DELX).GT.ABS(AG1)) DELX=AG1
IF (ABS(DELY).GT.ABS(AH1)) DELY=AH1
IF (ABS(DELZ).GT.ABS(AI1)) DELZ=AI1
```

deal with the situation where the "aircraft" is sufficiently close to "new" that the amount of translation covered in one second is greater than that needed to exactly arrive at "new" (prevents overshoot).

7. IMPENT

- a. expanded name: Temporary Point
- b. function: Define in map coordinates the location of the point "temp".
- c. equations/calls:

```
XTEMP=XOLD+DELX
YTEMP=YOLD+DELY
ZTEMP=ZOLD+DELZ
IF (DELX.EQ.AG1) XTEMP=XNEW
IF (DELY.EQ.AH1) YTEMP=YNEW
IF (DELZ.EQ.AI1) ZTEMP=ZNEW
```

- d. comments: The first three equations

```
XTEMP=XCID+DELX
YTEMP=YCID+DELY
ZTEMP=ZCID+DELZ
```

are self-explanatory. The group of logic statements

```
IF (DELX.EQ.AG1) XTEMP=XNEW
IF (DELY.EQ.AH1) YTEMP=YNEW
IF (DELZ.EQ.AI1) ZTEMP=ZNEW
```

are in keeping with the need for exact arrival at "new".

8. IMPVEL

- a. expanded name: Temporary Point Velocity Components

- b. function: Generate velocity components for the point "temp".
- c. equations/calls:

```

UTEMP=UOLD+UDOT*DELTEE
VTEMP=VOLD+VDOT*DELTEE
WTEMP=WOLD+WDOT*DELTEE
IF (DELX.EQ.AG1) UTEMP=UNEW
IF (DELY.EQ.AH1) VTEMP=VNEW
IF (DELZ.EQ.AI1) WTEMP=WNEW
VELOT=SQRT (UTEMP**2+VTEMP**2+WTEMP**2)

```

- d. comments: The below equations

```

UTEMP=UCID+UDOT*DELTEE
VTEMP=VCID+VDOT*DELTEE
WTEMP=WCID+WDOT*DELTEE
VELOT=SQRT (UTEMP**2+VTEMP**2+WTEMP**2)

```

are conventional dynamic equations and are derived in appendix E. The three logic statements

```

IF (DELX.EQ.AG1) UTEMP=UNEW
IF (DELY.EQ.AH1) VTEMP=VNEW
IF (DELZ.EQ.AI1) WTEMP=WNEW

```

again deal with the exact arrival at "new".

9. INRTRM

- a. expanded name: Initial Rotational Transformation
- b. function: Convert velocities and accelerations which are defined in terms of map coordinate (y points North, x points East, and z points "up") components to a coordinate system which sees conventional use by aircraft designers (y points South, x points East, and z points "down" toward the earth). See appendix C.

c. equations/calls:

```
U1= UTEMP
V1=-VTEMP
W1=-WTEMP
UD1= UDOT
VD1=-VDOT
WD1=-WDOT
```

d. comments: None.

10. ANGLES

- a. expanded name: Angle Change Increments
- b. function: Compute the angles resulting from the "aircraft's" move from "old" to "temp".
- c. equations/calls:

```
DS= SQRT (DELX**2+DELY**2+DELZ**2)
IF (DELX.NE.0.) GOTO 10
    IF (DELX.EQ.0...AND.DELY.LT.0.)
*       PSINEW=AA1
    IF (DELX.EQ.0...AND.DELY.GT.0.)
*       PSINEW=-AA1
    GOTO 20
10    CONTINUE
    PSINEW=-ATAN (DELY/DELX)
    IF (DELX.GT.0...AND.DELY.EQ.0.) PSINEW=0.
    IF (DELX.LT.0...AND.DELY.LT.0.)
*       PSINEW=AB1+PSINEW
    IF (DELX.LT.0...AND.DELY.EQ.0.) PSINEW=AB1
    IF (DELX.LT.0...AND.DELY.GT.0.)
*       PSINEW=PSINEW-AB1
20    CONTINUE
    THENEW=ASIN (DELZ/DS)
```

```

      TRNRAT=(PSINew-PSIOLD)/DELTEE
      IF (PSINew.GT.0.) PHINew=
*      ATAN (ABS (TRNRAT*VELOT/9.7958))
      IF (PSINew.LT.0.) PHINew=
*      -ATAN (ABS (TRNRAT*VELOT/9.7958))
      IF (PSINew.EQ.PSIOLD) PHINew=PHIOLD

```

d. comments: The aircraft has a particular attitude at the defined location "old". The movement to "temp" represents a "turn" toward "new". The angles are required for two reasons: the fact that the vulnerable area of the aircraft is a function of the aircraft's attitude with respect to damage propagators and the rotation of the aircraft in the turn generates additional accelerations which superpose on the linear ones just determined. These rotational accelerations must be accounted for when analysing the loads imposed on the aircraft. The variables

```

      AA1=1.5708 radians (90 degrees)
      AB1=3.1416 radians (180 degrees)

```

represent recurring quadrant angles. The equations

```

      IF (DELX.NE.0.) GOTO 10
      IF (DELX.EQ.0..AND.DELY.LT.0.)
*      PSINew=AA1
      IF (DELX.EQ.0..AND.DELY.GT.0.)
*      PSINew=-AA1
      GOTO 20
10      CONTINUE
      PSINew=-ATAN (DELY/DELX)
      IF (DELX.GT.0..AND.DELY.EQ.0.) PSINew=0.
      IF (DELX.LT.0..AND.DELY.LT.0.)
*      PSINew=AB1+PSINew

```



```
IF (DELX.LT.0..AND.DELY.EQ.0.) PSINEW=AB1
```

```
IF (DELX.LT.0..AND.DELY.GT.0.)
```

```
* PSINEW=PSINEW-AB1
```

determine the turn angle PSINEW. The turn angle (or heading change) is referenced from the positive




Figure 5.4 Sense for Horizontal Turns.

x-axis, is measured in radians, and may be either positive or negative. Positive is defined as a CLOCKWISE rotation. This sense is specified to insure compatibility with upcoming transformation matrices. See figure 5.4. The equation

$$\text{THENEW} = \text{ASIN}(\text{DELZ}/\text{DS})$$

defines an angle THENEW (thetaneu) which is a measure of the "aircraft's" pitch above or below




Figure 5.5 Sense for Pitch Above/Below the Horizon.

the horizontal plane (horizon). Positive is defined as nose above the horizon. THENEW is measured in radians. See figure 5.5. The roll angle PHINEW defines how much the right hand wing of the "aircraft" is rotated above or below the horizon. PHINEW is a function of PSINEW and is related through the turn rate of the aircraft. The equation

$$TRNRAT = (PSINEW - PSIOLD) / DELTEE$$

defines turn rate as the heading change that took place going from "old" to "temp" over the period DELTEE. The factor 9.7958 that appears in equations

```
IF (PSINEW.GT.0.) PHINEW=
*   ATAN (ABS (TRNRAT*VELOI/9.7958))
IF (PSINEW.LT.0.) PHINEW=
*   -ATAN (ABS (TRNRAT*VELOI/9.7958))
```

is derived in appendix B. The logic statement

```
IF (PSINEW.EQ.PSIOLD) PHINEW=PHIOLD
```

accounts for constant heading. It is written in this fashion to smooth the roll angle and therefore roll rate through the "new" waypoint. This will be clarified in the comments on the next subroutine.

11. ROTRAT

- a. expanded name: Rotational Rates
- b. function: Compute the orthogonal rotational rates that occurred as a result of the move from "old" to "temp".
- c. equations/calls:

```
PSIDOT=(PSINEW-PSIOLD)/DELTEE
THEDOT=(THENEW-THEOLD)/DELTEE
PHIDOT=(PHINEW-PHIOLD)/DELTEE
```

- d. comments: See figure 5.6 for rotation sense.

12. ACTRM1

- a. expanded name: Aircraft Transformation Matrix #1
- b. function: Transform the velocity and acceleration components referenced to the earth-fixed coordinate system (x pointing East and z pointing down) into components referenced to coordinate system with x




Figure 5.6 Definition of Positive Rotations.

pointing along the nose of the aircraft (but still in the horizontal plane) and z pointing down.
c. equations/calls:

```

ANG=PSINEW
U2= COS(ANG)*U1+SIN(ANG)*V1
V2=-SIN(ANG)*U1+COS(ANG)*V1
W2=W1
UD2= COS(ANG)*UD1+SIN(ANG)*VD1
VD2=-SIN(ANG)*UD1+COS(ANG)*VD1
WD2=WD1

```

- d. comments: See appendix C for a development of all three transformation matrices, ACTRM1, ACTRM2, and ACTRM3. The requirement for the matrices stems from the requirement to transform the earth-fixed coordinate system velocity and acceleration components into aircraft-fixed coordinate velocity and acceleration components. Because the rotations being dealt with are discrete rather than differential, the order of the transformation matrices is fixed. This is also demonstrated in appendix C.

13. ACTRM2

- a. expanded name: Aircraft Transformation Matrix #2
b. function: Carry out the second transformation whereby the x-axis is rotated up/down out of the horizontal plane to go through the nose of the aircraft.
c. equations/calls:

```
ANG=THENEW
U3=COS (ANG) *U2-SIN (ANG) *W2
V3=V2
W3=SIN (ANG) *U2+COS (ANG) *W2
UD3=COS (ANG) *UD2-SIN (ANG) *WD2
VD3=VD2
WD3=SIN (ANG) *UD2+COS (ANG) *WD2
```

- d. comments: See appendix C.

14. ACTRM3

- a. expanded name: Aircraft Transformation Matrix #3
b. function: Carry out the third transformation whereby the y-axis is rotated up/down out of the horizontal plane to go through the right wing (as referenced from the cockpit).
c. equations/calls:

```

ANG=PHINEW
UAC=U3
VAC= COS (ANG)*V3+SIN (ANG)*W3
WAC=-SIN (ANG)*V3+COS (ANG)*W3
UDCTAC=UD3
VDCTAC= COS (ANG)*VD3+SIN (ANG)*WD3
WDCTAC=-SIN (ANG)*VD3+COS (ANG)*WD3

```

d. comments: See appendix C.

15. ACRVEL

- a. expanded name: Aircraft Rotational Velocities
- b. function: Convert (transform) the rotational velocities from the earth-fixed coordinate system to the aircraft-fixed coordinate system.
- c. equations/calls:

```

ANG1=THENEW
ANG2=PHINEW
P=PHIDOT-SIN (ANG1)*PSIDOT
Q= COS (ANG2)*THEDOT
*   COS (ANG1)*SIN (ANG2)*PSIDOT
R=-SIN (ANG2)*THEDOT
*   COS (ANG1)*COS (ANG2)*PSIDOT

```

d. comments: See figure 5.7 for sense. See appendix C for derivation.

16. ACACC

- a. expanded name: Aircraft Accelerations
- b. function: Sum up the linear and rotational accelerations imposed on the aircraft.
- c. equations/calls:




Figure 5.7 Aircraft Rotational Velocities.

$$\begin{aligned} AX &= UDOTAC - VAC * R + WAC * Q \\ AY &= VDOTAC + UAC * R - WAC * P \\ AZ &= WDOTAC - UAC * Q + VAC * P \end{aligned}$$

d. comments: Ncne.

17. ACLMIS

- a. expanded name: Aircraft Limitations
- b. function: This is the key subroutine of the trajectory package. It calls for computation of the forces imposed on the aircraft and compares the forces to allowable values. If the forces are too great, it initiates a selective reduction in the earth-fixed acceleration components until the

forces on the aircraft fall within limitations. If the forces are less than allowable values it initiates a selective increase in earth-fixed acceleration components until the maximum value is reached.

c. equations/calls:

```
CALL THRUST
      IF (AN.LT.ANMAX.AND.FWDACC.LT.THMAX)
*      CALL BOOSTA
      IF (AN.GT.ANMAX.OR.FWDACC.GT.THMAX)
*      CALL REDUCR
```

d. comments: Ncne.

13. XCHNGE

a. expanded name: Exchange

b. function: Once the performance of the aircraft has been maximized at the point "temp", "temp" becomes accepted as a point along the trace toward waypoint "new". "Old" is moved up to "temp".

c. equations/calls:

```
XOLD=XTEMP
YOLD=YTEMP
ZOLD=ZTEMP
UOLD=UTEMP
VOLD=VTEMP
WOLD=WTEMP
PSICLD=PSINew
THECLD=THENEW
PHICLD=PHINew
VELCO=VELOT
```


- d. comments: This is, in effect, the movement forward of the "aircraft" to "temp", the next increment toward waypoint "new".

19. WAYPNT

- a. expanded name: Waypoint
b. function: Load the accepted values into vectors for use elsewhere in the non-BIGCAL portion of IBMPIP.
c. equations/calls:

```
WX (ICT)=XOLD  
WY (ICT)=YOLD  
WZ (ICT)=ZOLD  
WU (ICT)=UOLD  
WV (ICT)=VOLD  
WW (ICT)=WOLD  
WH (ICT)= - PSINEW  
WP (ICT)= THENEW  
WR (ICT)= - PHINEW  
WG (ICT)=AN  
T (ICT)=T (ICT-1) +DELTEE
```

- d. comments: The minus signs appear in WH(ICT)= and WR(ICT)= to account for transformation back into the original map coordinate system which has z pointing up.

20. FILE

- a. expanded name: Write to file
b. function: Immediately write all the appropriate information to disk file for future use
c. equations/calls:

```
IF (XOLD.NE.XNEW.OR.YOLD.NE.YNEW.OR.ZOLD.NE.ZNEW)  
*   GOTO 10
```

```

        WRITE(11,100) I(ICT),WX(ICT),WY(ICT),WZ(ICT),
*
*           WU(ICT),WV(ICT),WW(ICT),
*           WH(ICT),WP(ICT),WR(ICT),
*           WG(ICT),LTR
        RETURN
10      CONTINUE
        LTR=0
        WRITE(11,100) I(ICT),WX(ICT),WY(ICT),WZ(ICT),
*
*           WU(ICT),WV(ICT),WW(ICT),
*           WH(ICT),WP(ICT),WR(ICT),
*           WG(ICT),LTR
100     FORMAT(11(F10.2,1X),I3)

```

- d. comments: The if statement is the current method of "breaking out" of BIGCAL when the program arrives at the waypoint "new". To aid in reading the data files the control variable LTR is set to zero for all the interim points on the curve. LTR is a notification by the user of arrival at certain key points in the game scenario and are described elsewhere.

21. GRAFIX

- a. expanded name: Graphics subroutine
b. function: Use the WX(ICNT) and WY(ICNT) vector values to plot the trace of the flightpath on the graphics screen.
c. equations/calls:

```

PX1=WX(ICT-1)
PY1=WY(ICT-1)
PX2=WX(ICT)
PY2=WY(ICT)
CALL WIN(MINX,MAXX,13000.,12000.,0)
CALL GBVECT(0.,PX1,PY1)

```

```
CALL GBVECT(1.,PX2,PY2)
CALL GSFRCE
```

d. comments: The equations

```
PX1=WX(ICT-1)
PY1=WY(ICT-1)
PX2=WX(ICT)
PY2=WY(ICT)
```

establish the beginning and end points of the draw.
The call to the subroutine WIN (window)

```
CALL WIN(MINX,MAXX,18000.,12000.,0)
```

reaches into non-BIGCAL IBMPIP. For here it is simply described as a definer of the portion of the graphics screen on which the drawing is to take place. The calls

```
CALL GBVECT(0.,PX1,PY1)
CALL GBVECT(1.,PX2,PY2)
```

are calls to the graphics package GRAF 77, the IBM graphics package at Naval Postgraduate School. GBVECT passing a (0.) interprets as "Move to the following coordinates.". GBVECT passing a (1.) interprets as "Draw to the following coordinates". The final call

```
CALL GSFRCE
```

forces the actual updating of the graphics screen with the move and draw just called for.

C. THIRD LAYER SUBROUTINES

The following subroutines are accessed through SIGCAL. Their overall function is to compute the forces on the "aircraft" based on the accelerations in the "aircraft's" coordinate system. Once the forces are established, a forth level subroutine, which will be included here for continuity, re-drives the higher level subroutines to iterate (ultimately) the forces to within limitations.

1. THRUST

- a. expanded name: Thrust and g-load
- b. function: Establish the forward acceleration and g-load on the airframe.
- c. equations/calls:

```
ANG=THENEW
THRQD=AX/GEE
AN=SQRT (AY**2+AZ**2) /GEE
SIGMA=(1+D TDH*ZTEMP/TO) **4.257
RHOALT=RHO SSL*SIGMA
CL= (2.*AN*WL) / (RHOALT*VELOT**2)
DRAG=AN*((CDO+CDK*CL**2) /CL)
FWDACC=SIN (ANG) +THRQD+DRAG
```

- d. comments: The equation

```
ANG=THENEW
```

establishes the "aircraft's" attitude above or below the horizon and is necessary for computing the direction through which gravity forces act upon the "aircraft". The following equations respectively

```
THRQD=AX/GEE
AN=SQRT (AY**2+AZ**2) /GEE
```

compute the longitudinal non-dimensionalized acceleration based on the user's desired move and the composite non-dimensionalized acceleration perpendicular to the longitudinal axis. The next equation

$$\text{SIGMA} = (1 + \text{DTDH} * \text{ZTEMP} / \text{TO}) ** 4.257$$

is the density ratio (altitude to sea-level) and is a function of standard temperature lapse rate and altitude. It is derived in appendix 3. The density at altitude is then

$$\text{RHOALT} = \text{RHOSL} * \text{SIGMA}$$

the density at sea-level times the given ratio. The density, velocity, non-dimensional g-load and wing loading (found in BLOCK DATA) are

$$\text{CL} = (2. * \text{AN} * \text{WL}) / (\text{RHOALT} * \text{VELOT} ** 2)$$

fed into the equation for coefficient of lift. Drag is a function of the coefficient and is given as:

$$\text{DRAG} = \text{AN} * ((\text{CDO} + \text{CDK} * \text{CL} ** 2) / \text{CL})$$

The components gravity, forward acceleration (required) and the

$$\text{FWDACC} = \text{SIN}(\text{ANG}) + \text{THRQD} + \text{DRAG}$$

resulting drag on the airframe are summed to give the total forward acceleration on the "aircraft". (The acceleration will be negative if user "slows down".)

2. BOOSTR

- a. expanded name: Performance booster
- b. function: Increase the "aircraft" performance up to the allowable maximum thrust or g-load, whichever is smaller.

c. equations/calls:

```

      ACCUM=1
5      CONTINUE
      I=0
      IF (AG1.EQ.DELX.OR.AG1.EQ.0.) GOTO 10
          IF (ABS (AG1) .LT. ABS (AH1) .AND. ABS (AG1) .LT.
*          ABS (AI1)) I=1
              IF (I.NE.1) GOTO 10
                  UDOT=1.02*UDOT
10     CONTINUE
      IF (AH1.EQ.DELY.OR.AH1.EQ.0.) GOTO 20
          IF (ABS (AH1) .LT. ABS (AG1) .AND. ABS (AH1) .LT.
*          ABS (AI1)) I=2
              IF (I.NE.2) GOTO 20
                  VDOT=1.02*VDOT
20     CONTINUE
      IF (AI1.EQ.DELZ.OR.AI1.EQ.0.) GOTO 30
          IF (ABS (AI1) .LT. ABS (AG1) .AND. ABS (AI1) .LT.
*          ABS (AH1)) I=3
              IF (I.NE.3) GOTO 30
                  WDOT=1.02*WDOT
30     CONTINUE
      IF (AG1.EQ.DELX.OR.AG1.EQ.0.) GOTO 40
          IF (ABS (AG1) .EQ. ABS (AI1) .AND. ABS (AG1) .LT.
*          ABS (AH1)) I=4
              IF (I.NE.4) GOTO 40
                  UDOT=1.02*UDOT
                  WDOT=1.02*WDOT
40     CONTINUE
      IF (AH1.EQ.DELY.OR.AH1.EQ.0.) GOTO 50
          IF (ABS (AG1) .EQ. ABS (AH1) .AND. ABS (AG1) .LT.
*          ABS (AI1)) I=5
              IF (I.NE.5) GOTO 50

```

```

                                UDOT=1.02*UDOT
                                VDOT=1.02*VDOT
50      CONTINUE
      IF (AI1.EQ.DELX.OR.AI1.EQ.0.) GOTO 10
      IF (ABS(AH1).EQ.ABS(AI1).AND.ABS(AH1).LT.
*      ABS(AG1)) I=0
      IF (I.NE.3) GOTO 60
      VDOT=1.02*VDOT
      WDOT=1.02*WDOT
60      CONTINUE
      CALL SMLCAL
      CALL THRUST
      IF (AN.GE.ANMAX.OR.FWDACC.GE.IHMAX) GOTO 70
      GOTO 5
70      CONTINUE
      IF (AN.GE.ANMAX) AN=ANMAX
      IF (FWDACC.GT.IHMAX) FWDACC=IHMAX

```

d. comments: The logic statements

```

      IF (AG1.EQ.DELX.OR.AG1.EQ.0.) GOTO 10
      IF (AH1.EQ.DELY.OR.AH1.EQ.0.) GOTO 20
      IF (AI1.EQ.DELZ.OR.AI1.EQ.0.) GOTO 30
      IF (AG1.EQ.DELX.OR.AG1.EQ.0.) GOTO 40
      IF (AH1.EQ.DELY.OR.AH1.EQ.0.) GOTO 50
      IF (AI1.EQ.DELZ.OR.AI1.EQ.0.) GOTO 60

```

avoid iterating on orthogonal directions that are defined as zero by user input and to turn off iteration when then "aircraft" has arrived at the destination (in that coordinate plane). The logic equations that follow choose the direction

```

      IF (ABS(AG1).LT.ABS(AH1).AND.ABS(AG1).LT.
*      ABS(AI1)) I=1
      IF (ABS(AH1).LT.ABS(AG1).AND.ABS(AH1).LT.

```

```

*      ABS(AI1)) I=2
      IF (ABS(AI1).LT.ABS(AG1).AND.ABS(AI1).LT.
*      ABS(AH1)) I=3
      IF (ABS(AG1).EQ.ABS(AI1).AND.ABS(AG1).LT.
*      ABS(AH1)) I=4
      IF (ABS(AG1).EQ.ABS(AH1).AND.ABS(AG1).LT.
*      ABS(AI1)) I=5
      IF (ABS(AH1).EQ.ABS(AI1).AND.ABS(AH1).LT.
*      ABS(AG1)) I=6

```

in which the iteration is to take place. The selection criteria is the coordinate plane in which there is the least distance left to go to the destination. Thus for small altitude changes, the "aircraft" will "pop-up" to the desired altitude as soon as physically possible. In other situations the "aircraft" will turn in shortest direction first. Finally, the acceleration (in map coordinates) in the selected coordinate plane is increased in magnitude

```

UDOT=1.02*UDOT
VDOT=1.02*VDOT
WDOT=1.02*WDOT

```

until performance limitations are reached.

3. REDUCR

- a. expanded name: Demanded performance reducer
- b. function: For a user defined waypoint that exceeds the allowable maximum thrust or g-load, whichever is smaller, reduce the performance demand.
- c. equations/calls:

```

      MCONT=1
5      CONTINUE
      VELCN=VELON-DELTU
      A=VSTALL+2.*DELTU

```



```

      IF (VELON.GE.A) GOTO 10
      ANG=180*(90/ATG)
      ACC=1.1*ACC
      AR1=COF(ANG)*AJ2
      AR1=SIN(ANG)*AJ2
      VELON=V1
10      CONTINUE
      N=0
      CALL MVELOS
      CALL MVDOTS
      CALL SMLCAL
      CALL THRUST
      IF (AN.LE.ANMAX.AND.FWDACC.LE.THMAX) GOTO 20
      GOTO 5

```

- d. comments: The tact adopted is different from the one chosen for ECOSTR. The "aircraft" in moving from "old" to "new" has a radius of curvature. When the performance limitations of the "aircraft" are exceeded, this means the "aircraft" cannot fly with a small enough radius of curvature to converge on the waypoint "new". The two available means of meeting the demand are to decrease the "aircraft's" deliverable radius of curvature by reducing the destination ("new") velocity or increase the demanded radius of curvature to something the "aircraft" can accomplish by moving the point "new" further away from the point "old". Frequently a small change in velocity is sufficient, therefore

VELON=VELON-DELTV

is chosen as the first iteration. DELTV is a velocity increment found in BLOCK DATA and

represents approximately five knots airspeed in meters per second. This value was chosen as representative of an attack pilot's maximum precision in airspeed control. There is a lower bound to which airspeed may be reduced, and that is the stall limitation of the aircraft. When the "aircraft" is

```
A=VSTALL+2.*DELT  
IF(VELON.GE.A) GOTO 10
```

close to this limit, the second portion of the subroutine is invoked

```
ANG=ACOS(AG1/AJ2)  
AJ2=1.1*AJ2  
AG1=COS(ANG)*AJ2  
AH1=SIN(ANG)*AJ2  
VELON=V1
```

to move the point "new" further out. Note the final equation; the view is adopted that an attack pilot will not wish to be at a minimum energy anywhere in the approach phase. Therefore the originally selected airspeed is reset into the iteration.

In summation, this approach was taken in preference to merely setting demanded performance equal to maximum deliverable performance to avoid the unrealistic scenario depicted in figure 5.8

4. SMLCAL

- a. expanded name: Small call
- b. function: This forth level subroutine was written as a programmer convenience to drive the iterations.
- c. equations/calls:

```
CALL DELVEC  
CALL TMPNT
```




Figure 5.8 Unrealistic Scenario.

```
CALL TMPVEL
CALL INFTRM
CALL ANGLES
CALL ROTRAT
CALL ACTRM1
CALL ACTRM2
CALL ACTRM3
CALL ACVEL
CALL ACACC
```

d. comments: As can be seen the subroutines are those previously described.

VI. NON-BIGCAL IBMPIP SUBROUTINES

A. INTRODUCTION

For the sake of brevity, the only subroutine addressed in the section below is the one that was drastically altered to accomodate the BIGCAL package. The rest of the subroutines that are not mentioned may be found in the listing at the end of the thesis. They will have changes from the Johns [Ref. 1] version of IBMPIP but will also have extensive numbers of comment cards to describe to key points of each subroutine.

The final section provides a consolidated listing of the graphics calls along with a short description of their use. For follow-on alterations to this version of IBMPIP the user should consult [Ref. 2] for complete description of the available graphics subroutines.

B. SUBROUTINES

1. ERRCHK

- a. expanded name: Error checking
- b. function: Check the user defined "new" waypoint for game rule violations or user commands before entering into the BIGCAL subroutines.
- c. equations/calls:

```
DX=TARGX-X1
DY=TARGY-Y1
DIST=SQRT(DX**2+DY**2)
IF(DIST.LE.POPMIN) GOTO 10
  IF(Z1.GT.APPMAX) Z1=APPMAX
  IF(Z1.LT.HIMIN) Z1=HIMIN
```

```

10      CONTINUE
      IF (LTR.NE.65.OR.LTR2.NE.65) GOTO 20
      IF (Z1.LT.BAALT) Z1=BAALT
20      CONTINUE
      IF (LTR.NE.66.OR.LTR2.NE.66) GOTO 60
      IF (Z1.LT.BRMIN) Z1=BRMIN
      IF (Z1.GT.BRMAX) Z1=BRMAX
      IF (DIST.LE.BRMAX.AND.DIST.GE.BRMIN)

GOTO 30

      IF (DIST.GT.BRMAX) IERR=9
      IF (DIST.LI.BRMIN) IERR=13
      RETURN

30      CONTINUE
      TGTHDG=ATAN2(DY,DX)*RTD
      IF (TGTHDG.LT.0.) TGTHDG=TGTHDG+360.
      DX=X1-WX (ICT)
      DY=Y1-WY (ICT)
      ACHDG=ATAN2(DY,DX)*RTD
      IF (ACHDG.LT.0.) ACHDG=ACHDG+360.
      HDGLMT=ABS(TGTHDG-ACHDG)
      IF (HDGLMT.LE.5.) GOTO 40
      IERR=10
      RETURN

40      CONTINUE
      DIST=SQRT(DX**2+DY**2)
      SPEED=SQRT(WU (ICT) **2+WV (ICT) **2+WW (ICT) **2)
      DT=DIST/SPEED
      IF (DT.GE.2.33) GOTO 50
      IERR=10
      RETURN

50      CONTINUE
60      CONTINUE

```

d. comments: The first equations establish the distance from

```
DX=TARGX-X1
DY=TARGY-Y1
DIST=SQRT(DX**2+DY**2)
```

the waypoint "new" to the target. The next group of equations

```
IF (DIST.LE.POPMIN) continue
IF (Z1.GT.APPMAX) Z1=APPMAX
IF (Z1.LT.HTMIN) Z1=HTMIN
CONTINUE
```

look at the user input altitude. If the user exceeds either the maximum or minimum inbound altitudes, the input altitude is automatically set to the limiting parameter. APPMAX, HTMIN, and POPMIN are found in BLOCK DATA. The next group of lines satisfy the game parameter that the "aircraft" must be "popped-up" to a given altitude before aim at the target can be taken. LTR is the code passed from

```
IF (LTR.NE.65.OR.LTR2.NE.65) continue
IF (Z1.LT.BAALT) Z1=BAALT
CONTINUE
```

the graphics subroutines signifying that the bomb aim line is desired. LTR2 is a back-up code passed from the same subroutines and allows the user to change his/her mind while still entering data. LTR is generated upon entry of the X-Y point on the graphics screen. LTR2 is generated upon entry of the Z-velocity point on the graphics screen. BAALT is the mnemonic for bomb aim altitude and is found in BLOCK DATA. The following statements all relate to

the bomb release point. If bomb release is not called for;

```
IF (LTR.NE.66.05.LTRD.NE.66) GOTO 60
```

skips over all the rest and returns to MAIN. If at bomb release the altitude is too high or low,

```
IF (Z1.LT.BRMIN) Z1=BRMIN
```

```
IF (Z1.GT.BRMAX) Z1=BRMAX
```

set the altitude to the minimum/maximum allowable. BRMIN is the mnemonic for minimum bomb release altitude, BRMAX is similar, and both are defined in BLOCK DATA. Because the flight path is now curvilinear, there is no convenient way to correct for an input that violates minimum or maximum bomb release range (from target). Error codes are generated that inform the user that the just-entered point will have to be moved. BRMAX and BRMIN are found in BLOCK DATA.

```
IF (DIST.LE.BRMAX.AND.DIST.GE.BRMIN) continue
```

```
IF (DIST.GT.BRMAX) IERR=9
```

```
IF (DIST.LT.BRMIN) IERR=13
```

```
RETURN
```

```
CONTINUE
```

The following group of statements compare the heading from the aimpoint to the target with the aircraft heading to the target.

```
TGTHDG=ATAN2(DY,DX)*RTD
```

```
IF (TGTHDG.LT.0.) TGTHDG=TGTHDG+360.
```

```
DX=X1-WX(ICT)
```

```
DY=Y1-WY(ICT)
```

```
ACHDG=ATAN2(DY,DX)*RTD
```

```
IF (ACHDG.LT.0.) ACHDG=ACHDG+360.
```

```

HDGLMT=ABS(TGTHDG-ACHDG)
IF (HDGLMT.LE.5.) continue
      IERR=10
      RETURN
CONTINUE

```

If the "aircraft" heading is not within five degrees of the aimline the user is informed, and the point must be user moved. RTD is the mnemonic for radians to degrees and is found in BLOCK DATA. If the aircraft does not travel down the aimline for a minimum of 2.33 seconds

```

DIST=SQRT(DX**2+DY**2)
SPEED=SQRT(WU(ICT)**2+WV(ICT)**2+WF(ICT)**2)
DT=DIST/SPEED
IF (DT.GE.2.33) GOTO continue
      IERR=11
      RETURN
CONTINUE

```

the user is informed, and must make the correction.

C. GRAPHIC CALLS

DSINIT

function: Initialise both of the 3277 screens.

DSTERM

function: Terminates dual screen graphics activity.

GASVIE(aa,bb)

function: Defines a viewport, or a smaller portion of the total graphics screen available. Allows subdividing the total screen into several smaller pictures.

GASWIN(aa,bb)

function: Takes the data being supplied by the user's equations and converts it into absolute graphic screen coordinates in preparation for drawing. Takes care of proportionality.

GAXCTI(aa,bb,cc,dd,ee)

function: Convert user supplied character strings into integer vectors.

GAXITC(aa,bb,cc,dd,ee)

function: Convert one or more integers into characters in preparation for writing onto the graphics screen.

GBCHAR(aa,bb,cc,dd,ee,ff)

function: Invokes two lower-level graphics calls to write characters on the graphics screen in the defined font.

GBGARC(aa,bb,cc,dd,ee,ff,gg)

function: Invokes two lower-level graphics call to generate an arc of either a circle or an ellipse (can also be the whole circle, etc).

GBGDOT(aa,bb,cc)

function: Invokes two lower-level subroutines to draw a filled-in dot.

GBRXYC(aa,bb,cc)

function: Read one graphic data point using the cursor cross-hairs.

GBVECT(aa,bb,cc)

function: Generates a "move-to" or a "draw-to" command, depending on whether (aa) is zero or non-zero (real number).

GSERSE

function: Erase the graphics screen.

GSFRCE

function: Force an immediate update of the graphics
screen with new data.

GSLI(aa)

function: Sets the line type to be used for drawing
(dot, dashed, etc.).

VII. STATUS OF PROPOSED IBMPIP AND SUMMARY

Despite best efforts, the proposed version is not ready for implementation. The flaws revealed by extensive testing, center around the two iterative subroutines and are felt to be solvable. In particular, subroutine MVDOTS does not account for the following situation, see figure 7.1:




Figure 7.1 A Situation Not Addressed By Subroutine ACACC.

$$ACC = (VELON**2 - VELOO**2) / (2 * AJ1)$$

$$UDOT = (AG1 / AJ1) * ACC = 1. * ACC = ACC$$

$$VDOT = (0. / AJ1) * ACC = 0.$$

We see that by the model, $V_{DOT}=0$. Realistically, this will not be so. There is a V_{OLD} and the "aircraft" will move some Y distance below "old". Let that distance be named $Y(unknown)$ or Y_{UNK} . V_{DOT} then will actually be:

$$V_{DOT}=V_{OLD}**2/(2*Y_{UNK}) \text{ -- or some positive value.}$$

The best estimate at an approach would be either to guess a temporary distance based upon the ratio;

$$(V_{OLD}/U_{OLD}) * \Delta t$$

or to guess a temporary distance based upon a linear guess of the elapsed time between "old" and "new". Let linear time estimate be represented by LTE , then:

$$LTE=ABS((U_{NEW}-U_{OLD})/U_{DOT})$$

$$Y_{UNK}=V_{OLD}*LTE$$

$$V_{DOT}=-V_{OLD}/(2*((U_{NEW}-U_{OLD})/U_{DOT}))$$

Another area of concern is in the definition of the angles in subroutine ANGLES. Artificially large effects are felt in the angles PS_{NEW} and PH_{NEW} if $DELX$ or $DELY$ collapse to zero before the "aircraft" arrives at "new" in all three orthogonal planes. Additionally, large effects are produced in the last DEL -movement to "new", causing a hang-up in the $BOCSTR/REDUCR$ subroutines. Because the current game restricts altitude changes to approximately one magnitude less than either X or Y changes, the effect by TH_{NEW} (theta) is roughly one magnitude less throughout. To pave the way for future efforts to smooth out the angle changes between "old" and "new", the variable counter $MCCNT$ was added to $COMMON/ARE5/$. $MCCNT$ is set from 0 to 1 by activation of either $BOCSTR$ or $REDUCR$ and switched back to 0

upon exit from either iterative loop. As numerical data are written to test files, the addition of MCONT as another column allows differentiation of first-guess values from the ECOSTR/REDUCR generated values.

The question was asked, "If the angles (and therefore rotational rates and therefore angular acceleration) components are so troublesome, how necessary are they to the accuracy of the output?". An analysis of the individual acceleration components in subroutine ACACC revealed that omission of the angular accelerations could lead to as much as a 50% difference in the magnitude of the net acceleration in any one of the orthogonal directions imposed on the aircraft. The answer then, is that smooth generation of angles is necessary if the modelled trajectory is to be considered faithful to a real flightpath.

In summation, a proposed IBMPIP improvement has been introduced and discussed. It is substantially more user friendly. It employs increased use of specialized graphics from [Ref. 2] and when completely debugged, will provide a far more accurate flightpath trace with less user interaction necessary.

APPENDIX A
USER'S MANUAL FOR CURRENT IBMPIP.

USER'S MANUAL

AE 3251
AIRCRAFT COMBAT SURVIVABILITY

A STUDY
of
AIRCRAFT ATTRITION
in a
HOSTILE AAA AND SAM ENVIRONMENT

NAVAL POSTGRADUATE SCHOOL
MCNTEREY, CALIFORNIA
WINTER QUARTER, 1984


I. INTRODUCTION


This aircraft attrition study is designed to present the student with an opportunity to see first-hand how the survivability of an aircraft can be evaluated in a given combat scenario. The methods employed in this study are those used by both industry and government when making decisions in the survivability analysis and design of an aircraft system. In this study, one computer program named P001 (the AFATL Antiaircraft Artillery Simulation Computer Program) will be used to simulate the flight of a typical Naval attack aircraft through a hostile antiaircraft artillery (AAA) environment and to compute the aircraft probability of survival. Another computer program, MICE II (the Missile Intercept Capability Evaluation Program), will be used to compute the survivability of the aircraft on the same flight path against a typical short-to-medium range surface-to-air missile (SAM).


The DOD specifies the use of P001 and MICE in all nonnuclear survivability assessments in MIL-STD-2069, REQUIREMENTS FOR AIRCRAFT NONNUCLEAR SURVIVABILITY PROGRAM, 24 August 1981.

II. PROBLEM DEFINITION

- A. You are going to conduct a survivability assessment of a familiar Naval aircraft, shown in Figs. 1 and 2, on a typical attack mission to destroy the bridge shown in Fig. 3.
- B. The class will be divided into groups of four (4), with two members in each group on the BLUE team and two members on the RED team.
- C. Each team will use P001 and MICE II to determine the survivability of the aircraft on the class problem scenario, as follows:
 - 1. Each team will generate a flight a flight path to the bridge according to the rules of the scenario given in Section IV. Keep this path a secret.
 - 2. Each team will also select the locations of six AAA emplacements and one SAM emplacement that will defend against air attack. Locate the weapons according to the order of battle given in Section IV. Keep these locations a secret also.
 - 3. Each team will conduct an attack against the other team in the following fashion: The two teams in each group will conduct a trade of offensive data files. That is; RED teams flight path will go up against the BLUE teams defensive positions and BLUE teams flight path will go up against RED teams defensive positions.







III. SCENARIO DESCRIPTION

A. This scenario is purely for instructional purposes and is not based on any actual or planned combat attack situation. The target site, order of battle, and flight path and weapon delivery parameter limits have been chosen only to provide guidelines for the class problem. As much realism has been introduced for the players as possible while retaining an unclassified scenario.

b. Your target is the bridge shown in Fig. 3 located at :

X -- 14,000 mtrs

Y --- 7,220 mtrs

Z ----- 20 mtrs

Heavy military supply traffic has been reported in this area. Your mission is to destroy this vital supply link.

C. The following order of battle has been gathered from intelligence reports of the target area:

SAM - one site in the vicinity of the target

AAA - (2) type 1 mode 1

(2) type 2 mode 1

(1) type 3 mode 3

(1) type 3 mode 4

(1) type 5 mode 3

****NOTE**** Gun types and their relationship to AAA and the SAM type will be discussed in class.

D. The SAM threat requires that the inbound approach to the target be made from the west at low level. A pop-up maneuver is required to visually identify the target followed by a dive bombing run to weapon release. The aircraft ordnance consists of MK82 500-pound Snakeeye bombs. Egress must be made either to the north or south, depending upon individual strategy.

E. The following list of scenario limitations to be used in the development of your strategy:

1. Aircraft speed limitations

- a. minimum (stall) ----- 90 m/s (175 knots)
- b. maximum, with bombs ----- 260 m/s (505 knots)
- c. maximum, bombs released -- 310 m/s (603 knots)

2. Aircraft altitude limitations

- a. prior to pop-up
 - 1). max --- 457 mtrs
 - 2). min ---- 60 mtrs
- b. after pop-up
 - 1). max -- 2050 mtrs
 - 2). min ---- 60 mtrs

3. Maneuvering -- will be limited by:

- a. thrust
- b. speed brake size
- c. aircraft "g" loading --
the shorter the leg distance
the greater the restriction on:
 - 1). amount of turn OR
 - 2). airspeed/altitude changes

****NOTE**** Remember the following rule of thumb -- The greater a change in altitude the closer together minimum and maximum allowable velocities get.

4. Pop-up maneuver

- a. max allow dist (from tgt) to pop-up -- 6000 mtr
- b. minimum acceptable pop-up altitude --- 1000 mtr

5. Ordnance delivery

- a. boresight dive/glide only type acceptable
- b. dive limitations
 - 1) must last -- 2.33 sec (606 mtrs at 260 knots)
 - 2) heading ---- must be within 5 degrees

****NOTE**** The closer the attack
is pressed to the target,
the more precisely placed

the bomb release point must be.

c. bomb release ranges

- 1) max allowable from tgt -- 1000 mtrs
- 2) min allowable from tgt --- 100 mtrs

d. bomb release altitude limitations

- 1) max allowable -- 2000 mtrs
- 2) min allowable --- 100 mtrs

F. Weapons emplacements

1. order of emplacement fixed by program and goes

(2) type 1 mode 1

(2) type 2 mode 1

(1) type 3 mode 3

(1) type 3 mode 4

a seventh type 5 mode 3 battery

is always fixed at location

X=12,800 mtr/Y=7,500 mtr (near bridge)

2. neither of the type 3 batteries may be placed closer than 3000 mtrs from bridge.

3. (1) type 5 SAM battery may be put anywhere east of the 6000 mtr X location

G. Locate the AAA & SAM batteries (constrained by the above conditions) to defend the bridge.

H. Develop a flight path originating at an entry point anywhere near (but not 'on') the western boundary, attack the bridge and exit the map anywhere near (but not 'on') the northern or southern boundaries.

I. May the force be with you.

IV. PROCEDURES FOR OPERATING IBMPIP

- A. In gross terms, the following will take place:
1. a computer session with IbmPIP
 2. submission of your data to (2) batch programs to determine your success
 3. making a hard copy of your map from the Tektronix TEK618 terminal
- B. The following equipment is required: a graphics station consisting of:
1. an IBM3277 alpha-numeric terminal
 2. a Tektronix TEK618 graphics screen
 3. an IBM cursor control joystick

Many will be familiar with the above from working with the 'DISPLA' programs. Additional information will now be supplied to enable utilization for this interactive graphics program.

- C. Preflight:
1. ensure graphics terminal switched on
 2. joystick set up -- ensure all three (3) blue rocker switches are in the (NORMAL) position
 3. the 3277 terminal should always be 'power on' -- if not -- do so now and set screen intensity to your satisfaction

D. Program execution

Refer to Appendix A to link up to Aero Disk, run IBMPIP and generate a flight path. Appendix B shows the sequence for gun/missile positioning. The black arrow heads are user entered commands or responses.

- The following notes amplify certain aspects of the procedure. Read the Appendices and refer to these notes.

GUNS: 0=DISK FILE; 1=TERMINAL; 2=PRESET

Do not choose DISK FILE until you have created one by utilizing TERMINAL to input some gun/missile locations. The locations entered at TERMINAL will on your disk as SUB LOC A1.

AIRCRAFT MILESTONE INPUT: 0=DISK 1=TERMINAL

For the same reason as above do not choose DISK until you have created a file by utilizing TERMINAL. Your flight path will be written on your disk as PTS LOC A1.

ERROR CHECKING: 0=NO CHECKING 1=CHECK FOR ERRORS

Recommend only using error checking when entering aircraft flight path at terminal. It will erroneously activate on good data points being read in from the data file you will create.

FLIGHT & GAME PARAMETERS 1=DEFAULT 2=USER INPUT

For class competition, select 1.

VILLAGE DRAWN 0=NOT DRAWN 1=DRAWN

User preference.

ENTER AIRCRAFT MILESTONES

Look at bottom right hand corner of the IBM screen. You will see MORE... This is a prompt for you to hit CLEAR key. When you do,

1. The border of the map on the graphics screen will flash and the red light on joystick control will illuminate.
2. You may or may not see cross hairs on your graphics screen. Move the joystick around and try to find it.

3. If the cross hair is to faint, turn CLOCKWISE the WRITE THROUGH INTENSITY knob under the graphics screen. Not too much....
4. If the cross hair is too intense it will wipe a bright band across map messing it up. Turn COUNTERCLOCKWISE the WRITE THROUGH INTENSITY knob, until it stops.
5. The cross hair may drift slowly without your moving the joystick. Two little slider switches, under and to the right of the joystick are used to null out this drift. Move the obvious one until unwanted motion stops.
6. To enter a point: Manipulate the joystick until the cross hairs are somewhere near the western border. The number keys on top of the keyboard are the ones used to enter a data point. Press any key greater than 4. A dot will appear and then the border around the altimeter/airspeed bar will flash, prompting you to move the crosshair over there. Do so.

The vertical cross hair is to be set on your desired airspeed (as read from the tick marks on the bottom), slow on the left, fast on the right. Altitude is determined by the horizontal cross hair. When satisfied, press a number key greater than 4. A dot will appear and the border will flash (if all goes well) prompting you to return to do the next point.

If all does not go well, the skinny rectangle to the right of the graphics screen flashes and you will get an error message. A list of all possible error messages is now provided. Read them and the suggested user responses.

***** AIRCRAFT *****

MAXIMUM BRAKING EXCEEDED

The aircraft unable to slow down to chosen speed -- increase speed.

MAX G EXCEEDED

Rare -- usually aircraft is not able to handle G-load of turn -- try slowing down a little.

MAX THRUST EXCEEDED

The airspeed chosen is too fast -- slow down a little.
NOTE When maneuvering near the target, the distance between MAX BRAKING and MAX THRUST can get to be small. If unable to find an airspeed between them, next try changing altitude. If still unable to fit between the limiters, you will have to back up and enter a new X-Y location and try again.

ALT TCO LOW

Self explanatory.

ALT TCO HIGH

Self explanatory

POP-UP TCO LOW

Self explanatory.

BMB DRCP LOW

Self explanatory.

BMB DROP HI

Self explanatory.

STALL

Rare -- try increasing airspeed.

HDG<5 DEG TO TGT

Must reenter the X-Y point. Do a better job of putting point on bomb aim line.

FINAL RUN<2.33 SEC

Must reenter the X-Y point -- put it further down the aimline toward the target.

NO HCRIZCNTAL MOTION

Rare You didn't move far enough away from last entered point. Reenter a new X-Y point.

MAX LIFT EXCEED

Extremely rare. Manuever too severe. Try adjusting speed downward or moving altitude closer to the last one entered.

***** GUNS *****

TOO CLOSE TC IGT

Type 3 guns not far enough out from bridge. -- Reenter.

***** MISSILE *****

X COORDINATE LESS THAN 6000'

Missile is too close to the western border. Move to east of 6000 mtr line.

If you make an error and do not throw away the X-Y point, the altimeter border will flash and you may make you airspeed/altitude corrections. If you choose to correct the X-Y point, the map border will flash and you must then go over and reenter the point, see the altimeter flash and

return to it to reenter the associated altitude/airspeed combination.

If all goes well, no error is made and the user proceeds. Once the second point is entered, the program will connect-the-dots. Observe Fig 4.

As you progress, your flight path may resemble Fig. 5.

At this time note the bold rings on the map.

1. The outer ring is used for aircraft pop-up. Once inside the ring, you may at any time commence pop-up.
2. The inner ring is used for placing gun/missile batteries and is explained elsewhere.

Observe Fig. 6. In the artificial case presented here, the user knows where the guns are and is maneuvering around them to a thin spot in the defense. Up to point 11, the aircraft is maintained at a low altitude. Note where the dots are on the altimeter bar.

Observe Fig. 7. The user has popped up between points 12 and 13. Observe the lone altitude dot at about 1250 mtrs altitude. The user is ready to take aim as he is about to input point 13. Number 1 key is the aim button. Press it for both the X-Y point and the associated altitude. A dotted line will appear. This is the line you must be on to release the bombs.

Observe Fig. 8. Point 14 is entered using Number 2 key. Bombs Away. Press the Number 2 key for both the X-Y point and the associated altitude. Note the 3 dots at about 800 mtrs -- it took 3 tries to get the airspeed right. It is now time to separt Dodge City. Point 15 is entered using Number 4 key. Again, as always, do this for both the X-Y point and the associated altitude. Normal termination of the program occurs.

Summary of the special keys:

1=take aim

2=bomb release

3=abnormal termination

4=normal termination

****NOTE**** Abnormal termination is used to go back to a point on the flight path and start over.

****NOTE**** The significance of these four (4) keys only applies to aircraft milestone entry. Any numbered key is appropriate for entering gun/missile locations.

ARE YOU FINISHED WITH THIS FLIGHT PATH: 0=NO 1=YES

Answer with 1, the 0 isn't working at present.

OUTPUT FILE: 0=NO OUTPUT; 1=OUTPUT

In order to submit your data to either P001 or MICE you must have generated both a guns/missile AND a flight path file. Until both are done or when experimenting without a desire for survival statistics, select 0=NO OUTPUT and IBMPIP will terminate.

EXTENDED OUTPUT: 0=NOT WANTED: 1=EXTENDED OUTPUT

Select 0; there is a bug in selection 1 which does not affect the operation of the game.

MISSILE TYPE BETWEEN 1 AND 7

Select 5 only; the performance data on the other missiles are not contained in this instructional package.

ENTER YOUR USER ID NUMBER: -- WITHOUT THE "p"

The questions you are now answering are for the automatic generation of JCL (Job Control Language) cards that will be inserted into the P001 DATA A1 and/or the MICE DATA A1 files for submission to batch processing.

At this time refer to Appendix B for procedures on entering gun emplacements.

**** CHOICE 1 NEGATES GOING TO ALTIMETER**

The advantage of choice 1 to the user is the convenience of not going over to the altitude bar for the guns/missile; each time a battery is emplaced, the map border will flash again, prompting the input of the next battery. Should 2 be selected, there is no program limit on how high a gun may be emplaced. Consult with the instructor to determine his wishes.

ERROR CHECKING: 0=NO CHECKING, 1=CHECKING

You have all ready become acquainted with the possible gun/missile errors. It is recommended that error checking be not selected, for the following reason. As earlier mentioned, error checking will trigger on flight path data being read in from a data file. At present, once guns/missile are entered, the user must still either generate a flight path at the terminal, or read one in from a data file in order for program to progress normally.

ENTER GUN LOCATIONS

Look at the bottom right hand corner of the IBM screen. You will see MORE... You are being prompted to hit the CLEAR key. At this time, the map border will flash and the cross hairs will appear again.

At this time look sequentially at Figs. 9,10,11,12,13,14,&15. The fixed, type 5 battery is all ready in place. In each succeeding frame, another battery is emplaced.

Now note the inner bold ring. This is the 3000 str limit, outside of which your type 3 weapons must be emplaced. Note Figs. 14 and 15.

When the last user defineable battery is emplaced, the IBM screen will illuminate with the following message: ENTER MISSILE LOCATION along with the now familiar MORE... Again hit the CLEAR key and enter the missile location. Observe Fig. 16 carefully, as the missile symbol is not large. (X=8,500,Y=9,500).

At this point you will be prompted with ENTER AIRCRAFT MILESTONES. Proceed as discussed under Aircraft.

E. AT COMPLETION OF SESSION

When you are all done, and IBMPIP is terminated you should have a GUN LOC file and a PTS LOC file residing on your A1 disk. If you are not ready at this time to conduct file exchanges with the opposing team you release the 222 B disk with the command:

REL 222

then log off or whatever.

F. HOW TO MAKE A HARD COPY

To make a hard copy of your map, reach over and hit the HARD COPY button on the graphics screen. A loud racket will indicate which printer is making the copy. Most of the graphics screens indicate to which printer they are attached. You may have to turn on the printer as they are noisy and are frequently left off until needed. If you turn the printer on, give it 30 seconds to 1 minute to warm up or copy quality will be non-existent or severely degraded. Darkness of the copy is controlled by the HARD COPY INTENSITY knob under the graphics screen. CLOCKWISE increases darkness.

G. PRIOR TO EXCHANGING FILES

Exchanging files is the method of attacking or defending against the opposing team. If a file is sent to another user and that user has a file by the same name the incoming file will overwrite the existing file destroying the existing file unless precautions are taken.

The following is recommended; RED team; rename your pts loc file PTSR LOC BLUE team rename your pts loc file PTSB LOC

This can be done inside FLIST in the following manner; Place cursor beside PTS LOC and type

RENAME / PTSR = =

and hit enter. (The BLUE team, of course, would use PTSB) Now your file is protected.

(BLUE/RED) team; SEND your (PTSB/PTSR) LOC file to the opposition. If the respective teams do not have a SEND EXEC file, one may be obtained from the Aero Disk. Link up to the disk using the previous instructions. When linked, issue the following command,

SEND (you user number) SEND EXEC.

Example; SEND 2408p SEND EXEC

Don't forget to release 222 when done. For instructions on how to use SEND, merely type SEND. It will also tell the receiver how to load the PTSx LOC file sent to them. To load this SEND EXEC on your disk issue either of the following commands;

RDR

DISK LOAD

Once the files are received, rename them back to PTS LOC. Link to the Aero Disk using the described procedures. Run IEMPIP and select

0=DISK for guns 0=DISK for aircraft

with ERROR CHECKING off. At the completion of your run the P001 and MICE printouts will report on how well the oppositions aircraft did against your defense. The other team will (hopefully not gleefully) report to you how well your flight fared against their defense. Good Luck.

APPENDIX B
DERIVATION OF EQUATIONS USED IN TEXT

From [Ref. 3], instantaneous velocity is given as;

$$v = \frac{ds}{dt}$$

and instantaneous acceleration is given as:

$$a = \frac{dv}{dt}$$

If the first equation is solved for it and substituted into the second equation, the following results:

$$a ds = v dv$$

If the acceleration is presumed constant over finite distances, the above equation may be integrated:

$$a \int_0^s ds = \int_{v_{old}}^{v_{new}} v dv$$

$$a = \frac{v_{new}^2 - v_{old}^2}{2s}$$

$$ACC = (VELON ** 2 - VELOO ** 2) / (2 * AJ1)$$

AD-A144 019


IMPROVEMENTS TO IDNPIP(U) NAVAL POSTGRADUATE SCHOOL
MONTEREY CA D A MILTON MAR 84


2/3

UNCLASSIFIED

F/G 9/2

NL





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963-A

Returning to [Ref. 3], for;

$$a = \frac{dv}{dt}$$

if the equation is recast as;

$$dv = a dt$$

and the presumption of constant acceleration is made, the following integration results;

$$\int_{V_{OLD}}^{V_{NEW}} dv = a \int_0^t dt$$

$$V_{NEW} - V_{OLD} = at$$

$$V_{NEW} = V_{OLD} + at$$

Substitute this equation into;

$$v = \frac{ds}{dt}$$

and integrate to get;

$$ds = v dt$$

$$\int_0^s ds = \int_0^t (v_{old} + at) dt$$

$$s = v_{old} t + \frac{1}{2} at^2$$

$$DELX = UOLD * DELTEE + .5 * UDOT * DELTEE ** 2$$

Reaching back;

$$\int_{v_{old}}^{v_{TEMP}} dv = a \int_0^t dt$$

$$v_{TEMP} = v_{old} + at$$

$$UTEMP = UOLD + UDOT * DELTEE$$

From [Ref. 4], for a steady coordinated turn;

$$\text{TURNRATE (deg/sec)} = \frac{1091 \tan \phi (d)}{V}$$

(ϕ) = bank angle (degrees)

V = velocity (knots) T&S

Convert the turn rate to radians/sec:

$$\text{TURNRATE (r/s)} = \frac{1091 \tan \phi (r)}{V} \cdot \frac{2\pi}{360}$$

Convert V(knots) to V(meters/sec):

$$\text{TURNRATE (r/s)} = \frac{1091 \tan \phi (r)}{(V \cdot 1.9438)} \cdot \frac{2\pi}{360}$$

Solve for angle of bank:

$$\phi (r) = \text{atan} \left(\frac{\text{TURNRATE (r/s)} \cdot V (m/s)}{9.7958} \right)$$

$$\text{PHNEW} = \text{ATAN}(\text{TURNRAT} \times \text{VELOT} / 9.7958)$$

From [Ref. 5], the pressure ratio as a function of temperature and altitude, for the model atmosphere is:

$$\int_{p_0}^p dp = -\frac{G}{R} \int_0^H \frac{dH}{T_0 + (dT/dH)H}$$

$$\frac{p}{p_0} = \left[1 + \left(\frac{dT}{dH} \right) \left(\frac{H}{T_0} \right) \right]^{\left(\frac{G/R}{-dT/dH} \right)}$$

where

p (naught) = standard sea-level atmospheric pressure

dT/dH = temperature lapse rate in the troposphere

H = geopotential altitude (assumed equal to geometric or tapeline altitude for low altitudes)

T (naught) = standard sea-level atmospheric temperature

G = acceleration due to gravity (assumed to be constant)

R = universal gas constant

The temperature profile for the same model atmosphere is:

$$T = T_0 + (dT/dH)H$$

Applying the perfect gas law to get density profile:

$$\frac{\rho}{\rho_0} = \frac{\left[1 + \left(\frac{dT}{dH} \right) \left(\frac{H}{T_0} \right) \right]^{\left(\frac{G/R}{-dT/dH} \right)}}{\left[1 + \left(\frac{dT}{dH} \right) \left(\frac{H}{T_0} \right) \right]} \\ = \left[1 + \left(\frac{dT}{dH} \right) \left(\frac{H}{T_0} \right) \right]^{\left(\frac{G/R}{-dT/dH} - 1 \right)}$$

The temperature lapse rate in SI units is:

$$\frac{dT}{dH} = -6.5 \times 10^{-3} \text{ } ^\circ\text{K/m}$$

Gravitational acceleration in SI units is:

$$G = 9.807 \text{ m/s}^2$$

The universal gas constant is:

$$287 \frac{\text{N}\cdot\text{m}}{\text{kg}\cdot^\circ\text{K}}$$

Thus;

$$\frac{G/R}{-dT/dH} - 1 = 4.257$$

and sea-level standard air density is:

$$\rho_0 = 1.225 \frac{\text{N}\cdot\text{s}^2}{\text{m}^4}$$

APPENDIX C
FLIGHT DYNAMICS AND COORDINATE TRANSFORMATIONS




Figure C.1 The Map Coordinate System.




Figure C.2 The Aerodynamicist's Coordinate System.

The following development is taken from [Ref. 6]. For the equation (linear momentum = applied forces) for an aircraft with a constant mass (fuel burn not accounted for);

$$m \frac{d\vec{V}_e}{dt} = mg + F_a + F_t$$

m = mass of the airplane

$(\frac{d\vec{V}_e}{dt})$ = the acceleration of the aircraft in the earth-fixed coordinate system

mg = force applied due to gravity

F_a = force applied by aerodynamic loading

F_t = force applied by thrust

This equation is transformed from the earth-fixed coordinate system to a coordinate system attached to the aircraft;

$$m \frac{d\vec{V}_a}{dt} = m \left(\frac{d\vec{V}_a}{dt} + \omega \times \vec{V}_a \right)$$

$(\frac{d\vec{V}_a}{dt})$ = acceleration of the aircraft in the aircraft-fixed coordinate system

(ω) = rotational velocity of the aircraft-fixed coordinate system with respect to the earth-fixed coordinate system

If the above equation is expanded into its orthogonal components:

$$m\dot{u}_e = m (\dot{u}_a - v_a R + w_a Q) = mg_x + F_{a_x} + F_{t_x}$$

$$m\dot{v}_e = m (\dot{v}_a + u_a R - w_a P) = mg_y + F_{a_y} + F_{t_y}$$

$$m\dot{w}_e = m (\dot{w}_a - u_a Q + v_a P) = mg_z + F_{a_z} + F_{t_z}$$

The above is termed the aircraft equations of motion. In the aircraft-fixed coordinate system, the components are shown in figure C.3. The next three illustrations show the transformation of earth-fixed linear velocities and accelerations to aircraft-fixed linear velocities and accelerations: Finite rotational displacements do not act as vectors, hence the requirement for the order of the above rotations. This is demonstrated in figure C.7. Transformation of earth-fixed rotational velocities into aircraft-fixed velocities involves the following mapping.

$$\vec{\omega} = \dot{\psi} \vec{e}_1 + \dot{\theta} \vec{e}_2 + \dot{\phi} \vec{e}_3 \Rightarrow (\text{transform}) \Rightarrow \vec{P} + \vec{Q} + \vec{R}$$

In terms of unit vectors, (ω) earth-fixed is presented;

$$\vec{\omega}_e = \dot{\psi} \hat{k}_2 + \dot{\theta} \hat{j}_3 + \dot{\phi} \hat{i}_a$$

looking at figure C.8, it is seen that;

$$\hat{k}_2 = -\sin \theta \hat{i}_3 + \cos \theta \hat{k}_3 = -\sin \theta \hat{i}_a + \cos \theta \hat{k}_3$$





Figure C.3 Components of the Equations of Motion.



$$u_2 = \cos \psi u_e + \sin \psi v_e$$

$$v_2 = -\sin \psi u_e + \cos \psi v_e$$


$$w_2 = w_e$$

$$\dot{u}_2 = \cos \psi \dot{u}_e + \sin \psi \dot{v}_e$$

$$\dot{v}_2 = -\sin \psi \dot{u}_e + \cos \psi \dot{v}_e$$

$$\dot{w}_2 = \dot{w}_e$$

Figure C.4 First Rotation.



$$\mu_3 = \cos \theta \mu_2 - \sin \theta w_2$$

$$v_3 = v_2$$


$$w_3 = \sin \theta \mu_2 + \cos \theta w_2$$

$$\dot{\mu}_3 = \cos \theta \dot{\mu}_2 - \sin \theta \dot{w}_2$$

$$\dot{v}_3 = \dot{v}_2$$

$$\dot{w}_3 = \sin \theta \dot{\mu}_2 + \cos \theta \dot{w}_2$$

Figure C.5 Second Rotation.



$$\mu_a = \mu_3$$

$$v_a = \cos \phi \, v_3 + \sin \phi \, w_3$$

$$w_a = -\sin \phi \, v_3 + \cos \phi \, w_3$$

$$\dot{\mu}_a = \dot{\mu}_3$$

$$\dot{v}_a = \cos \phi \, \dot{v}_3 + \sin \phi \, \dot{w}_3$$

$$\dot{w}_a = -\sin \phi \, \dot{v}_3 + \cos \phi \, \dot{w}_3$$

Figure C.6 Third Rotation.




Figure C.7 Finite Rotations Do Not Act As Vectors.


furthermore; looking at C.8,

$$\hat{k}_3 = \sin \phi \hat{j}_a + \cos \phi \hat{k}_a$$


and finally, looking at the same figure,

$$\hat{j}_3 = \cos \phi \hat{j}_a - \sin \phi \hat{k}_a$$

$$\dot{\vec{\psi}} = \dot{\psi} \hat{k}_e = \dot{\psi} \hat{k}_2$$



$$\dot{\vec{\theta}} = \dot{\theta} \hat{j}_2 = \dot{\theta} \hat{j}_3$$



$$\dot{\vec{\phi}} = \dot{\phi} \hat{l}_3 = \dot{\phi} \hat{l}_a$$




Figure C.8 Transformation of $(\dot{\vec{\psi}})$.

Substituting into (ω) in terms of the aircraft direction vectors;

$$\vec{\omega} = -\sin\theta \hat{i}_a + \cos\theta (\sin\phi \hat{j}_a + \cos\phi \hat{k}_a) \dot{\psi} + (\cos\phi \hat{j}_a - \sin\phi \hat{k}_a) \dot{\theta} + \dot{\phi} \hat{i}_a$$

and this must equal

$$\vec{\omega} = P \hat{i}_a + Q \hat{j}_a + R \hat{k}_a$$

Therefore, solving for components,

$$P = \dot{\phi} - \sin(\theta) \dot{\psi}$$

$$Q = \cos(\phi) \dot{\theta} + \cos(\theta) \sin(\phi) \dot{\psi}$$

$$R = -\sin(\phi) \dot{\theta} + \cos(\theta) \cos(\phi) \dot{\psi}$$

APPENDIX D
CONSOLIDATED COMMON LISTING

```
COMMON/ABC1/WX(1000),WY(1000),WZ(1000),
*      WU(1000),WV(1000),WW(1000),
*      WH(1000),WP(1000),WR(1000),
*      WG(1000),I(1000),ICT
```

```
COMMON/ABC2/XNEW,DELX,XTEMP,XOLD,
*      YNEW,DELY,YTEMP,YOLD,
*      ZNEW,DELZ,ZTEMP,ZOLD
```

```
COMMON/ABC3/VEION,VELOT,VELOO,N,
*      UNEW,UTEMP,UOLD,
*      VNEW,VTEMP,VOLD,
*      WNEW,WTEMP,WOLD
```

```
COMMON/ABC4/AG1,AH1,AI1,AJ1,AJ2
```

```
COMMON/ABD1/AA1,AB1,AC1
```

```
COMMON/ABD2/VSTALL,VMAX,VMAX1,VMAX2,DELTEE,DELTV,DELTZ
```

```
COMMON/ABD3/PSIDOT,THEDOT,PHIDOT
```

```
COMMON/ABD4/PSINEW,THENEW,PHINEW,
*      PSIOLD,THEOLD,PHIOLD
```

```
COMMON/ABF1/U1,V1,W1,U2,V2,W2,U3,V3,W3
```

```
COMMON/ABF2/UD1,VD1,WD1,UD2,VD2,WD2,UD3,VD3,WD3
```

```
COMMON/ABF3/UAC,VAC,WAC,UDOTAC,VDOTAC,WDOTAC,P,Q,R
```

```
COMMON/LOC/X1,Y1,Z1,V1,LTR,LTR2
```

```
COMMON/MN/ IBAUD
```

```
COMMON/MN1/MINX,MAXX,MINY,MAXY,IINX1,MAXX1,MINX2,MAXX2
```

```
COMMON/NAM/INAM1(2),INAM2(2),IUNR,IANR,IDEST
```

```
COMMON/OPT/IGUN,IPNCH,IEXT,ISAM,IMP,KER,IMPZ
```

```
COMMON/PAR2/XGUN(7),YGUN(7),ZGUN(7),XSAM,YSAM,ZSAM,GR(7)
```

* COMMON/PAR4/APEMAX,HTMIN,HTMAX,POPMIN,BAALT,BREIN,LEMAX,
BREMIN,BRRMAX,RADTODEG,HTRTOFT

COMMON/TAE/TARGX,TARGY

APPENDIX E

EXECS USED TO DRIVE FORTRAN PROGRAMS

```

*****
C IBMPIP1 EXEC A1
C THE FOLLOWING EXEC DRIVES IBMPIP1 -- D.A.M. 17MAR84 --
*****
STRACE ERR
EXEC GRAF77
FILEDEF 09 DISK PICTUR DATA B1 (RECFM F LRECL 80
FILEDEF 10 DISK GUN LCC A1 (RECFM F LRECL 80
FILEDEF 11 DISK PTS LCC A1 (RECFM F LRECL 80
FILEDEF 16 DISK PAR SAV A1 (RECFM F LRECL 80
FILEDEF 18 DISK POO1 DATA A1 (RECFM F LRECL 80
FILEDEF 17 DISK MICE DATA A1 (RECFM F LRECL 80
FILEDEF 19 DISK TEMP DATA A1 (RECFM F LRECL 80
LOAD IBMPIP1 (START

```

```

*****
C IBMPIP2 EXEC A1
C THE FOLLOWING EXEC WAS USED TO DRIVE IBMPIP2 -- D.A.M. 17MAR84 --
*****
STRACE ERR
EXEC GRAF77
FILEDEF 09 DISK PICTUR DATA A1 (RECFM F LRECL 80
FILEDEF 10 DISK GUN LCC A1 (RECFM F LRECL 80
FILEDEF 11 DISK PTS LCC A1 (RECFM F LRECL 130 BLOCK 130
FILEDEF 16 DISK PAR SAV A1 (RECFM F LRECL 80
FILEDEF 18 DISK POO1 DATA A1 (RECFM F LRECL 80
FILEDEF 17 DISK MICE DATA A1 (RECFM F LRECL 80
LOAD IBMPIP2 (START

```

```

*****
C GRAF77 EXEC A1
C THE FOLLOWING EXEC LINKS THE USER TO THE GRAPHICS IMPLEMENTATION
C -- D.A.M. 17MAR84 --
*****
STRACE ERR
CP LINK GRAF77 191 199 RR
ACC 199 G
GLOBAL TITLIB MOD2EEN PORTMOD2 GRAFLIB CHSLIB NONINSL

```

APPENDIX F

CLEANED UP JOHNS VERSION IBMPIP

```

C *****
C MAIN PROGRAM 04/OCT/83 VERSION
C *****
C CONNECTS THE EXECUTION OF THE ENTIRE PROGRAM.
C THE 04/OCT VERSION IS ESSENTIALLY ERIC JOHNS'
C VERSION WITH SOME USER FRIENDLINESS FEATURES
C ADDED. THE AIRCRAFT FLIGHTPATH GENERATOR IS
C UNCHANGED FROM THE JOHNS' VERSION AND IS KNOWN
C TO WORK AS THIS IS THE VERSION IN USE BY PROP.
C BALL'S SURVIVABILITY CLASS. -- D.M.M. 16MAR84 --
C *****
COMMON /MN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
COMMON /LCC/ X1,Z1,Z1,V1,ITE,ITE2
COMMON /MN/ IEADU
COMMON /PAR/ X(200),Y(200),Z(200),HDG(200),CA(200),RA(200),VEL(200)
1)
COMMON /PAR1/ YDOT(200),YDOT(200),ZDOT(200),ANUM,ABR
COMMON /PAR2/ T(200),XGUN(7),YGUN(7),ZGUN(7),XSAM,YSAM,ZSAM,GR(7)
COMMON /CPT/ IGUN,IEACH,IEAT,ISAM,IMF,KEB,IMPZ
COMMON /SAM/ INAM1(2),INAM2(2),IUNR,IANS,IDEST
HBR=0
HNUM=0
T(1)=0
CALL BEGIN
CALL SCENE (0,0)
REWINO 10
C -----
C DRAW THE FIXED GUN SITE & ENGAGEMENT CIRCLE
C -----
CALL GUNLOC (XGUN(7),YGUN(7),GR(7))
IF (IGUN.NE.1) GO TO 90
C IGUN=1==> READ USER DEFINEABLE GUN SITES FROM TERMINAL
C -----
CALL ERRBK (16)
DC 50 I=1,5
IERB=J
IF (IMPZ.NE.1) GO TO 20
CALL XYPT
ZGUN(I)=20
GO TO 30
20 CALL XYPT
CALL ZVPT
ZGUN(I)=21
30 XGUN(I)=X1
YGUN(I)=Y1
C -----
C IF GUN TYPE 3, CHK FOR 3 KM SEPARATION FM BRIDGE
C -----
IF (I.GE.5) CALL GUNCHK (X1,Y1,IERB)
IF (IERB.EQ.0) GO TO 40
CALL ERRBK (IERB)
GO TO 10
C -----
C DRAW GUN SITE AND ENGAGEMENT CIRCLE
C -----
CALL GUNLOC (XGUN(I),YGUN(I),GR(I))
50 WRITE (10,350) XGUN(I),YGUN(I),ZGUN(I)
C READ USER DEFINEABLE SAM SITE FM TERMINAL
C -----
60 CALL ERRBK (14)
IF (IMPZ.NE.1) GO TO 70
CALL XYPT
ZSAM=20
GO TO 80
70 CALL XYPT
CALL ZVPT
ZSAM=21
80 XSAM=X1
YSAM=Y1
C -----
C VERIFY SAM SITE AT LEAST 6KM FM WESTERN BOUNDARY
C -----
CALL SAMCHK (X1,IERB)
IF (IERB.NE.0) GO TO 60
C -----

```



```

C DRAW SAM SITE
C-----
      CALL GUNICC (XSAM,YSAM,150.)
      WRITE (10,350) XSAM,YSAM,ZSAM
      GO TO 13C
C-----
C IGUN=2==> READ GUN SITES FROM DATA FILE
C-----
90    IF (IGUN.NE.2) GO TO 110
      DC 100 I=1,5
100   READ (10,350) XGUN(I),YGUN(I),ZGUN(I)
      READ (10,350) XSAM,YSAM,ZSAM
C-----
C DRAW GUN SITES AND ENGAGEMENT CIRCLES
C-----
110   DC 120 I=1,6
120   CALL GUNLOC (XGUN(I),YGUN(I),GE(I))
      CALL GUNLOC (XSAM,YSAM,150.)
130   CONTINUE
C-----
C THIS SECTION ACCEPTS THE FLIGHT MILESTONES
C-----
      PTFAC=3.28084
      DGFAC=57.29578
      CALL ERRBK (15)
      REWIND 11
140   MNUM=MNUM+1
C-----
C READ MILESTONES FROM THE DISK
C-----
150   IF (IMP.NE.3) GO TO 160
      READ (11,360) X(MNUM),Y(MNUM),Z(MNUM),VEL(MNUM),LTR
      IF (X(MNUM).LE.0) GO TO 150
      IF (LTR.EQ.1) IMP=1
      LTR2=LTR
      GO TO 18C
C-----
C READ MILESTONES FROM THE TERMINAL
C-----
160   CALL XYPT
      X(MNUM)=X1
      Y(MNUM)=Y1
170   CALL ZVPT
      Z(MNUM)=Z1
      VEL(MNUM)=V1
      IF (IMP.EQ.0) GO TO 140
C-----
C COMPUTE FLIGHT PARAMETERS AND CHECK FOR ERRORS OR USER COMMANDS
C-----
180   IF (MNUM.EQ.1.AND.(LTR.EQ.83.OR.LTR2.EQ.83)) STOP
      IF (MNUM.EQ.1) GO TO 140
      IERR=0
      CALL VALSET (IERR)
      IF ((LTR.EQ.82).OR.(LTR2.EQ.82).AND.(IMP.NE.0)) GO TO 200
      IF ((LTR.EQ.86).OR.(LTR2.EQ.86)) MBR=MNUM
      IF ((LTR.EQ.83).OR.(LTR2.EQ.83)) GO TO 230
      IF (IERR.EQ.0) CALL ERRCHK (IERR)
      IF ((IERR*MBR.EQ.0).AND.(IERR.NE.12)) GO TO 190
      CALL ERRBK (IERR)
      WRITE (6,390)
      WRITE (6,400)
      READ (5,*) ICOR
      CALL PUTCMS ('CLRSCHN ')
      IF (ICOR.NE.1) GO TO 190
      WRITE (6,410)
      READ (5,*) IANS
      CALL PUTCMS ('CLRSCHN ')
      IF (IANS.NE.1) GO TO 160
      GO TO 17C
C-----
C MILESTONE ACCEPTED, RESTART THE SEQUENCE
C-----
190   CALL PTHFLT
      IF (LTR.EQ. 65 .OR. LTR2.EQ. 65) CALL AIMPT (MNUM)
      GO TO 14C
C-----

```

```

C THIS SECTION RESETS THE DATA
200 CALL SCENE (1,ICT)
    REWIND 19
    IF (MBR.GT. ICT) MBR=0
C COMPLETE RESTART
    IF (ICT.GT. 1) GC TO 210
    MNUM=0
    GC TO 110
C DRAW RETAINED MILESTONES
210 IF ((ICT.GE. MNUM).AND.(MNUM.GE. 3)) ICT=MNUM-1
    DO 220 MNUM=2,ICT
220 CALL PTHFLT
    MNUM=MNUM-1
    GC TO 110
C THIS SECTION TERMINATES THE PROGRAM
230 BLANK=0.
    CALL PTHFLT
    LAST=IMP
    CALL ELFIN (LAST)
C COMPUTE FLIGHT PARAMETERS FOR FINAL LEG
    DX=X(MNUM)-X(MNUM-1)
    DY=Y(MNUM)-Y(MNUM-1)
    DZ=Z(MNUM)-Z(MNUM-1)
    RA(MNUM)=0.
    CA(MNUM)=ATAN2(DZ,SQRT(DX**2 + DY**2))
    IF ((DX.EQ. 0.).OR.(DY.EQ. 0.)) GO TO 240
    HDG(MNUM)=ATAN2(DY,DX)
    GC TO 250
240 IF ((DX.EQ. 0.) .AND. (DY.GT. 0.)) HDG(MNUM)=1.57079
    IF ((DX.EQ. 0.) .AND. (DY.LT. 0.)) HDG(MNUM)=-1.57079
    IF ((DY.EQ. 0.) .AND. (DX.GT. 0.)) HDG(MNUM)=3.14159
    IF ((DY.EQ. 0.) .AND. (DX.LT. 0.)) HDG(MNUM)=0.
250 XCOT(MNUM)=VEL(MNUM)*COS(HDG(MNUM))*COS(CA(MNUM))
    YDOT(MNUM)=VEL(MNUM)*SIN(HDG(MNUM))*COS(CA(MNUM))
    ZDOT(MNUM)=VEL(MNUM)*SIN(CA(MNUM))
C CREATES NEW " PTS LOC " IF NEW WEAPON OR MILESTONE COORDINATES
    HAVE BEEN INPUT
    IF ((IMP.EQ. 0.) .AND. (IGUN.NE. 1)) GO TO 280
    REWIND 11
    IGUN=1
    WRITE (11,360) BLANK,BLANK,BLANK,BLANK,BLANK
    DO 260 I=1,MNUM
    LTR=0
    IF (I.EQ. MBR) LTR=66
    IF (I.EQ. MNUM) LTR=LAST
260 WRITE (11,360) X(I),Y(I),Z(I),VEL(I),LTR
    WRITE (11,370)
    WRITE (11,380) VEL(1),MBR,BLANK,BLANK,IGUN,IGUN,BLANK,BLANK,IGUN,B
    BLANK
    IF (IGUN.EQ. 0) GO TO 280
    DO 270 I=1,6
270 WRITE (11,360) XGUN(I),YGUN(I),ZGUN(I)
    WRITE (11,360) XSAM,YSAM,ZSAM
C CONVERT ANGLES FROM RADIANS TO DEGREES
280 DO 290 I=1,MNUM
    CA(I)=CA(I)*DGEFAC
    RA(I)=RA(I)*DGEFAC
290 HDG(I)=HDG(I)*DGEFAC
C WRITE THE JCI CARES
    IF (IPNCH.LT.1) STOP
    IF (IPNCH.EQ.2) GC TO 300

```

```

WRITE (6,420)
WRITE (6,430)
WRITE (6,440)
WRITE (6,450)
READ (5,430) INAM1(1),INAM1(2)
CALL PRTCMS ('CLASCSN ')
300 IF (IPNCH.EQ.1) GO TO 310
WRITE (6,460)
WRITE (6,430)
WRITE (6,440)
WRITE (6,450)
READ (5,430) INAM2(1),INAM2(2)
CALL PRTCMS ('CLASCSN ')
310 WRITE (6,470)
READ (5,*) IUNG
CALL PRTCMS ('CLASCFN ')
WRITE (6,480)
READ (5,*) IANH
CALL PRTCMS ('CLASCFN ')
C-----
C CHOOSE DESTINATION FOR OUTPUT: PRINTER OR READER FILE
C-----
320 WRITE (6,490)
WRITE (6,500)
READ (5,*) IDEST
IF ((IDEST.NE.1).AND.(IDEST.NE.2)) GO TO 320
CALL PRTCMS ('CLASCFN ')
C-----
C PRESET LOADS MICE/POO1 DATA FILES ONTO USERS A1 DISK
C-----
CALL PRESET
C-----
C DUMMY INPUT ROUTINE TO LET USER KNOW WHERE S/HE IS IN THE PGM
C-----
WRITE (6,510)
READ (5,*) IGC
CALL PRTCMS ('CLASCFN ')
C-----
C FORCE CALL TO CMS TO SUBMIT DATA FILES TO BATCH PROCESSING PGM
C-----
IF (IPNCH.EQ.2) GO TO 330
CALL PRTCMS ('EXEC ', 'SUBMIT ', 'POO1 ', 'DATA ')
IF (IPNCH.EQ.1) GO TO 340
330 CALL PRTCMS ('EXEC ', 'SUBMIT ', 'MICE ', 'DATA ')
340 CONTINUE
C-----
C DUMMY INPUT ROUTINE TO LET USER KNOW PGM TERMINATION HAS BEEN REACHED
C-----
WRITE (6,520)
READ (5,*) IGO
STOP
350 FORMAT (3F10.2)
360 FCENAT (4F10.0,I3)
370 FORMAT (6H99999)
380 FCENAT (F10.0,I2,2I1,F10.0)
390 FORMAT (3H )
400 FCENAT (54H DO YOU WANT TO FIX THE ERROR:0=NO,USE THE POINT;1=YES)
410 FORMAT (40H DO YOU WANT TO RETAIN X-Y PT:1=YES;2=NO)
420 FCENAT (40H TO SUBMIT POO1 TO BATCH YOU MUST CREATE)
430 FORMAT (31H A JCB CONTROL LANGUAGE "CABC".)
440 FORMAT (51H ENTER A NAME -- IT MAY CONTAIN UP TO 8 CHARACTERS;)
450 FCENAT (25H **DO NOT INSERT BLANKS**)
460 FCENAT (44H TO SUBMIT **MICE** TO BATCH YOU MUST CREATE)
470 FCENAT (46H ENTER YOUR USER ID NUMBER -- WITHOUT THE "P".)
480 FCENAT (48H ENTER YOUR ACC# NUMBER -- PROVIDED BY THE PROF.)
490 FORMAT (41H CHOOSE THE DESTINATION FOR YOUR OUTPUT: )
500 FCENAT (30H 1=PRINTER; 2=YOUR READER FILE)
510 FCENAT (46H ENTER ANY **NUMBER** TO SUBMIT YOUR POO1/MICE,14H DATA
1 FILE(S).)
520 FCENAT (40H ENTER ANY **NUMBER** TO TERMINATE T2PIP)
530 FCENAT (2A4)
END

```

```

C*****
C SUBROUTINE BEGIN
C      THIS SUBROUTINE INITIALIZES THE GRAPHICS AND REQUESTS
C      THE USER OPTIONS.
C*****
      SUBROUTINE BEGIN
      COMMON /MN/ IEAUD
      COMMON /CET/ IGUN, IEMCH, IEXT, ISAM, IMP, KER, KMDI
C-----
C READ USER OPTIONS
C-----
10  CALL FRTCHS ('CLRSCHN ')
    WRITE (6,60)
    READ (5,*) IGUN
    IF ((IGUN.NE.0).AND.(IGUN.NE.1).AND.(IGUN.NE.2)) GO TO 10
    CALL FRTCHS ('CLRSCHN ')
    IF (IGUN.NE.1) GO TO 20
    WRITE (6,70)
    WRITE (6,80)
    READ (5,*) IMPZ
    CALL FRTCHS ('CLRSCHN ')
20  WRITE (6,90)
    READ (5,*) IMP
    IF ((IMP.NE.0).AND.(IMP.NE.1)) GO TO 20
    CALL FRTCHS ('CLRSCHN ')
30  WRITE (6,100)
    READ (5,*) KER
    IF ((KER.NE.0).AND.(KER.NE.1)) GO TO 30
    CALL FRTCHS ('CLRSCHN ')
40  WRITE (6,110)
    WRITE (6,120)
    READ (5,*) IEAUD
    IF ((IEAUD.NE.0).AND.(IEAUD.NE.1)) GO TO 40
    CALL FRTCHS ('CLRSCHN ')
50  WRITE (6,130)
    READ (5,*) KON
    IF ((KON.NE.1).AND.(KON.NE.2)) GO TO 50
    CALL FRTCHS ('CLRSCHN ')
    IF (KON.NE.1) CALL CONCEG
C-----
C INITIALIZE THE GRAPHICS AND CLEAR SCREEN
C-----
    CALL DSINTT
    CALL GSERSE
    RETURN
60  FORMAT (56H GUNS:0=DISK FILE;1=TERMINAL;2=PRESET(GOUGE SET OF GUNS
1)
70  FORMAT (55H ** CHOICE 1 NEGATES HAVING TO GO OVER TO THE ALTIMETER
1)
80  FORMAT (55H GUN/SAM SITE ALTITUDE:1=FIXED TO 20M;2=USER DEFINEABLE
1)
90  FORMAT (5CH AIRCRAFT MILESTONE INPUT: 0=DISK FILE; 1=TERMINAL)
100  FORMAT (50H ERROR CHECKING: 0=NO CHECKING; 1=CHECK FOR ERRORS)
110  FORMAT (54H ** SELECT 1200 BAUD FOR THE 1EM3277/TEK618 TERMINALS.)
120  FORMAT (35H BAUD RATE: 0=300 BAUD; 1=1200 BAUD)
130  FORMAT (50H FLIGHT 5 GAME PARAMETERS: 1=DEFAULT; 2=USER INPUT)
      END

```

```

C*****
C SUBROUTINE CONCHG
C      THIS SUBROUTINE ALLOWS OPERATOR CHANGES TO THE
C      SIMULATION PARAMETERS.
C*****
C      SUBROUTINE CONCHG
C      COMMON /PAR3/ TMD,ACLIFT,CLMAX,WL,TMAX,CDO,CDK,VMAX1,VMAX2
C      COMMON /PAR4/ APMAX,HTMIN,HTMAX,SPDMIN,GMAX,ECPMIN
C      COMMON /PAR/ TARGX,TARGY
C-----
C WRITE INSTRUCTIONS
C-----
10  WRITE (6,190)
    WRITE (6,200)
    WRITE (6,210)
    WRITE (6,220)
    WRITE (6,230)
    WRITE (6,240)
    WRITE (6,250)
    WRITE (6,260)
    WRITE (6,270)
    READ (5,*) K
    IF ((K.LT.0).OR.(K.GT.17)).GO TO 10
    GC TO (100,20,30,40,50,60,70,80,90,100,110,120,130,140,150,160,170)
20  1) K
    WRITE (6,290)
    READ (5,*) CLMAX
    GC TO 10
30  WRITE (6,290)
    READ (5,*) AL
    GC TO 10
40  WRITE (6,300)
    READ (5,*) SPDMIN
    GC TO 10
50  WRITE (6,310)
    READ (5,*) GMAX
    GC TO 10
60  WRITE (6,320)
    READ (5,*) HTMIN
    GC TO 10
70  WRITE (6,330)
    READ (5,*) HTMAX
    GC TO 10
80  WRITE (6,340)
    READ (5,*) ECPMIN
    GC TO 10
90  WRITE (6,350)
    READ (5,*) APMAX
    GC TO 10
100 WRITE (6,360)
    READ (5,*) TMAX
    GC TO 10
110 WRITE (6,370)
    READ (5,*) CDO
    GC TO 10
120 WRITE (6,380)
    READ (5,*) CDK
    GC TO 10
130 WRITE (6,390)
    READ (5,*) VMAX1
    GC TO 10
140 WRITE (6,400)
    READ (5,*) VMAX2
    GC TO 10
150 WRITE (6,410)
    READ (5,*) TARGX,TARGY
    GC TO 10
C-----
C READ NEW PARAMETER VALUES FROM THE DISK
C-----
160 REWIND 16
    READ (16,450) CLMAX,WL,SPDMIN,GMAX,HTMIN,HTMAX
    READ (16,450) ECPMIN,APMAX,TMAX,CDO,CDK,VMAX1
    READ (16,450) VMAX2,TARGX,TARGY
    GO TO 10
C-----

```

C WRITE PARAMETER VALUES TO THE TERMINAL

```

170  WRITE (6,420)
      WRITE (6,430) CLMAX,WL,SPDMIN,GMAX,HTMIN,HTMAX
      WRITE (6,440) FOFMIN,APPMAX,TEAX,CDO,CDK,VMAX1
      WRITE (6,450) VMAX2,TARGX,TARGY
      GC TO 180

```

C SAVE PARAMETER VALUES ON DISK AND RETURN TO CALLING ROUTINE

```

180  REWIND 16
      WRITE (16,450) CLMAX,WL,SPDMIN,GMAX,HTMIN,HTMAX
      WRITE (16,460) FOFMIN,APPMAX,TEAX,CDO,CDK,VMAX1
      WRITE (16,470) VMAX2,TARGX,TARGY
      RETURN
190  FORMAT (25H
200  FCORMAT (50H 1=SELECT PARAMETER TO BE CHANGED: 1=NO MORE CHANGES)
210  FCORMAT (48H 2=MAX LIFT COEFF; 3=WING LOADING; 4=STALL SPEED)
220  FCORMAT (47H 5=MAX G FORCE; 6=MIN ALT; 7=MAX ALT (<2200 MTS))
230  FCORMAT (42H 8=DISTANCE TO TARGET BEFORE POPUP ALLOWED)
240  FCORMAT (63H 9=MAX APPROACH ALT; 10=MAX T/W RATIO; 11=DRAG COEF. W/
10  LIFT)
250  FCORMAT (44H 12=LIFT DRAG CONSTANT; 13=MAX SPD WITH BOMB)
260  FCORMAT (44H 14=MAX SPD W/O BOMB; 15=TARGET COORDINATES)
270  FCORMAT (43H 16=READ PARAMETER FILE; 17=LIST PARAMETERS)
280  FCORMAT (27H ENTER MAX LIFT COEFFICIENT)
290  FCORMAT (19H ENTER WING LOADING)
300  FCORMAT (18H ENTER STALL SPEED)
310  FCORMAT (26H ENTER MAX G FORCE ALLOWED)
320  FCORMAT (23H ENTER MINIMUM ALTITUDE)
330  FCORMAT (47H ENTER MAXIMUM ALTITUDE (LESS THAN 2000 METERS))
340  FCORMAT (55H ENTER MINIMUM DISTANCE TO TARGET BEFORE POPUP ALLOWED)
1)
350  FCORMAT (32H ENTER MAXIMUM APPROACH ALTITUDE)
360  FCORMAT (35H ENTER MAX THRUST TO WEIGHT ALLOWED)
370  FCORMAT (37H ENTER DRAG COEFFICIENT FOR ZERO LIFT)
380  FCORMAT (25H ENTER LIFT DRAG CONSTANT)
390  FCORMAT (32H ENTER MAX SPEED CARRYING A BOMB)
400  FCORMAT (39H ENTER MAX SPEED AFTER BOMB IS RELEASED)
410  FCORMAT (33H ENTER TARGET X AND Y COORDINATES)
420  FCORMAT (55H MAX CL WING LD STALL SPD MAX G MIN.HT. MAX.HT.
1)
430  FCORMAT (75H POP-UP DIST APPR.HT. MAX THRUST CDO DRAG CONSTANT
1 MAX SEL WITH BOMB)
440  FCORMAT (55H MAX SPD W/O BOMB TARGET X COORD. TARGET Y COORD.
1)
450  FCORMAT (6F12.4)
      ENL

```

```

C *****
C SUBROUTINE SCENE
C      THIS ROUTINE DRAWS THE ATTACK MAP AND ASSOCIATED
C      DISPLAYS. DURING RESET IT CONTAINS THE LAST FILE-
C      STONE THE USER WISHES TO RETAIN.
C *****
C      SUBROUTINE SCENE (IRC,ICT)
C      COMMON /MN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
C      COMMON /ERR/ MKEEX(3),MKEY(19)
C      COMMON /MN/ IEACC
C      COMMON /PAR/ X(200),Y(200),Z(200),HDG(200),CA(200),RA(200),VEL(200)
C      1) COMMON /TAR/ TARGX,TARGY
C      REAL*4 GX,GY
C      LOGICAL *1CHARS(20)
C      ICT=0
C -----
C ERASE THE TEK618 SCREEN
C -----
C      CALL GSERSZ
C      CALL DSTERN
C -----
C READ USER OPTIONS: EORDER AND GUN/MISS POSITS OR FILE IN MAP ALSO.
C -----
C      WRITE (6,100)
C      READ (5,*) MAP
C      IF (IRC.EQ. 0) GO TO 10
C      WRITE (6,90)
C      READ (5,*) ICT
C      CALL PRICMS ('CL3SCRN ')
C -----
C DRAW THE C,Y MAP
C THE ROUTINE READS X,Y PATHS FROM FILE 09. A -2.0,0 INDICATES
C END OF FILE, -0.5,0 INDICATES A MOVE, ALL OTHER VALUES ARE PO-
C SITIVE AND RESULT IN A DRAW TO THAT POINT.
C -----
C RE-INITIALIZE THE TEK618 SCREEN
C -----
10  CALL DSINIT
    CALL MIN (MINX,MAXX,18000.,12000.,1)
    IF (MAP.EQ. 0) GO TO 40
    BEWIND 9
    READ (9,80) GX,GY
20  READ (9,80) GX,GY
    CALL GBMOVE (GX,GY)
30  READ (9,80) GX,GY
    IF (GX.LI.-1) GO TO 40
    IF (GX.LI. 0) GO TO 20
    CALL GBDRAW (GX,GY)
    GO TO 30
C -----
C MARK THE TARGET: GUNLCC PUTS A * AT GUN/MISS POSIT AND CIRCUMSCRIBES
C -----
40  CALL GUNLCC (TARGX,TARGY,150.)
    CALL GUNLCC (TARGX,TARGY,300.)
C -----
C DRAW TIC MARKS EVERY 2000 MTRS
C -----
    DO 50 I=1,8
      IW=2*I
C -----
C THIS BLOCK DRAWS THE X-AXIS TIC MARKS
C -----
    CALL GBMOVE (I*2000.,1000.)
    CALL GBDRAW (I*2000.,0.)
    CALL GAXITC (1,IW,2,CHARS)
    CALL GBCHAR (I*2000.,0.,2.,0.,2,CHARS)
C -----
C THIS BLOCK DRAWS THE Y-AXIS TIC MARKS
C -----
    IF (I.GE. 6) GO TO 50
    CALL GBMOVE (1000.,I*2000.)
    CALL GBDRAW (0.,I*2000.)
    CALL GAXITC (1,IW,2,CHARS)
    CALL GBCHAR (-60.,I*2000.,2.,0.,2,CHARS)
50  CONTINUE

```

```

I1=MINY
I2=MAXY
MAXY=MINY-15
MINY=MINY-200
CALL WIN (MINX+275,MINX+2200,195.,185.,C)
CALL GBCHAR (10.,110.,2.5,0.,30,'KEY MARKS IN 2000 METER INTVL')
CALL GBCHAR (10.,40.,2.5,0.,25,'ZERO DEGREES ALONG X AXIS')
CALL GSFBCF
MAXY=I2
MINY=I1
C-----
C DRAW THE ALTIMETER
C-----
CALL WIN (MINX1,MAXX1,350.,2200.,1)
DO 60 I=2,30,2
CALL GBMCVE (0.,I*100.)
CALL GBDRAW (350.,I*100.)
CALL GAXITC (1,I,2,CHARS)
60 CALL GBCHAR (0.,I*100.,2.,0.,2,CHARS)
DO 70 I=1,6
CALL GBMCVE (I*50.,100.)
70 CALL GBDRAW (I*50.,0.)
C-----
C MARK RESET POINT VELOCITY AND ALTITUDE AS OPERATOR AID
C-----
IF (ISQ.NE.0 .AND. ICT.GT.1) CALL GBGDOT (9.,VEL(ICT),Z(ICT))
MAXY=MINY-15
MINY=MINY-200
CALL WIN (MINX+2800,MINX+3900,195.,185.,J)
CALL GBCHAR (10.,110.,2.5,0.,25,'ALT MARKS IN 200 METER INTVL')
CALL GBCHAR (10.,60.,2.5,0.,33,'VELO IN 50 M/S INTVL ALONG X AXIS')
1) CALL GSFBCF
MAXY=I2
MINY=I1
RETURN
80 FORMAT (2F10.2)
90 FORMAT (38H AT WHICH POINT DO YOU WANT TO RESTART)
100 FORMAT (38H VILLAGE: 0=NOT DRAWN; 1=VILLAGE DRAWN)
END

```



```

C *****
C SUBROUTINE WIN
C      THIS ROUTINE DEFINES A WINDOW EXTENDING FROM LX TO MX
C      ON THE HORIZONTAL AXIS, AND FROM MINY TO MAXY ON THE
C      VERTICAL AXIS. THE HORIZONTAL RANGE IS RX, THE
C      VERTICAL RANGE IS RY.
C *****
C      SUBROUTINE WIN (LX,MX,RX,RY,JMP)
C      COMMON /NN/ IEAUB
C      COMMON /NN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
C      REAL*4 WIN1(4)
C      INTEGER*4 V1(4)
C      DATA WIN1(1)/C./,WIN1(2)/0./
C -----
C DEFINE THE WINDOW
C -----
      V1(2)=MINY
      V1(4)=MAXY
      WIN1(3)=RX
      WIN1(4)=RY
      V1(1)=LX
      V1(3)=MX
      CALL GASVIE (V1,3)
      CALL GASWIN (WIN1,3)
      IF (JMP .EQ. 0) GC TC 20
C -----
C FLASH THE DEFINED WINDOW
C -----
      ICT=4+50*IEAUB
      DO 10 I=1,ICT
      CALL GEMOVE (C,J-)
      CALL GEDRAW (*WIN1(1),WIN1(4))
      CALL GEDRAW (*WIN1(3),WIN1(4))
      CALL GEDRAW (*WIN1(3),WIN1(2))
      CALL GEDRAW (*WIN1(1),WIN1(2))
10    RETURN
20    END

```

```

C *****
C SUBROUTINE GUNLOC
C      THIS SUBROUTINE DRAWS EFFECTIVE FIRE RADIUS CIRCLES
C      AROUND THE DEFENSIVE AAA BATTERIES. IT DRAWS
C      A RING WITHIN WHICH AIRCRAFT POP-UP MUST TAKE PLACE
C      AND A RING OUTSIDE WHICH THE TYPE 1 AAA BATTERIES
C      MUST BE PLACED.
C *****
C SUBROUTINE GUNLOC (GX,GY,RAD)
C      COMMON /MN/ IBAUD
C      COMMON /MN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
C      REAL*4 X,Y,DX,DY
C      X=GX
C      Y=GY
C -----
C IDENTIFY THE MAP AND PLACE A '+' AT THE LOCATION
C -----
C      CALL WTN (MINX,MAXX,18000.,12000.,0)
C      CALL GEMOVE (X-75.,Y)
C      CALL GBDRAW (X-75.,Y)
C      CALL GEMOVE (X,Y+75.)
C      CALL GBDRAW (X,Y+75.)
C -----
C DETERMINE NUMBER OF STEPS TO BE USED
C -----
C      ISTEP=3
C      IF (RAD.LT. 1600.) ISTEP=6
C -----
C DRAW A CIRCLE AROUND THE SITE
C -----
C      DC 10 I=1,180,ISTEP
C      ANGLE=I*.034907
C      DX=RAD*CCS(ANGLE)+X
C      DY=RAD*SIN(ANGLE)+Y
C      CALL GEMOVE (DX+10.,DY)
10  CALL GBDRAW (DX+10.,DY)
C -----
C DRAW 3KM & 6KM GUNSITE AND POP-UP LIMITATION RINGS
C -----
C      IF ((X.NE.14000.) .AND. (Y.NE.7220.)) RETURN
C      CALL GEGARC (3000.,3000.,X,Y,1.,1.,2.)
C      CALL GEGARC (6000.,6000.,X,Y,1.,1.,2.)
C      RETURN
C      END

```

```

C*****
C SUBROUTINE XYPT      THIS SUBROUTINE OBTAINS THE X AND Y COORDINATES
C                      AND COMMAND FOR EACH DESIGNATED POINT (MILESTONE).
C*****
      SUBROUTINE XYPT
      COMMON /LCC/ X1,Y1,Z1,V1,ITS,ITS2
      COMMON /MN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
      COMMON /MN/ IEAUC
      CALL BELL
      -----
C FLASH MAP AND GET X,Y AND THE FIRST COMMAND
C-----
      CALL WIN (MINX,MAXX,18000.,12000.,1)
      CALL SPOT (X1,Y1,ITS)
      CALL BELL
      RETURN
      END

```

```

C*****
C SUBROUTINE ZVPT      THIS SUBROUTINE OBTAINS THE ALTITUDE AND, DEPENDING
C                      ON THE CIRCUMSTANCES, THE VELOCITY OF THE DESIGNATED
C                      POINT.
C*****
      SUBROUTINE ZVPT
      COMMON /LCC/ X1,Y1,Z1,V1,ITS,ITS2
      COMMON /MN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
      COMMON /MN/ IEAUC
      -----
C FLASH ALTIMETER AND GET VEL,ALT AND THE SECOND COMMAND
C-----
      CALL WIN (MINX1,MAXX1,350.,2200.,1)
      CALL SPOT (V1,Z1,ITS2)
      RETURN
      END

```

```

C*****
C SUBROUTINE SFCT      THIS RETURNS AN X-Y PAIR AND A COMMAND VALUE L1
C                     THE ROUTINE ALSO CREATES A DOT AT POINT X,Y.
C*****
C SUBROUTINE SPOT (X,Y,L1)
C   REAL*4 TX,TY,DCT
C   INTEGER*4 L,1,CUT,KEY
C-----
C READ THE CURSOR AND PICK UP USER COMMAND
C-----
10  CALL GBRXYC (M,L,KEY,TX,TY)
    CALL GAXCTI (1,KEY,1,LEN,CUT)
    DCT=40.
C-----
C MARK THE SPOT
C-----
    CALL G2GECT (DCT,TX,TY)
    X=TX
    Y=TY
C-----
C CONVERT THE COMMAND TO THE PROPER FORMAT
C-----
    L1=0
    IF (OUT.EQ.1) L1=65
    IF (OUT.EQ.2) L1=86
    IF (OUT.EQ.3) L1=82
    IF (OUT.EQ.4) L1=83
    RETURN
END

```

```

C*****
C SUBROUTINE GUNCHK  THIS SUBROUTINE CHECKS GUN LOCATIONS AGAINST
C                     EMPLACEMENT RULES.
C*****
C SUBROUTINE GUNCHK (X,Y,IERR)
C   COMMON /IAB/ IABGY,IABGY
C-----
C COMPUTE DISTANCE TO TARGET
C-----
    DIST=SQRT((X-IABGX)**2 + (Y-IABGY)**2)
    IF (DIST.LT. 3000.) IERR=13
    RETURN
END

```

```

C*****
C SUBROUTINE SAMCHK  THIS SUBROUTINE CHECKS THE MISSILE EMPLACEMENT
C                     AGAINST GAME LIMITATIONS.
C*****
C SUBROUTINE SAMCHK (X,IERR)
C   IERR=0
C   IF (X.GE. 6000.) RETURN
C   CALL ZRRMK (13)
C   IERR=1
C   RETURN
END

```

```

C*****
C SUBROUTINE ERRMK
C      THIS SUBROUTINE SENDS PROMPTS AND ERROR MESSAGES
C      TO THE USER.
C*****
C SUBROUTINE ERRMK (IEERR)
C COMMON /EN/ IEAUL
C COMMON /EN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
C COMMON /FAR/ X(200),Y(200),Z(200),HOG(200),CR(200),BR(200),VEL(200)
C 1) COMMON /FAR1/ XDOT(200),YDOT(200),ZDOT(200),MNUM,MBR
C COMMON /ERR/ MERR1(3),MKEY(15)
C IF (IEERR .GT. 21) GO TO 210
C-----
C FLASH THE PROMPT WINDOW
C-----
C CALL MIN (MINX2,MAXX2,2700.,185.,1)
C CALL GSFRCS
C GO TO (10,20,30,40,50,60,70,80,90,100,110,120,130,140,150,160,170,
180,190), IERR
10 WRITE (6,220)
GO TO 200
20 WRITE (6,230)
GO TO 200
30 WRITE (6,240)
GO TO 200
40 WRITE (6,250)
GO TO 200
50 WRITE (6,260)
GO TO 200
60 WRITE (6,270)
GO TO 200
70 WRITE (6,280)
GO TO 200
80 WRITE (6,290)
GO TO 200
90 WRITE (6,300)
GO TO 200
100 WRITE (6,310)
GO TO 200
110 WRITE (6,320)
GO TO 200
120 WRITE (6,330)
GO TO 200
130 WRITE (6,340)
GO TO 210
140 WRITE (6,350)
GO TO 210
150 WRITE (6,360)
GO TO 210
160 WRITE (6,370)
GO TO 210
170 WRITE (6,380)
GO TO 200
180 WRITE (6,390)
GO TO 200
190 WRITE (6,400)
GO TO 210
200 WRITE (6,410) X(MNUM),Y(MNUM),Z(MNUM),VEL(MNUM)
210 RETURN
220 FORMAT (25H MAXIMUM BRAKING EXCEEDED)
230 FORMAT (15H MAX G EXCEEDED)
240 FORMAT (12H ALT TOO LOW)
250 FORMAT (13H ALT TOO HIGH)
260 FORMAT (6H STALL)
270 FORMAT (15H PCF-IF TOO LOW)
280 FORMAT (13H BME DECF LOW)
290 FORMAT (12H BME DECF HI)
300 FORMAT (15H TCC FAR FM TGT)
310 FORMAT (17H HEG>5 DEG TO TGT)
320 FORMAT (19H FINAL RUN<2.33 SEC)
330 FORMAT (21H LC HORIZONTAL MOTION)
340 FORMAT (17H TCC CLOSE TO TGT)
350 FORMAT (23H ENTER MISSILE LOCATION)
360 FORMAT (26H ENTER AIRCRAFT MISSILES)
370 FORMAT (20H ENTER GUN LOCATIONS)

```

```
380 PCBMAT (18H MAX LIFT EXCEEDED)
390 FORMAT (20H MAX THRUST EXCEEDED)
400 PCBMAT (28H X COORDINATE LESS THAN 6000)
410 FORMAT (19H X,Y,Z,AND VELOCITY,4F9.1)
    END
```

```

C *****
C SUBROUTINE VALSET
C THIS SUBROUTINE COMPUTES THE FLIGHT PARAMETERS FOR
C EACH MILESTONE. XECT, YECT, ZECT, CA, HDG, AND RA
C ARE COMPUTED FOR OUTPUT TO PLOT AND MICE II. TND AND
C ACCLIFT ARE COMPUTED FOR USE BY ERCHK.
C *****
SUBROUTINE VALSET (IERR)
COMMON /PAR/ X(200),Y(200),Z(200),HDG(200),CA(200),RA(200),VEL(200)
1)
COMMON /PAR1/ XDCI(200),YDOT(200),ZDOT(200),MNUM,MBR
COMMON /PAR2/ T(200)
COMMON /PAR3/ TND,ACCLIFT,CLMAX,FLTMAX,CDO,CDK,VMAX1,VMAX2
DIMENSION AXC(200),AYD(200),AZL(200),XDD(200),YDD(200),ZDD(200)
GEE=.82
DX=X(MNUM)-X(MNUM-1)
DY=Y(MNUM)-Y(MNUM-1)
DZ=Z(MNUM)-Z(MNUM-1)
IF ((DX.NE.0.) .OR. (DY.NE.0.)) GO TO 10
IERR=12
RETURN
10
VAVGL=VAVG
DISTL=DIST
C -----
C LIMIT THE SPEED
C -----
DIST=SQRT(DX**2 + DY**2 + DZ**2)
IF ((VEL(MNUM) .GT. VMAX1) .AND. (MBR .EQ. 0)) VEL(MNUM)=VMAX1
IF ((VEL(MNUM) .GT. VMAX2) .AND. (MBR .GE. 1)) VEL(MNUM)=VMAX2
VAVG=(VEL(MNUM)+VEL(MNUM-1))/2.
DT=DIST/VAVG
T(MNUM)=T(MNUM-1)+DT
C -----
C COMPUTE AVERAGE VELOCITY COMPONENTS
C -----
AXD(MNUM)=VAVG*DX/DIST
AYD(MNUM)=VAVG*DY/DIST
AZD(MNUM)=VAVG*DZ/DIST
IF (MNUM .GE. 3) GO TO 40
C -----
C COMPUTE THE PARAMETERS FOR THE INITIAL LEG OF THE FLIGHT PATH
C -----
CA(1)=ATAN2(DZ,SQRT(DX**2 + DY**2))
IF ((DX .EQ. 0.) .OR. (DY .EQ. 0.)) GO TO 20
HDG(1)=ATAN2(DY,DX)
GO TO 30
20
IF ((DX .EQ. 0.) .AND. (DY .GT. 0.)) HDG(1)=1.57079
IF ((DX .EQ. 0.) .AND. (DY .LT. 0.)) HDG(1)=-1.57079
IF ((DY .EQ. 0.) .AND. (DX .GT. 0.)) HDG(1)=3.14159
IF ((DY .EQ. 0.) .AND. (DX .LT. 0.)) HDG(1)=0.
30
RA(1)=0.
XECT(1)=VEL(1)*DX/DIST
YECT(1)=VEL(1)*DY/DIST
ZECT(1)=VEL(1)*DZ/DIST
RETURN
40
DELT=(T(MNUM)-T(MNUM-1))/2.
C -----
C COMPUTE THE ACCELERATION COMPONENTS
C -----
XDD(MNUM-1)=(AXC(MNUM)-AXD(MNUM-1))/DELT
YDD(MNUM-1)=(AYD(MNUM)-AYD(MNUM-1))/DELT
ZDD(MNUM-1)=(AZC(MNUM)-AZD(MNUM-1))/DELT
C -----
C WEIGHT AVERAGE OF THE VELOCITY COMPONENTS
C -----
HCAVG=DISTL/(DIST+DISTL)
TDX=(AXD(MNUM)/VAVG-AXD(MNUM-1)/VAVGL)*HCAVG+AXD(MNUM-1)/VAVGL
TDY=(AYD(MNUM)/VAVG-AYD(MNUM-1)/VAVGL)*HCAVG+AYD(MNUM-1)/VAVGL
TDZ=(AZD(MNUM)/VAVG-AZD(MNUM-1)/VAVGL)*HCAVG+AZD(MNUM-1)/VAVGL
C -----
C MAKE THE WEIGHTED VALUES A UNIT VECTOR AND COMPUTE THE MILESTONE
C VELOCITY COMPONENTS
C -----
UNIT=SQRT(TDX*TDX + TDY*TDY + TDZ*TDZ)
IF (ABS(UNIT) .GE. 0.01) GO TO 50
IERR=12

```

```

RETURN
50 IDX=TDY/UNIT
   TEY=TDY/UNIT
   TDZ=TDZ/UNIT
   XDCT(MNUM-1)=VEL(MNUM-1)*TDX
   YDCT(MNUM-1)=VEL(MNUM-1)*TDY
   ZDCT(MNUM-1)=VEL(MNUM-1)*TDZ
   IF (SQRT(IDX*TDX+TEY*TEY) .GE. 0.01) GO TO 60
   CA(MNUM-1)=1.5533
   GO TO 70
60 CA(MNUM-1)=ATAN2(IDZ,SQRT(TDX*TDX+TDY*TEY))
70 IF ((TDX .EQ. 0.) .AND. (TDY .EQ. 0.)) GO TO 80
   HDG(MNUM-1)=ATAN2(TDY,TDX)
   GO TO 90
80 IF ((TDX .EQ. 0.) .AND. (TDY .GT. 0.)) HDG(MNUM-1)=1.57079
   IF ((TDX .EQ. 0.) .AND. (TDY .LT. 0.)) HDG(MNUM-1)=-1.57079
   IF ((TDY .EQ. 0.) .AND. (TDX .GT. 0.)) HDG(MNUM-1)=3.14159
   IF ((TDY .EQ. 0.) .AND. (TDX .LT. 0.)) HDG(MNUM-1)=0.
C-----
C COMPONENTS OF ACCELERATION IN THE AIRCRAFT COORDINATE SYSTEM
C-----
90 CASIN=SIN(CA(MNUM-1))
   CACOS=COS(CA(MNUM-1))
   HDSIN=SIN(HDG(MNUM-1))
   HDCOS=COS(HDG(MNUM-1))
   A11=XDC(MNUM-1)*HDCOS*CACOS
   A21=XDC(MNUM-1)*HDSIN
   A31=XDC(MNUM-1)*HDCOS*CASIN
   A12=YDC(MNUM-1)*HDSIN*CACOS
   A22=YDC(MNUM-1)*HDCOS
   A32=YDC(MNUM-1)*HDSIN*CASIN
   A13=(ZDC(MNUM-1)+GEE)*CASIN
   A23=0.
   A33=(ZDC(MNUM-1)+GEE)*CACOS
C-----
C COMPUTE ACCELERATION PARALLEL AND PERPENDICULAR TO FLIGHT PATH
C-----
   TMD=(A11+A12+A13)/GEE
   ACLPT=(SQRT((A21+A22)**2+(A31+A32+A33)**2))/GEE
   IF (ABS(A31+A32+A33) .GE. 0.01) GO TO 100
   RA(MNUM-1)=1.57079
   GO TO 110
100 RA(MNUM-1)=ATAN2((A21+A22),(A31+A32+A33))
110 CALL ERRMK (22)
   RETURN
   END

```



```

C*****
C SUBROUTINE ERRCHK
C      THIS SUBROUTINE EVALUATES THE FLIGHT PARAMETERS TO
C      ENSURE THAT THEY MEET THE DESIRED SIMULATION LIMITS.
C*****
SUBROUTINE ERRCHK (IEBR)
COMMON /PAR/ X(200),Y(200),Z(200),HDG(200),CA(200),RA(200),VEL(200)
1)
COMMON /PAR1/ YDOT(200),YDOT(200),ZDOT(200),MNUM,MBR
COMMON /PAR2/ T(200)
COMMON /PAR3/ TARGX,TARGY
COMMON /PAR3/ TBL,ACLIFT,CLMAX,WL,TMAX,CDO,CDK
COMMON /PAR4/ APPMAX,HTMIN,HTMAX,SPDMIN,GMAX,POPMIN
DATA TMSAV/-1./
DX=TARGX-X(MNUM)
DY=TARGY-Y(MNUM)
DIST=SQRT(DX**2 + DY**2)
C-----
C INITIALIZE POPALT AND IMSAV
C-----
IF ((MNUM.NE.2) .AND. (TMSAV.NE.-1.)) GO TO 10
PCFALT=0.
TMSAV=TMAX
10 IF (MBR.EQ.0 .AND. TMAX.NE.TMSAV) TMAX=IMSAV
CALL ERRCHK (23)
IF (MBR.GE.1) GO TO 20
IF ((DIST.LT. PCFMIN).OR. (Z(MNUM) .LT. APPMAX)) GO TO 20
IEBR=4
RETURN
20 IF (DIST.LE. PCFMIN .AND. Z(MNUM).GT. POPALT) POPALT=Z(MNUM)
IF (Z(MNUM) .GE. HTMIN) GO TO 30
IEBR=1
RETURN
30 Z(MNUM)=HTMIN
IF (Z(MNUM) .LE. ETMAX) GO TO 40
IEBR=4
RETURN
40 Z(MNUM)=ETMAX
IF (VEL(MNUM) .GE. SPDMIN) GO TO 50
IEBR=5
RETURN
50 IF (MNUM.EQ.2) RETURN
IF (ACLIFT.LE. GMAX) GO TO 60
IEBR=2
RETURN
C-----
C COMPUTE DRAG AND LIFT FORCES
C-----
60 BHO=0.0256*EXP(-0.103*(Z(MNUM)/1000.))
IF (Z(MNUM) .GE. 10670.) GO TO 70
BHO=0.00793*EXP(-0.156*(Z(MNUM)-10670.)/1000.)
70 CL=2*ACLIFT/(BHO*(VEL(MNUM)**2)/WL)
IF (CL.LE. CLMAX) GO TO 80
IEBR=17
RETURN
80 DW=((CDO+CDK*CL*CL)/CL)*ACLIFT
TW=TMD+DW
IF ((TW.LE. TMAX) .AND. (TW.GE.0.)) GO TO 90
IF (TW.GT. TMAX) IEBR=18
DW=(BHO*(VEL(MNUM)**2)/WL)*(0.05+CDO+CDK*(CL**2))/2.
IF (TMD+DW.LE.0) IEBR=1
IF (IEBR.NE.0) RETURN
90 IF (MNUM.NE. MBR) RETURN
C-----
C EVALUATE BECOMING RUN
C-----
DT=T(MNUM)-T(MNUM-1)
TGTHDG=ATAN2(DY,DX)*57.29578
IF (TGTHDG.LT.0.) TGTHDG=TGTHDG+360.
DX=X(MNUM)-X(MNUM-1)
DY=Y(MNUM)-Y(MNUM-1)
ACHDG=ATAN2(DY,DX)*57.29578
IF (ACHDG.LT.0.) ACHDG=ACHDG+360.
HGLST=ABS(TGTHDG-ACHDG)
IF (POPALT .GE. 1000.) GO TO 100
IEBR=6

```

```

100  RETURN
    IF (Z(MNUM) .GE. 100.) GO TO 110
    IERR=7
    RETURN
110  IF (Z(MNCM) .LE. 2000.) GO TO 120
    IERR=8
    RETURN
120  IF (DIST .LE. 2000.) GO TO 130
    IERR=9
    RETURN
130  IF (HDGLMT .LE. 5.) GO TO 140
    IERR=10
    RETURN
140  IF (DT .GE. 2.33) GO TO 150
    IERR=11
    TMAX=.2*TMAX
150  RETURN
    END

```

```

C*****
CC SUBROUTINE PTHPLT THIS SUBROUTINE ACTIFIES THE USER THAT HIS MILE-
CC      STONE HAS BEEN ACCEPTED AND THEN SAVES THE SUCCESSFUL
CC      POINT IN A TEMPORARY DISK FILE.
C*****
SUBROUTINE PTHPLT
COMMON /FAR/ X(200),Y(200),Z(200),HDG(200),CA(200),SA(200),VEL(200)
1)
COMMON /FAR1/ XDOT(200),YDOT(200),ZDOT(200),MNUM,MBR
COMMON /MN/ IBAUD
COMMON /MN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
REAL*4 TX1,TY1,TX2,TY2
LOGICAL *1CHARS(12)
TX1=X(MNUM-1)
TX2=X(MNUM)
TY1=Y(MNUM-1)
TY2=Y(MNUM)
-----
C IDENTIFY THE MAP, DRAW AND LABEL THE FLIGHT LEG
C-----
CALL MIN (MINX,MAXX,18000.,12000.,0)
CALL GENCVE (TX1,TY1)
CALL GBDEAW (TX2,TY2)
IF (MNUM.GT.99) IW=3
IF ((MNUM.GT.9) .AND. (MNUM.LT.100)) IW=2
IF (MNUM.LE.9) IW=1
CALL GAXITC (1,MNUM,IW,CHARS)
CALL GBCHAR (TX2,TY2,2,0.,IW,CHARS)
CALL GSFRCE
-----
C SAVE THE POINT IN 'TEMP DATA'
C-----
WRITE (19,10) X(MNUM),Y(MNUM),Z(MNUM),VEL(MNUM),MBR
RETURN
10 FORMAT (4F10.0,13)
END

```

```

C*****
CC SUBROUTINE AIMPT THIS SUBROUTINE MARKS A LINE FROM THE CURRENT
CC      AIRCRAFT POSITION TO THE TARGET AS A USER AID IN
CC      ALIGNING BOMB RELEASE POINT.
C*****
SUBROUTINE AIMPT (I)
COMMON /IAR/ TARGX,TARGY
COMMON /FAR/ X(200),Y(200)
REAL*4 TX,TY,TX1,TY1
TX=X(I)
TY=Y(I)
TX1=TARGX
TY1=TARGY
CALL GSLT (1)
-----
C MOVE TO CURRENT MILESTONE COORDINATES
C-----
CALL GENCVE (TX,TY)
-----
C DRAW DASHED LINE TO TARGET
C-----
CALL GBDEAW (TX1,TY1)
CALL GSLT (0)
RETURN
END

```

```

C*****
C SUBROUTINE ELFIN THIS SUBROUTINE REQUESTS THE USER OPTIONS AND CLOSES
C THE GRAPHIC SUBROUTINES.
C*****
      SUBROUTINE ELFIN (LAST)
      COMMON /CET/ IGUN,IPNCH,TEXT,ISAM,IMP,KER
      COMMON /MM/ ISABD
      COMMON /MM1/ MIN1,MAX1,MIN2,MAX2,MINX1,MAXX1,MINX2,MAXX2
C-----
C CLOSE GRAPHICS ROUTINES
C-----
      CALL DSIFRM
C-----
C OLD (LAST=0) OR NEW (LAST=1) FLIGHT PATH?
C-----
      IF (LAST.EQ. 0) GO TO 20
C-----
C REQUEST USER OUTPUT OPTIONS
C-----
10    WRITE (6,40)
      READ (5,*) LAST
      CALL PRTCHS ('CLASCRN ')
      IF (LAST.GE. 2 .OR. LAST.LT.0) GO TO 10
      LAST=1+82*LAST
20    WRITE (6,50)
      WRITE (6,60)
      READ (5,*) IPNCH
      CALL PRTCHS ('CLASCRN ')
C-----
C IF MILESTONES CAME FROM DISK, RETURN END OF FILE MARKER
C-----
      IF (LAST.EQ. 0) LAST=83
      IF (IPNCH.EQ. 0) RETURN
      IF (IPNCH.EQ. 2) GO TO 30
      WRITE (6,70)
      READ (5,*) TEXT
      CALL PRTCHS ('CLASCRN ')
      IF (IPNCH.EQ. 1) RETURN
30    WRITE (6,80)
      READ (5,*) ISAM
      CALL PRTCHS ('CLASCRN ')
      IF ((ISAM.LT. 1) .OR. (ISAM.GT. 7)) GO TO 30
      RETURN
40    FORMAT (51H ARE YOU FINISHED WITH THIS FLIGHTPATH: 0=NO; 1=YES)
50    FORMAT (43H OUTPUT FILE: 0=NO OUTPUT; 1=POOL FILE ONLY)
60    FORMAT (51H 2=MICE FILE ONLY; 3=POOL & MICE FILES)
70    FORMAT (49H EXTENDED OUTPUT: 0=NOT WANTED; 1=EXTENDED OUTPUT)
80    FORMAT (29H MISSILE TYPE BETWEEN 1 AND 7)
      END

```

```

C*****
C SUBROUTINE PRESET
C      THIS SUBROUTINE WRITES THE P001 AND MICE II FILES
C      FOR THE USER.
C*****
C SUBROUTINE PRESET
COMMON /PAR/ X(200), Y(200), Z(200), HDG(200), CA(200), RA(200), VEL(200)
1)
COMMON /PAR1/ XDCT(200), YDCT(200), ZDCT(200), ANUM, MBR
COMMON /PAR2/ T(200), XGUN(7), YGUN(7), ZGUN(7), XSAM, YSAM, ZSAM
COMMON /CPT/ IGUN, IENCH, IEXT, ISAM, IIE, IER
COMMON /NAM/ INAM1(2), INAM2(2), IUNR, IANR, IDEST
DIMENSION X10(200), Y10(200)
DIMENSION ECSTAB(1000), TINK(10)
DIMENSION VAT1N2(208), VATJ(208), VATS(208)
-----
C VULNERABLE AREA TABLE VS TYPE 1 AND 2 WEAPONS
C
DATA VAT1N2/2*.4645,6*7.107,2*.6568,6*5.551,2*.5968,6*5.574,2*.656
18,6*7.357,2*.6568,6*5.574,2*.6568,6*5.551,2*.5968,6*5.574,2*.6568,
26*7.357,2*.6568,6*5.574,2*.4645,6*.7432,2*.6568,6*2.858,2*.4645,6*
33,258,2*.6568,6*2.858,2*.4645,6*.7432,2*.6568,6*2.858,2*.4645,6*
4298,2*.6568,6*2.858,2*.5968,6*5.551,2*.5968,6*5.574,2*.6568,6*
57,2*.6968,6*5.574,2*.6568,6*5.551,2*.5968,6*5.574,2*.6568,6*7.357,
62*.6968,6*5.574,2*.4645,6*7.107/
-----
C VULNERABLE AREA TABLE VS TYPE 3 WEAPONS
C
DATA VAT3/2*.12.54,6*13.47,2*.9.653,6*10.51,2*.9.639,6*11.15,2*.12.64,
16*.14.78,6*.839,6*11.15,2*.9.653,6*10.51,2*.9.639,6*11.15,2*.12.64,
214.78,2*.839,6*11.15,6*1.394,2*.4.762,6*.6.240,2*.5.342,6*7.432,2*.4.
3762,6*.6.240,6*1.394,2*.4.762,6*.6.240,2*.5.342,6*7.432,2*.4.762,6*
40,2*.9.653,6*10.51,2*.9.639,6*11.15,2*.12.64,6*14.78,2*.9.639,6*11.15,
52*.9.653,6*10.51,2*.9.639,6*11.15,2*.12.64,6*14.78,2*.9.639,6*11.15,
612.54,6*13.47/
-----
C VULNERABLE AREA TABLE VS TYPE 5 WEAPONS
C
DATA VATS/8*.5.37,3*.43.22,3*.47.10,3*.62.53,6*.47.10,3*.43.22,3*.47.10,
18*.62.53,3*.47.10,6*.5.761,3*.27.45,6*.33.07,3*.27.45,3*.5.761,3*.27.45,
233.07,3*.27.45,6*.5.761,3*.47.10,6*.62.53,6*.47.10,3*.43.22,3*.47.10,6*
3.53,6*.47.10,3*.55.37/
-----
C RACAR CROSS SECTION TABLE
C
DATA ECSTAB/19*1000.,19*100.,19*10.,19*10.,19*10.,19*100.,19*1000.
1,867*0.0/
-----
C CALL ERRSET SUPPRESSES ANY POSSIBLE UNDERFLOW PROBLEMS THAT MAY
C RESULT FROM MANIPULATION OF SCENARIO PARAMETERS.
C
CALL ERRSET (208,50,-1,1,1)
JAN=0
-----
C CARD 2 TIME INCREMENT CALCULATION
C
TINC=T(MNUM)/1000.+0.0008
-----
C CARD 6 TIME INCREMENT CALCULATIONS
C
TINKI=0
DO 10 I=1,9
TINK(I)=TINKI+T(MNUM)/10
TINKI=TINK(I)
10 CONTINUE
-----
C ***** FUNCH PROGRAM *****
C
OPTION TO PUNCH THE P001 CARD DECK OR MICE-II CARD DECK
IF (IPNCH.EQ.2) GO TO 30
C
COMMENCE PUNCHED OUTPUT OF THE P001 CARD DECK.
C

```

```

C THE JCL CARDS.
C-----
      WRITE (18,60) INAM1(1),INAM1(2),IUNR,IANR,INAM1(1),INAM1(2),IUNR
      IF (IDEST.EQ.2) WRITE (18,70) IUNR
      WRITE (18,80)
      WRITE (18,90)
      WRITE (18,100)
      WRITE (18,110)
      WRITE (18,120)
      WRITE (18,130)
      WRITE (18,140)
      WRITE (18,150)
      WRITE (18,160)
C-----
C LEADING BLANK DATA CARD SIGNIFIES RADAR MASKING ANGLE OF ZERO.
C-----
C THE OUTPUT TITLE CARD.
C-----
      WRITE (18,190)
C-----
C CARD 2
C-----
      WRITE (18,170)
      WRITE (18,200) I(MNUM),TIME
C-----
C THE 2A CARDS (MILESTONES).
C-----
      DO 20 I=1,MNUM
      WRITE (18,210) T(I),X(I),Y(I),Z(I),XDOT(I),YDOT(I),ZDOT(I),HDG(I),
1CA(I),RA(I)
20 CONTINUE
      WRITE (18,230)
C-----
C CARD 3 (GUN EMPLACEMENT CARD).
C-----
      WRITE (18,240) XGUN(1),YGUN(1),ZGUN(1)
C-----
C CARD 4 (GUN TYPE).
C-----
      WRITE (18,220)
      WRITE (18,250)
C-----
C CARD 5
C-----
      WRITE (18,180)
      WRITE (18,260)
C-----
C CARD 6
C-----
      WRITE (18,270)
      WRITE (18,280) (LINK(I),I=1,9)
C-----
C CARD 7 (VULNERABLE AREA TABLE VS TYPE 1 AND 2 WEAPONS)
C-----
      WRITE (18,290)
      WRITE (18,300)
      WRITE (18,310) (VAT1N2(I),I=1,208)
C-----
C CARD 12 (EXECUTE RUN).
C EXTENDED OUTPUT OPTION
C-----
      WRITE (18,320)
      IF (IEXT.NE.1) WRITE (18,340)
      IF (IEXT.EQ.1) WRITE (18,330)
C-----
C THE REMAINDERS OF THE CARDS INTRODUCE NEW GUN LOCATIONS, GUN TYPES
C AND VULNERABLE AREA TABLES TO BE EXECUTED BY THE PROGRAM.
C-----
      WRITE (18,230)
      WRITE (18,240) XGUN(2),YGUN(2),ZGUN(2)
C-----
C EXTENDED OUTPUT OPTION
C-----
      WRITE (18,320)
      IF (IEXT.NE.1) WRITE (18,340)

```

```

      IF (IEXT.EQ.1) WRITE (19,330)
      WRITE (18,230)
      WRITE (18,240) XGUN(3),YGUN(3),ZGUN(3)
      WRITE (18,220)
      WRITE (18,330)
C-----
C EXTENDED OUTPUT OPTION
C-----
      WRITE (18,320)
      IF (IEXT.NE.1) WRITE (18,340)
      IF (IEXT.EQ.1) WRITE (18,330)
      WRITE (18,230)
      WRITE (18,240) XGUN(4),YGUN(4),ZGUN(4)
C-----
C EXTENDED OUTPUT OPTION
C-----
      WRITE (18,320)
      IF (IEXT.NE.1) WRITE (18,340)
      IF (IEXT.EQ.1) WRITE (18,330)
      WRITE (18,230)
      WRITE (18,240) XGUN(5),YGUN(5),ZGUN(5)
      WRITE (18,220)
      WRITE (18,330)
C-----
C CARD 7 (VULNERABLE AREA TABLE VS TYPE 3 WEAPONS)
C-----
      WRITE (18,290)
      WRITE (18,400)
      WRITE (18,310) (VAT3(I),I=1,208)
C-----
C-----
C EXTENDED OUTPUT OPTION
C-----
      WRITE (18,320)
      IF (IEXT.NE.1) WRITE (18,340)
      IF (IEXT.EQ.1) WRITE (18,330)
      WRITE (18,230)
      WRITE (18,240) XGUN(6),YGUN(6),ZGUN(6)
      WRITE (18,220)
      WRITE (18,370)
C-----
C EXTENDED OUTPUT OPTION
C-----
      WRITE (18,320)
      IF (IEXT.NE.1) WRITE (18,340)
      IF (IEXT.EQ.1) WRITE (18,330)
      WRITE (18,230)
      WRITE (18,240) XGUN(7),YGUN(7),ZGUN(7)
      WRITE (18,220)
      WRITE (18,380)
C-----
C CARD 7 (VULNERABLE AREA TABLE VS TYPE 5 WEAPON)
C-----
      WRITE (18,290)
      WRITE (18,410)
      WRITE (18,310) (VAT5(I),I=1,208)
C-----
C EXTENDED OUTPUT OPTION
C-----
      WRITE (18,320)
      IF (IEXT.NE.1) WRITE (18,340)
      IF (IEXT.EQ.1) WRITE (18,330)
      WRITE (18,390)
      IF (IPNCH.EQ.1) RETURN
C-----
C FORMAT STATEMENTS
C-----
30 CONTINUE
C-----
C COMMENCE PUNCHED OUTPUT OF THE MICE-II CARD DECK
C-----
C CHECK FOR VALID MISSILE DESIGNATION NUMBER FOR MICE II
      IF (ISAM.LE.7.AND.ISAM.GE.1) GO TO 40
      RETURN
C-----
C THE JCL CARDS

```

```

C-----
40  WRITE (17,420) INAM2(1),INAM2(2),IUNR,IANR,INAM2(1),INAM2(2),IUNR
    IF (IDEST.EQ.2) WRITE (17,430) IUNR
    WRITE (17,440)
    WRITE (17,450)
    WRITE (17,460)
    WRITE (17,470)
C-----
C THE OUTPUT TITLE CARDS
C-----
    WRITE (17,480)
    WRITE (17,490)
C-----
C THE PROBLEM RUN INPUT CARDS, CHECKING FOR TYPE OF MISSILE
C INPUT TO MICE II
C-----
    WRITE (17,500)
    IF (ISAM.EQ.1) WRITE (17,670)
    IF (ISAM.EQ.2) WRITE (17,680)
    IF (ISAM.EQ.3) WRITE (17,690)
    IF (ISAM.EQ.4) WRITE (17,700)
    IF (ISAM.EQ.5) WRITE (17,710)
    IF (ISAM.EQ.6) WRITE (17,720)
    IF (ISAM.EQ.7) WRITE (17,730)
C-----
C THE PSSK CALCULATION CARDS
C-----
    WRITE (17,510)
    WRITE (17,520)
C-----
C THE RADAR CROSS SECTION TABLE
C-----
    WRITE (17,530)
    WRITE (17,540)
    WRITE (17,550)
    WRITE (17,560)
    WRITE (17,570) (RCSTAS(I),I=1,133)
C-----
C THE SIMULATION TIME PARAMETERS
C-----
    WRITE (17,580)
    WRITE (17,590)
C-----
C THE MISSILE LAUNCHER LOCATION
C-----
    PTFAC=3.28084
    WRITE (17,600)
    XFSAM=XSAM*PTFAC
    YFSAM=YSAM*PTFAC
    ZFSAM=ZSAM*PTFAC
    WRITE (17,610) XFSAM,YFSAM,ZFSAM
C-----
C THE TARGET TRAJECTORY
C-----
    WRITE (17,620)
    WRITE (17,630) MNOM
C-----
C THE MILESTONE CARDS
C-----
    DO 50 I=1,MNOM
      Z(I)=X(I)*PTFAC
      Y(I)=Y(I)*PTFAC
      Z(I)=Z(I)*PTFAC
      VEL(I)=VEL(I)*PTFAC
      WRITE (17,640) T(I),X(I),Y(I),Z(I),VEL(I),CA(I),RA(I),RDG(I)
50  CONTINUE
C-----
C END OF PUNCHES CARDS
C-----
    WRITE (17,650)
    WRITE (17,660)
C-----
    RETURN
C-----
C /////***** FORMAT STATEMENTS *****/
C-----

```



```

60  FORMAT (2H//,2A4,6H JOB (,I4,1H,14,2H),,1H',2A4,1H ,I4,2HP')
70  FORMAT (19H//,MAIN OEG=NP5VM1,,I4,1HF)
80  FCBMAT (16H//,EXEC PGM=P1AD)
90  FORMAT (42H//,STEP113 DD DISP=SHR,DSN=MSS.F0559.P1PSAV)
100  FORMAT (47H//,GC.F107E001 DD UNIT=SYSDA,SPACE=(CYL,(1,1)),)
110  FCBMAT (41H//,ECF=1,RECFM=VBS,LRECL=404,BLKSIZE=3236))
120  FORMAT (22H//,GC.F109F001 DD DUMMY)
130  FCBMAT (25H//,GC.F106F001 DD SYSOUT=A)
140  FCBMAT (18H//,GC.F103F001 DD *)
150  FCBMAT (11H1,1,J,C,J,J)
160  FCBMAT (2H01)
170  FCBMAT (2H02)
180  FCBMAT (2H05)
190  FCBMAT (42H//,AIRCRAFT COMBAT SURVIVABILITY SCENARIO)
200  FORMAT (7H0,12,J,,F7.2,9H,100CCO.,,F7.4,1H/)
210  FCBMAT (10(F7-1,14))
220  FCBMAT (2H04)
230  FCBMAT (2H03)
240  FCBMAT (3(1X,F7.C),1CH 0.0,360.J)
250  FCBMAT (19H0,1,1,1,1,1,0.0,50.)
260  FCBMAT (7H1,1,1.0)
270  FCBMAT (2H06)
280  FCBMAT (3H1,9,9(1X,F7.3))
290  FCBMAT (2H07)
300  FCBMAT (49H//,VULNERABLE AREA TABLE VS TYPE 1 AND 2 WEAPONS)
310  FCBMAT (8F8,3)
320  FCBMAT (2H12)
330  FCBMAT (13H1,1,1,1,1,1,1)
340  FCBMAT (13H0,2,0,C,1,1,1)
350  FCBMAT (20H0,2,1,1,1,1,0.0,50.C)
360  FCBMAT (2CH0,3,4,4,1,1,0.0,50.C)
370  FCBMAT (2CH0,3,3,4,1,1,0.0,50.C)
380  FCBMAT (2CH0,5,3,2,1,1,0.0,50.C)
390  FCBMAT (2H/*)
400  FCBMAT (43H//,VULNERABLE AREA TABLE VS TYPE 3 WEAPONS)
410  FCBMAT (42H//,VULNERABLE AREA TABLE VS TYPE 5 WEAPONS)
420  FCBMAT (2H//,2A4,6H JOB (,I4,1H,14,2H),,1H',2A4,1H ,I4,2HP')
430  FCBMAT (19H//,MAIN OEG=NP5VM1,,I4,1HF)
440  FCBMAT (29H//,EXEC PGM=ECF,REGION=16CK)
450  FCBMAT (44H//,STEP113 DD DSN=MSS.F0559.MICESAV,DISP=SHR)
460  FCBMAT (23H//,FTC6F001 DD SYSOUT=A)
470  FCBMAT (15H//,FTC5F001 DD *)
480  FCBMAT (2H01)
490  FCBMAT (55HAE 3251 *****SURVIVABILITY SCENARIO***** SAM ENCOUNTER
1)
500  FCBMAT (2H02)
510  FCBMAT (2H06)
520  FCBMAT (9X,1H0,8X,2H0.,9X,1H0,4X,1H0,4X,1H0,8X,2H0.,8X,2H0.)
530  FCBMAT (2H08)
540  FCBMAT (7X,3H23.,3X,2H19,4X,1H7,4X,1H1)
550  FCBMAT (8X,2H0.,7X,3H10.,7X,3H20.,7X,3H30.,7X,3H40.,7X,3H50.,7X,3H
160.//,7X,3H70.,7X,3H80.,7X,3H90.,6X,4H100.,6X,4H110.,6X,4H120.,5X,
24H130.,6X,4H140.,6X,4H150.,6X,3H160,6X,4H170.,6X,4H180.)
560  FCBMAT (6X,4H-90.,6X,4H-60.,6X,4H-30.,8X,2H0.,7X,3H30.,7X,3H60.,7X
1,3H90.)
570  FCBMAT (7F10-2.,/7F10-2.,/5F10-2)
580  FCBMAT (2H09)
590  FCBMAT (7X,3H0.5,7X,3H0.1,7X,3H9.0,7X,3H0.0,8X,2H0.,7X,3H30.,8X,2H
10.)
600  FCBMAT (2H11)
610  FCBMAT (2X,F8.2,2F10.2)
620  FCBMAT (2H12)
630  FCBMAT (9X,1H1,2X,I3,4X,1H1,4X,1H0,8X,2H0.,8X,2H0.,8X,2H0.)
640  FCBMAT (F7.1,4F10.1,3F6.1,4X,2H0.,4X,2H0.)
650  FCBMAT (2H20)
660  FCBMAT (2H/*)
670  FCBMAT (9X,1H1,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H0)
680  FCBMAT (9X,1H2,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H0)
690  FCBMAT (9X,1H3,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H0)
700  FCBMAT (9X,1H4,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H0)
710  FCBMAT (9X,1H5,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H0)
720  FCBMAT (9X,1H6,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H0)
730  FCBMAT (9X,1H7,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H0)
END

```

```

C*****
C BLCCK DATA
C*****
      BLCCK DATA
COMMON /EN1/ MINY,MAXY,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
COMMON /ENR/ MKERY(3),MKERY(20)
COMMON /PAR/ X(200),Y(200),Z(200),HDG(200),CA(200),RA(200),VEL(200)
1)
COMMON /PAR1/ XDCT(200),YDOT(200),ZDCT(200),ANUM,MBR
COMMON /PAR2/ T(200),XGUN(7),YGUN(7),ZGUN(7),XSA1,YSA1,ZSA1,GB(7)
COMMON /PAR3/ TND,ACLIPT,CLMAX,ZL,TMAX,CDO,CDK,VMAX1,VMAX2
COMMON /PAR4/ AFEMAX,HTMIN,HTMAX,SPDMIN,GMAX,POPMIN
COMMON /TAR/ TARGX,TARGY
-----
C MAE WINDOW X COORDINATES
C-----
      DATA MINX/100/
      DATA MAXX/3700/
-----
C ALTIMETER WINDOW X COORDINATES
C-----
      DATA MINX1/3725/
      DATA MAXX1/3925/
-----
C FRECHTING WINDOW X COORDINATES
C-----
      DATA MINX2/3950/
      DATA MAXX2/4000/
-----
C COMMON Y COORDINATES FOR THE THREE WINDOWS
C-----
      DATA MINY/400/
      DATA MAXY/2900/
-----
C ESECR MESSAGE COORDINATES
C-----
      DATA MKERY/640,340,10/
      DATA MKERY/160,740,120,100,90,60,160,140,120,100,90,60,160,140,120
      1,100,90,60,180,40/
-----
C PREDETERMINED WEAPON ENPLACEMENT PARAMETERS
C-----
      DATA XGUN/14800.,16200.,13600.,13400.,11300.,15600.,12800./
      DATA YGUN/9000.,3200.,7200.,3000.,9700.,10900.,7500./
      DATA ZGUN/40.,40.,20.,30.,50.,20./
      DATA XSA1/12000.,15440,6000./,ZSA1/50./
      DATA GB/1000.,1000.,1400.,1400.,2500.,2500./
-----
C SIMULATION PARAMETERS
C-----
      DATA CLMAX/1./,WL/100./,SPDMIN/90./,GMAX/6./,HTMIN/60./
      DATA HTMAX/2050./,AFEMAX/457./,TMAX/0./,CDO/0.015/,CDK/0.1/
      DATA VMAX1/260./,VMAX2/310./,FCPMIN/6000./
      DATA TARGX/14000./,TARGY/7220./
      END

```

PROPOSED IEMPIP LISTING

```

C ***** 344 VERSION *****
C MAIN PROGRAM 16/MAB/344
C *****
C ***** THE EXECUTION OF THE ENTIRE PROGRAM. *****
C ***** THE PROPOSED MODIFICATION OF THE JOHNS *****
C ***** FOR SCHE CASES BUT NOT FOR EVERY *****
C ***** (LIGHT PACKAGE) (3IGCAL PACKAGE) *****
C ***** SEPARATELY AS 111 FORTRAN. THE *****
C ***** IS SET UP TO FILE AND *****
C ***** NOT CONTAIN ANY GRAPHICS DEPENDENT CALLS. *****
C ***** 16/MAB/344 *****
C *****
COMMON /MN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
COMMON /LCC/ X1,Z1,Z1,Z1,LTS,LTS2
COMMON /IN/ IEAUZ
COMMON /ABC1/ AX(1000),AY(1000),AZ(1000),W(1000),V(1000),W(1000)
1) /AH(1000),V(1000),Z(1000),X(1000),Y(1000),Z(1000),Y(1000),Z(1000)
COMMON /ABC2/ XNEW,XIEM,XOLD,YNEW,YIEM,YOLD,ZNEW,ZIEM,ZOLD
COMMON /AEDZ/ VSALL,VMAX,VMAX1,VMAX2,DELTAZ,DELTAZ1,DELTAZ2
COMMON /FARZ/ XGUN(7),YGUN(7),ZGUN(7),XSAM,YSAM,ZSAM,JR(7)
COMMON /CPT/ IGUN,LENCH,TEXT,XSAM,YSAM,KER,IMPZ
COMMON /NAM/ INAT(2),ZSAM2(2),IGUNR,IANR,IDEST
COMMON /TAR/ TARGX,TARGY
CALL ERRSET (207,250,-1,1,209)
ICT=2
VMAX=VMAX1
CALL BEGIN
CALL SCENE (0,0)
REWIND IC
C -----
C DRAW THE FIXED GUN SITE & ITS ENGAGEMENT CIRCLE
C -----
CALL GUNICC (XGUN(7),YGUN(7),CF(7))
C -----
C IGUN=1==> READ USER DEFINABLE GUN SITES FROM TERMINAL
C -----
IF (IGUN.NE.1) GO TO 43
C -----
C READ COMMENTS IN WINDOW: GRAPHICS INITIALIZER
C -----
CALL WIN (MINX,MAXX,18000.,12000.,0)
C -----
C GSLI DEFINES THE TYPE OF LINE TO BE DRAWN: BOLD, DASHED ETC.
C -----
CALL GSLI (1)
C -----
C GEGARC DRAWS ARCS AND IF SPECIFIED, WHOLE CIRCLES
C -----
CALL GEGARC (3000.,3000.,TARGX,TARGY,1.,1.,2.)
CALL GSLI (0)
CALL GSFRCE
IERR=16
CALL ERRCHK (IERR)
DO 40 I=1,0
10 CONTINUE
IERR=0
IF (IMPZ.NE.1) GO TO 20
CALL XYPT
ZGUN(I)=20.
GO TO 30
20 CONTINUE
CALL XYPT
CALL ZVPT
ZGUN(I)=Z1
30 CONTINUE
XGUN(I)=X1
YGUN(I)=Y1
C -----
C IF GUN TYPE 3, CHK FOR 3 KM SEPARATION FM BRIDGE
C -----
IF (T.GE.5) CALL GUNCHK (X1,Y1,IERR)
IF (IERR.NE.0) GO TO 10
C -----
C DRAW GUN SITE AND ENGAGEMENT CIRCLE OF SELECTED GUNSITES
C -----
CALL GUNICC (XGUN(I),YGUN(I),GR(I))
WRITE (10,250) XGUN(I),YGUN(I),ZGUN(I)

```

```

40      CONTINUE
C-----
C  READ USER DEFINEABLE SAM SITE FM TERMINAL
C-----
50      CONTINUE
      IERR=14
      CALL ERRMK (IERR)
      IF (IMPZ.NE.1) GO TO 60
      CALL XYPT
      ZSAM=20
      GO TO 70
60      CCNTINUE
      CALL XYPT
      CALL ZVPT
      ZSAM=21
70      CCNTINUE
      XSAM=X1
      YSAM=Y1
C-----
C  VERIFY SAM SITE AT LEAST 6KM FM WESTERN BOUNDARY
C-----
      CALL SAMCHK (X1,IERR)
      IF (IERR.NE.3) GO TO 50
C-----
C  DRAW SAM SITE
C-----
      CALL GUNICC (YSAM,YSAM,150.)
      WRITE (10,250) XSAM,YSAM,ZSAM
      GO TO 120
C-----
C  IGUN=2==> READ GUN SITES FROM DATA FILE
C-----
80      CONTINUE
      IF (IGUN.NE.3) GO TO 100
      DO 90 I=1,6
      READ (10,150) XGUN(I),YGUN(I),ZGUN(I)
90      CONTINUE
      READ (10,250) XSAM,YSAM,ZSAM
C-----
C  DRAW GUN SITES AND ENGAGEMENT CIRCLES
C-----
100     CONTINUE
      DO 110 I=1,6
      CALL GUNICC (XGUN(I),YGUN(I),GP(I))
110     CONTINUE
      CALL GUNICC (XSAM,YSAM,150.)
120     CONTINUE
C-----
C  THIS SECTION ACCEPTS THE FLIGHT MILESTONES
C-----
      IERR=15
      CALL ERRMK (IERR)
      REWIND 11
C-----
C  READ MILESTONES FROM THE DISK
C-----
130     IF (IMP.NE.0) GO TO 140
      READ (11,260) T(1CT),WX(1CT),WY(1CT),WZ(1CT),WU(1CT),WV(1CT),WW(1CT),
     1T),WH(1CT),WP(1CT),WA(1CT),WG(1CT),LTR
      LTR2=LTR
C-----
C  LTR=65 ==> CALL PCB AIM
C  LTR=66 ==> CALL PCB BCME RELEASE. ALSO ALLOWS INCREASED AIRSPEED.
C  LTR=82 ==> CALL PCB PFCGGM TERMINATION
C  LTR=83 ==> CALL TO BREAK OFF INPUT ROUTINE AND RESTART. MEANT TO
C-----
C  ALLOW CHANGING MIND WHILE IN MIDDLE OF PROGRAM.
C-----
      IF (LTR.EQ.65.CB.LTR2.EQ.65) CALL AIMET
      IF (LTR.EQ.66.CB.LTR2.EQ.66) VMA1=VMA12
      IF (LTR.EQ.82.CB.LTR2.EQ.82.AND.IMP.NE.0) GO TO 180
      IF (LTR.EQ.83.CB.LTR2.EQ.83) GO TO 140
      CALL GRAFIX
      ICT=ICT+1
      GO TO 130
C-----
C  READ MILESTONES FROM THE TERMINAL

```

```

C-----
140  CONTINUE
    CALL WIN (MINX,MAYX,18000.,12000.,0)
    CALL GSLLT (1)
    CALL GBGARC (6000.,6000.,TARGX,TARGY,1.,1.,2.)
    CALL GSLLT (0)
    CALL GSFBCE
    CALL XYPT
    CALL ZVPT
C-----
C COMPUTE FLIGHT PARAMETERS AND CHECK FOR ERRORS OR USER COMMANDS
C-----
    IERR=0
    CALL ZBRCK (IERR)
    IF (IERR.EQ.0) GO TO 150
    WRITE (8,270)
    WRITE (8,280)
    READ (5,4) ICC5
    CALL PRICMS ('CLBSCRN')
    IF (ICOR.NE.1) GO TO 150
    CALL XYPT
C-----
C WAYPOINT ACCEPTED, FILL IN THE CURVE
C-----
150  CONTINUE
    CALL BIGCAL
    ICT=ICT+1
    IF (XOLD.NE.XNEW.OR.YOLD.NE.YNEW.OR.ZOLD.NE.ZNEW) GO TO 150
C-----
C LTR=65 ==> CALL FOR AIM
C LTR=66 ==> CALL FOR SCMB RELEASE. ALSO ALLOWS INCREASED AIRSPEED.
C LTR=82 ==> CALL FOR PROGFAM TERMINATION
C LTR=83 ==> CALL TO BREAK OFF INPUT ROUTINE AND RESTART. MEANT TO
              ALLOW CHANGING WIND WHILE IN MIDDLE OF PROGRAM.
C-----
    IF (LTR.EQ.65.OR.LTR2.EQ.65) CALL AIMET
    IF (LTR.EQ.66.OR.LTR2.EQ.66) VMAX=VMAX2
    IF (LTR.EQ.82.OR.LTR2.EQ.82.AND.IMP.NE.0) GO TO 180
    IF (LTR.EQ.83.OR.LTR2.EQ.83) GO TO 160
    GO TO 140
C-----
C THIS SECTION RESETS THE DATA
C-----
160  CALL SCENE (1,ICNT)
    REWIND 19
C-----
C DRAW RETAINED MILESTONES
C-----
    REWIND 11
    ICT=ICNT
    DO 170 I=1,ICT
    READ (11,260) T(ICT),WX(ICT),WY(ICT),WZ(ICT),WU(ICT),WV(ICT),WW(IC
170  T(I),WH(ICT),WP(ICT),WB(ICT),WG(ICT),LFR
    LTR2=LTR
    IF (LTR.EQ.65.OR.LTR2.EQ.65) CALL AIMET
    IF (LTR.EQ.66.OR.LTR2.EQ.66) VMAX=VMAX2
    IF (LTR.EQ.82.OR.LTR2.EQ.82.AND.IMP.NE.0) GO TO 180
    IF (LTR.EQ.83.OR.LTR2.EQ.83) GO TO 140
    CALL GRAFIX
    CONTINUE
    GO TO 100
C-----
C THIS SECTION TERMINATES THE PROGRAM
C-----
180  CONTINUE
    LAST=IMP
    CALL ELFIN (LAST)
C-----
C CONVERT ANGLES FROM RADIAN TO DEGREES
C-----
    DO 190 I=1,ICT
    WH(I)=WH(I)*RTD
    WP(I)=WP(I)*RTD
    WB(I)=WB(I)*RTD
190  CONTINUE
C-----

```

```

C WRITE THE JCL CARDS
C
      IF (IPNCH.EQ.1) STOP
      IF (IPNCH.EQ.2) GO TO 200
      WRITE (6,230)
      WRITE (6,300)
      WRITE (6,310)
      WRITE (6,320)
      READ (5,400) INAM1(1),INAM1(2)
      CALL FRTCMS ('CLSCFN ')
200   IF (IPNCH.EQ.1) GO TO 210
      WRITE (6,330)
      WRITE (6,300)
      WRITE (6,310)
      WRITE (6,320)
      READ (5,400) INAM2(1),INAM2(2)
      CALL FRTCMS ('CLSCFN ')
210   WRITE (6,340)
      READ (5,*) IUNR
      CALL FRTCMS ('CLSCFN ')
      WRITE (6,350)
      READ (5,*) IANR
      CALL FRTCMS ('CLSCFN ')
C
C CHOOSE DESTINATION FOR OUTPUT: PRINTER OR READER FILE
C
      WRITE (6,360)
      WRITE (6,370)
      READ (5,*) IDEST
      IF ((IDEST.NE.1).AND.(IDEST.NE.2)) GO TO 220
      CALL FRTCMS ('CLSCFN ')
C
C PRESET LOADS MICE/POO1 DATA FILES ONTO USERS A1 DISK
C
      CALL PRESET
C
C DUMMY INPUT ROUTINE TO LET USER KNOW WHERE S/HE IS IN THE PGM
C
      WRITE (6,380)
      READ (5,*) IGO
      CALL FRTCMS ('CLSCFN ')
C
C FORCE CALL TO CMS TO SUBMIT DATA FILES TO BATCH PROCESSING PGM
C
      IF (IPNCH.EQ.2) GO TO 230
      CALL FRTCMS ('EXEC ', 'SUBMIT ', 'POO1 ', 'DATA ')
      IF (IPNCH.EQ.1) GO TO 240
      CALL FRTCMS ('EXEC ', 'SUBMIT ', 'MICE ', 'DATA ')
230   CALL FRTCMS ('EXEC ')
240   CONTINUE
C
C DUMMY INPUT ROUTINE TO LET USER KNOW PGM TERMINATION HAS BEEN REACHED
C
      WRITE (6,390)
      READ (5,*) IGO
      STOP
250   FORMAT (3F10.2)
260   FCORMAT (11(F10.1,1X),I3)
270   FORMAT (3H )
280   FCORMAT (54H DO YOU WANT TO FIX THE ERROR:0=NO,USE THE POINT:1=YES)
290   FCORMAT (40H TO SUBMIT POO1 TO BATCH YOU MUST CREATE)
300   FCORMAT (31H A JOB CONTROL LANGUAGE "CARC")
310   FCORMAT (51H ENTER A NAME - IT MAY CONTAIN UP TO 8 CHARACTERS;)
320   FCORMAT (25H **DO NOT INSERT BLANKS**)
330   FCORMAT (44H TO SUBMIT **MICE** TO BATCH YOU MUST CREATE)
340   FCORMAT (46H ENTER YOUR USER ID NUMBER -- WITHOUT THE "SH.")
350   FCORMAT (48H ENTER YOUR ACCT. NUMBER -- PROVIDED BY THE PROF.)
360   FCORMAT (41H CHOOSE THE DESTINATION FOR YOUR OUTPUT: )
370   FCORMAT (3CH 1=PRINTER; 2=YOUR READER FILE)
380   FCORMAT (46H ENTER ANY **NUMBER** TO SUBMIT YOUR POO1/MICE,14H DATA
1     FILE(S) )
390   FCORMAT (4CH ENTER ANY **NUMBER** TO TERMINATE T22IP)
400   FCORMAT (2A4)
      END

```

```

C*****
C SUBROUTINE BEGIN
C      THIS SUBROUTINE INITIALIZES THE GRAPHICS AND REQUESTS
C      THE USER OPTIONS.
C*****
C      SUBROUTINE BEGIN
C      COMMON /OFT/ IGUN,IFNCH,TEXT,ISAM,IMP,KON,IMPZ
C-----
C READ USER OPTIONS
C-----
10  CALL FRTCMS ('CLRSCRN ')
    WRITE (6,40)
    READ (5,*) IGUN
    IF ((IGUN.NE.0).AND.(IGUN.NE.1).AND.(IGUN.NE.2)) GO TO 10
    CALL FRTCMS ('CLRSCRN ')
    IF (IGUN.NE.1) GO TO 20
    WRITE (6,50)
    WRITE (6,60)
    READ (5,*) IMPZ
    CALL FRTCMS ('CLRSCRN ')
20  WRITE (6,70)
    READ (5,*) IMP
    IF ((IMP.NE.0).AND.(IMP.NE.1)) GO TO 20
    CALL FRTCMS ('CLRSCRN ')
30  WRITE (6,80)
    READ (5,*) KON
    IF ((KON.NE.1).AND.(KON.NE.2)) GO TO 30
    CALL FRTCMS ('CLRSCRN ')
    IF (KON.NE.1) CALL CONCHG
C-----
C INITIALIZE THE GRAPHICS AND CLEAR SCREEN
C-----
    CALL DSINIT
    CALL GSERSE
    RETURN
40  FORMAT (50H GUNS:C=DISK FILE;1=TERMINAL;2=PRESENT(GOUGE SET OF GUNS
1)
50  FORMAT (55H ** CHOICE 1 NEGATES HAVING TO GO OVER TO THE ALIIMETER
1)
60  FORMAT (55H GUN/SAM SITE ALTITUDE:1=FIXED TO 20M;2=USER DEFINEABLE
1)
70  FORMAT (50H AIRCRAFT MILESTONE INPUT: 0=DISK FILE; 1=TERMINAL)
80  FORMAT (50H FLIGHT & GAME PARAMETERS: 1=DEFAULT; 2=USER INPUT)
90  END

```

```

C*****
C SUBROUTINE CONCHG
C      THIS SUBROUTINE ALLOWS OPERATOR CHANGES TO THE
C      SIMULATION PARAMETERS.
C*****
C SUBROUTINE CONCHG
C COMMON /AED2/ VSTALL,VMAX,VMAX1,VMAX2,DELTEE,DELTU,DELTZ
C COMMON /AED4/ THMAX,ANMAX,CLMAX,GES,AKK,PHOSSE,L,CDO,CDK,AREA
C COMMON /AED4/ APPEMAX,HTMIN,HTMAX,POPMIN,JAALT,BRAIN,BRMAX,BRMIN,S
C BRMAX,RTD,AMIF
C COMMON /TAB/ TARGX,TARGY
C-----
C WRITE INSTRUCTIONS
C-----
10  WRITE (6,190)
    WRITE (6,200)
    WRITE (6,210)
    WRITE (6,220)
    WRITE (6,230)
    WRITE (6,240)
    WRITE (6,250)
    WRITE (6,260)
    WRITE (6,270)
    READ (5,*) K
    IF ((K - 1).EQ.0) OR ((K - GT. 17)) GO TO 10
    GO TO (180,20,30,40,50,60,70,80,90,100,110,120,130,140,150,160,170
1) , K
20  WRITE (6,280)
    READ (5,*) CLMAX
    GO TO 10
30  WRITE (6,290)
    READ (5,*) AL
    GO TO 10
40  WRITE (6,300)
    READ (5,*) VSTALL
    GO TO 10
50  WRITE (6,310)
    READ (5,*) ANMAX
    GO TO 10
60  WRITE (6,320)
    READ (5,*) HTMIN
    GO TO 10
70  WRITE (6,330)
    READ (5,*) HTMAX
    GO TO 10
80  WRITE (6,340)
    READ (5,*) POPMIN
    GO TO 10
90  WRITE (6,350)
    READ (5,*) APPEMAX
    GO TO 10
100 WRITE (6,360)
    READ (5,*) THMAX
    GO TO 10
110 WRITE (6,370)
    READ (5,*) CDO
    GO TO 10
120 WRITE (6,380)
    READ (5,*) CDK
    GO TO 10
130 WRITE (6,390)
    READ (5,*) VMAX1
    GO TO 10
140 WRITE (6,400)
    READ (5,*) VMAX2
    GO TO 10
150 WRITE (6,410)
    READ (5,*) TARGX,TARGY
    GO TO 10
C-----
C READ NEW PARAMETER VALUES FROM THE DISK
C-----
160 REWIND 16
    READ (16,450) CLMAX,AL,VSTALL,ANMAX,HTMIN,HTMAX
    READ (16,450) POPMIN,APPEMAX,THMAX,CDO,CDK,VMAX1
    READ (16,450) VMAX2,TARGX,TARGY

```



```

GO TO 10
C-----
C WRITE PARAMETER VALUES TO THE TERMINAL
C-----
170  WRITE (6,420)  CLMAX,WL,VSTALL,ANMAX,HTMIN,HTMAX
      WRITE (6,430)
      WRITE (6,440)  POPMIN,APPMAX,THMAX,CDO,CDK,VMAX1
      WRITE (6,450)  VMAX2,TARGX,TARGY
      GO TO 10
C-----
C SAVE PARAMETER VALUES ON DISK AND RETURN TO CALLING ROUTINE
C-----
180  REWIND 16
      WRITE (16,450) CLMAX,WL,SPDMIN,GMAX,HTMIN,HTMAX
      WRITE (16,450) PCMIN,APPMAX,THMAX,CDO,CDK,VMAX1
      WRITE (16,450) VMAX2,TARGX,TARGY
      RETURN
190  FORMAT (25H )
200  FORMAT (5CH SELECT PARAMETER TO BE CHANGED: 1=NO MORE CHANGES)
210  FORMAT (48H 2=MAX LIFT COEFF; 3=WING LOADING; 4=STALL SPEED)
220  FORMAT (47H 5=MAX G FORCS; 6=MIN ALT; 7=MAX ALT(<2200 MTR))
230  FORMAT (42H 8=DISTANCE TO TARGET BEFORE POPUP ALLOWED)
240  FORMAT (63H 9=MAX APPROACH ALT; 10=MAX T/W RATIO; 11=DRAG COEF. W/
10  LIFT)
250  FORMAT (44H 12=LIFT CFA; CONSTANT; 13=MAX SPD WITH BOMB)
260  FORMAT (44H 14=MAX SPD W/C BOMB; 15=TARGET COORDINATES )
270  FORMAT (43H 16=ENTERED PARAMETER FILE; 17=LIST PARAMETERS)
280  FORMAT (27H 18=MAX LIFT COEFFICIENT)
290  FORMAT (19H 19=ENTERED WING LOADING)
300  FORMAT (18H 20=STALL SPEED)
310  FORMAT (26H 21=MAX G BEFORE ALLOWED)
320  FORMAT (23H 22=MAXIMUM ALTITUDE)
330  FORMAT (47H 23=MAXIMUM ALTITUDE (LESS THAN 2000 METERS))
340  FORMAT (55H 24=MINIMUM DISTANCE TO TARGET BEFORE POP-UP ALLOWED)
350  FORMAT (32H 25=MAXIMUM APPROACH ALTITUDE)
360  FORMAT (35H 26=MAX THRUST TO WEIGHT ALLOWED)
370  FORMAT (37H 27=DRAG COEFFICIENT FOR ZERO LIFT)
380  FORMAT (25H 28=LIFT DRAG CONSTANT)
390  FORMAT (32H 29=MAX SPEED CARRYING A BOMB)
400  FORMAT (39H 30=MAX SPEED AFTER BOMB IS RELEASED)
410  FORMAT (33H 31=TARGET X AND Y COORDINATES)
420  FORMAT (55H 32=MAX CL WING LD STALL SPD MAX G MIN-HT. MAX-HT.
1)
430  FORMAT (75H POP-UP DIST APPR-HT. MAX THRUST CDO DRAG CONSTANT
1 MAX SPD WITH BOMB)
440  FORMAT (55H MAX SPD W/O BOMB TARGET X COORD. TARGET Y COORD.
1)
450  FORMAT (6F12.4)
      END

```

```

C*****
C SUBROUTINE SCENE THIS ROUTINE DRAWS THE ATTACK MAP AND ASSOCIATED
C DISPLAYS. DURING RESET IT OBTAINS THE LAST MILE-
C SIGN THE USER WISHES TO RETAIN.
C*****
SUBROUTINE SCENE (IRC,ICNT)
COMMON /MN1/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
COMMON /MN/ IBAUD
COMMON /ASCI/ *I(1000),*Y(1000),*Z(1000),*U(1000),*V(1000),*W(1000)
1) *H(1000),*P(1000),*R(1000),*G(1000),*T(1000),*CT
COMMON /TAR/ TARGX,TARGY
DIMENSION VEL(200)
VEL(ICNT)=SQRT(*U(ICNT)**2+*V(ICNT)**2+*W(ICNT)**2)
REAL*4 GX,GY
LOGICAL *ICHARS(20)
ICNT=0
-----
C ERASE THE TEK618 SCREEN
C-----
CALL GSERSE
CALL DSTERS
C-----
C READ USER OPTIONS: ECRER AND GUN/MISS POSITS OR FILL IN MAP ALSO.
C-----
WRITE (6,100)
READ (5,*) MAP
IF (IRC.EQ. 0) GC TO 10
WRITE (6,30)
READ (5,*) ICNT
CALL GETCHS ('CLASCFN')
C-----
C DRAW THE X,Y MAP
C THE ROUTINE READS X,Y PAIRS FROM FILE 09. A -2,0,0 INDICATES
C END OF FILE, -0,0,0 INDICATES A MOVE, ALL OTHER VALUES ARE CO-
C ORDINATE AND RESULT IN A DRAW TO THAT POINT.
C-----
C RE-INITIALIZE THE TEK618 SCREEN
C-----
10 CALL DSINIT
CALL MIN (MINX,MAXX,18000.,12000.,1)
IF (MAP.EQ. 0) GC TO 40
REWIND 9
20 READ (9,80) GX,GY
READ (9,80) GX,GY
CALL GBVECT (0.,GX,GY)
30 READ (9,80) GX,GY
IF (GX.LT.-1) GO TO 40
IF (GX.LT. 0) GO TO 20
CALL GBVECT (1.,GX,GY)
GO TO 30
C-----
C MARK THE TARGET: GUNLOC PUTS A + AT GUN/MISS POSIT AND CIRCUMSCRIBES
C-----
40 CALL GUNLOC (TARGX,TARGY,150.)
CALL GUNLOC (TARGX,TARGY,300.)
C-----
C DRAW TIC MARKS EVERY 2000 FTBS
C-----
DO 50 I=1,3
IW=2*I
C-----
C THIS BLOCK DRAWS THE X-AXIS TIC MARKS
C-----
CALL GBVECT (0.,I*2000.,1000.)
CALL GBVECT (1.,I*2000.,0.)
CALL GAXITC (1,IW,2,CHARS)
CALL GBCHAR (I*2000.,0.,2.,0.,2,CHARS)
C-----
C THIS BLOCK DRAWS THE Y-AXIS TIC MARKS
C-----
IF (I.GE. 6) GO TO 50
CALL GBVECT (0.,1000.,I*2000.)
CALL GBVECT (1.,0.,I*2000.)
CALL GAXITC (1,IW,2,CHARS)
CALL GBCHAR (-60.,I*2000.,2.,0.,2,CHARS)

```

```

50  CONTINUE
    I1=MINY
    I2=MAXY
    MAXY=MINY-15
    MINY=MINY-200
    CALL WIN (MINX+275, MINX+2200, 195., 185., 0)
    CALL GBCHAB (10., 110., 2.5, 0., 30., 'KEY MARKS IN 2000 METER INTVLS')
    CALL GBCEAR (10., 40., 2.5, 0., 25., 'ZERO DEGREES ALONG X AXIS')
    CALL GSFRCE
    MAXY=I2
    MINY=I1
-----
C  DRAW THE ALTIMETER
C -----
    CALL WIN (MINX1, MAXX1, 350., 2200., 1)
    DO 60 I=2, 20, 2
    CALL GBVECT (0., 0., I*100.)
    CALL GBVECT (1., 350., I*100.)
    CALL GAXITC (1, 1, 2, CARS)
    CALL GBCHAB (0., I*100., 2., 0., 2, CHARS)
60  CONTINUE
    DO 70 I=1, 6
    CALL GBVECT (0., I*50., 100.)
    CALL GBVECT (1., I*50., 0.)
70  CONTINUE
-----
C  MARK RESET POINT VELOCITY AND ALTITUDE AS OPERATOR AID
C -----
    IF (I20.NE.0 .AND. ICNT.GT.1) CALL GEGDOT (9., VEL(ICNT), WZ(ICNT))
    MAXY=MINY-15
    MINY=MINY-200
    CALL WIN (MINX+2800, MINX+3900, 195., 185., 0)
    CALL GBCHAB (10., 110., 2.5, 0., 29., 'ALT MARKS IN 200 METER INTVLS')
    CALL GBCEAR (10., 60., 2.0, 0., 33., 'VELO IN 50 1/5 INTVL ALONG X AXIS')
1)  CALL GSFRCE
    MAXY=I2
    MINY=I1
    RETURN
80  FORMAT (2F10-2)
90  FORMAT (38H AT WHICH POINT DO YOU WANT TO RESTART)
100 FORMAT (38H VILLAGE: 0=NOT DRAWN; 1=VILLAGE DRAWN)
    END

```

```

C*****
C SUBROUTINE WIN
C      THIS ROUTINE DEFINES A WINDOW EXTENDING FROM LX TO MX
C      ON THE HORIZONTAL AXIS, AND FROM MINY TO MAXY ON THE
C      VERTICAL AXIS. THE HORIZONTAL RANGE IS RX, THE
C      VERTICAL RANGE IS RY.
C*****
C      SUBROUTINE WIN (LX,MX,RX,RY,JMF)
C      COMMON /MM/ IEAUD
C      COMMON /MM/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
C      REAL*4 WAN1(4)
C      INTEGER*4 I(4)
C      DATA WAN1(1)/0.,WAN1(2)/0./
C-----
C  DEFINE THE WINDOW
C-----
C      V1(2)=MINY
C      V1(4)=MAXY
C      WAN1(3)=RX
C      WAN1(4)=RY
C      V1(1)=LX
C      V1(3)=MX
C      CALL GASVIE (V1,I)
C      CALL GASWIN (WAN1,C)
C      IF (JMF.EQ.0) GC TC 20
C-----
C  FLASH THE DEFINED WINDOW
C-----
C      ICNT=4+50*IEAUD
C      DO 10 I=1,ICNT
C      CALL GSVECT (C,0,0,0,WAN1(4))
C      CALL GSVECT (1.,WAN1(1),WAN1(4))
C      CALL GSVECT (1.,WAN1(3),WAN1(4))
C      CALL GSVECT (1.,WAN1(3),WAN1(2))
C      CALL GSVECT (1.,WAN1(1),WAN1(2))
C-----
C  YOU DO NOT WANT A "CALL GSFRCE" HERE. WINDOW DEFINES THE GRAPHICS
C  PCET OR "MINEC" YOU ARE "OPENING". THE OTHER SUBROUTINES ARE PASSING
C  THINGS THROUGH THE OPEN WINDOW. "CALL GSFRCE" CLOSSES THE WINDOW.
C-----
10  CONTINUE
20  RETURN
    END

```

```

C*****
C SUBROUTINE GUNLOC
C      THIS SUBROUTINE DRAWS EFFECTIVE FIRE RADIUS CIRCLES
C      AROUND THE DEFENSIVE AAA BATTERIES.
C*****
C      SUBROUTINE GUNLOC (GX,GY,RAD)
C      COMMON /EN/ LEAD
C      COMMON /MN1/ MIN1,MAX1,MIN2,MAX2,MINX1,MAXX1,MINX2,MAXX2
C      REAL*4 X,Y,DX,DY
C      X=GX
C      Y=GY
C-----
C IDENTIFY THE MAP AND PLACE A '+' AT THE LOCATION
C-----
C      CALL WIN (MIN1,MAX1,18000.,12000.,0)
C      CALL GBVECT (0.,X-75.,Y)
C      CALL GBVECT (1.,X+75.,Y)
C      CALL GBVECT (0.,X,Y-75.)
C      CALL GBVECT (1.,X,Y+75.)
C-----
C DRAW A CIRCLE AROUND THE SITE
C-----
C      CALL GSLT (14)
C      CALL GEGARC (RAD,RAD,X,Y,1.,1.,2.)
C      CALL GSLT (0)
C      CALL GSPRCE
C      RETURN
C      END

```

```

C*****
C SUBROUTINE XYPT
C      THIS SUBROUTINE OBTAINS THE X AND Y COORDINATES
C      AND COMMAND FOR EACH DESIGNATED POINT (MILESTONE).
C*****
C      SUBROUTINE XYPT
C      COMMON /LCC/ X1,Y1,Z1,V1,ITR,ITR2
C      COMMON /MN1/ MIN1,MAX1,MIN2,MAX2,MINX1,MAXX1,MINX2,MAXX2
C      CALL BELL
C-----
C FLASH MAP AND GET X,Y AND THE FIRST COMMAND
C-----
C      CALL WIN (MIN1,MAX1,18000.,12000.,1)
C      CALL SPOT (X1,Y1,ITR)
C      CALL GSPRCE
C      CALL BELL
C      RETURN
C      END

```

```

C*****
C SUBROUTINE ZVPT
C      THIS SUBROUTINE OBTAINS THE ALTITUDE AND, DEPENDING
C      ON THE CIRCUMSTANCES, THE VELOCITY OF THE DESIGNATED
C      POINT.
C*****
C      SUBROUTINE ZVPT
C      COMMON /LCC/ X1,Y1,Z1,V1,ITR,ITR2
C      COMMON /MN1/ MIN1,MAX1,MIN2,MAX2,MINX1,MAXX1,MINX2,MAXX2
C-----
C FLASH ALTIMETER AND GET VEL,ALT AND THE SECOND COMMAND
C-----
C      CALL WIN (MINX1,MAXX1,350.,2200.,1)
C      CALL SPOT (V1,Z1,ITR2)
C      CALL GSPRCE
C      RETURN
C      END

```

```

C*****
C SUBROUTINE SPOT      THIS RETURNS AN X-Y PAIR AND A COMMAND VALUE L1
C                      THE ROUTINE ALSO CREATES A DOT AT POINT X,Y.
C*****
SUBROUTINE SPOT (X,Y,L1)
  REAL*4 TX,TY,ECT
  INTEGER*4 L,M,CUT,KEY
C-----
C READ THE CURSOR AND PICK UP USER COMMAND
C-----
10  CALL GBRXYC (M,L,KEY,TX,TY)
    CALL GAXCTI (1,KEY,1,LEN,OUT)
    DOT=40.
C-----
C MARK THE SPOT
C-----
    CALL GBGECT (DOT,IX,IY)
    X=TX
    Y=TY
C-----
C CONVERT THE COMMAND TO THE PROPER FORMAT
C-----
    L1=0
    IF (OUT.EQ.1) L1=65
    IF (OUT.EQ.2) L1=66
    IF (OUT.EQ.3) L1=62
    IF (OUT.EQ.4) L1=63
    RETURN
END

C*****
C SUBROUTINE GUNCHK   THIS SUBROUTINE CHECKS GUN LOCATIONS AGAINST
C                      EMPLACEMENT RULES.
C*****
SUBROUTINE GUNCHK (X,Y,IERR)
  COMMON /TAR/ TARGX,TARGY
C-----
C COMPUTE DISTANCE TO TARGET
C-----
  DIST=SQRT((X-TARGX)**2 + (Y-TARGY)**2)
  IERR=0
  IF (DIST .GE. 3000.) RETURN
  IERR=13
  CALL ERRMK (IERR)
  RETURN
END

C*****
C SUBROUTINE SAMCHK   THIS SUBROUTINE CHECKS THE MISSILE EMPLACEMENT
C                      AGAINST GAME LIMITATIONS.
C*****
SUBROUTINE SAMCHK (X,IERR)
  IERR=0
  IF (X .GE. 6000.) RETURN
  IERR=13
  CALL ERRMK (IERR)
  RETURN
END

```

```

C*****
C SUBROUTINE ERMK      THIS SUBROUTINE SENDS PROMPTS AND ERROR MESSAGES
C                      TO THE USER.
C*****
C SUBROUTINE ERMK (IERR)
COMMON /MN/ IERR
COMMON /AEC/ AX(1000), AY(1000), AZ(1000), AX(1000), AY(1000), AZ(1000)
1) ,WH(1000), WP(1000), WB(1000), WG(1000), T(1000), ICT
COMMON /EN/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
C-----
C FLASH THE PROMPT WINDOW
C-----
      CALL WIN (MINX2,MAXX2,2700.,185.,1)
      CALL GSPECE
      GO TO (10,20,30,40,50,60,70,80,90,100,110,120,130,140,150,160,170,
1180), IERR
10  WRITE (6,200)
      GC TO 190
20  WRITE (6,210)
      GC TO 190
30  WRITE (6,220)
      GC TO 190
40  WRITE (6,230)
      GC TO 190
50  WRITE (6,240)
      GC TO 190
60  WRITE (6,250)
      GC TO 190
70  WRITE (6,260)
      GC TO 190
80  WRITE (6,270)
      GC TO 190
90  WRITE (6,280)
      GC TO 190
100 WRITE (6,290)
      GC TO 190
110 WRITE (6,300)
      GC TO 190
120 WRITE (6,310)
      GC TO 190
130 WRITE (6,320)
      GC TO 190
140 WRITE (6,330)
      GC TO 190
150 WRITE (6,340)
      GC TO 190
160 WRITE (6,350)
      GC TO 190
170 WRITE (6,360)
      GC TO 190
180 WRITE (6,370)
      GC TO 190
190 RETURN
200 FORMAT (25H MAXIMUM ERAKING EXCEEDED)
210 FORMAT (15H MAX G EXCEEDED)
220 FORMAT (12H ALT TCO LOW)
230 FORMAT (13H ALT TCO HIGH)
240 FORMAT (6H STALL)
250 FORMAT (15H PCF-JF TCO LOW)
260 FORMAT (13H BME DFCF LOW)
270 FORMAT (12H BME DFCF HI)
280 FORMAT (15H TCC F&R FM TGT)
290 FORMAT (17H HDG>5 DEG TO TGT)
300 FORMAT (19H FINAL RUN<2.33 SEC)
310 FORMAT (21H NC HCBIZCNTAL MOTICN)
320 FORMAT (17H TOC CLOSSE TO TGT)
330 FORMAT (23H ENTER MISSILE LOCATION)
340 FORMAT (26H ENTER AIRCRAFT MILESTONES)
350 FORMAT (20H ENTER GUN LOCATIONS)
360 FORMAT (20H MAX THRUST EXCEEDED)
370 FORMAT (28H X COORDINATE LESS THAN 6000)
      END

```

```

C*****
C SUBROUTINE SIGCAL THIS SUBROUTINE OPERATES AT A LEVEL BELOW MAIN
C PROGRAM AND ACTS AS A DRIVER FOR THE SUBROUTINES
C LISTED WITHIN.
C*****
SUBROUTINE SIGCAL
COMMON /AEC1/ WX(1000), WY(1000), WZ(1000), WU(1000), WV(1000), WW(1000)
1) /AEC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
IZTEMP, ZOLD
COMMON /AEC3/ VELCN, VELOT, VELCC, N, UNEW, UTEMP, UOLD, VNEW, VTEMP, VOLD,
1) WNEW, WTEMP, WOLD
COMMON /AEC4/ AG1, AH1, AI1, AJ1, AJ2
COMMON /AEC5/ VSTALL, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTE
COMMON /AEC6/ FADACC, AN, HCONT
N=0
HCONT=0
CALL TENFSM
CALL NEWCLD
CALL MVELCS
CALL MVDCLIS
CALL DELVEC
CALL TMPENT
CALL TMPVEL
CALL INBTSM
CALL ANGLES
CALL ROTRAT
CALL ACTRM1
CALL ACTRM2
CALL ACTSM3
CALL ACRVEL
CALL ACACC
CALL ACLM7S
CALL ACHANGE
CALL MAYENT
CALL FILE
ICT=ICT+1
RETURN
END

```



```

C*****
C SUBROUTINE TRNFRM
C*****
C TRANSFORM TAKES THE REAL VALUE VARIABLES SUPPLIED
C BY THE GRAPHICS SUBROUTINES AND LOADS THEM INTO
C VARIABLES SPECIFIC TO THIS AIRCRAFT TRAJECTORY
C GENERATING PACKAGE.
C*****
SUBROUTINE TRNFRM
COMMON /ICC/ X1,Y1,Z1,V1,ITR,ITR2
COMMON /ABC2/ XNEW,DELX,XTEMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1ZTEMP,ZOLD
COMMON /ABC3/ VELCN,VELOT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1VNEW,VTEMP,VOLD
COMMON /ABES/ FWDACC,AN,MCONT
XNEW=X1
YNEW=Y1
ZNEW=Z1
VELCN=V1
RETURN
END

```

```

C*****
C SUBROUTINE NEWOLD
C*****
C NEWOLD GENERATES LENGTH VECTOR COMPONENTS BETWEEN
C THE CURRENT WAYPOINT (OLD) AND THE DESIRED WAYPOINT
C USER HAS JUST ENTERED (NEW).
C*****
SUBROUTINE NEWOLD
COMMON /ABC2/ XNEW,DELX,XTEMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1ZTEMP,ZOLD
COMMON /ABC4/ AG1,AH1,AI1,AJ1,AJ2
COMMON /ABES/ FWDACC,AN,MCONT
AG1=XNEW-XOLD
AH1=YNEW-YOLD
AI1=ZNEW-ZOLD
AJ1=SQRT(AG1**2+AH1**2+AI1**2)
AJ2=SQRT(AG1**2+AH1**2)
RETURN
END

```

```

C*****
C SUBROUTINE MVELO3
C MVELO3 (MAP VELOCITY COMPONENTS) DETERMINES THE
C VELOCITY COMPONENTS BETWEEN CURRENT WAYPOINT (OLD)
C AND THE JUST ENTERED WAYPOINT (NEW). THE SUBROUTINE
C CONTAINS A FLAG (N) TO AVOID RESETTING THE VELOCITY
C COMPONENTS UNTIL EITHER A NEW WAYPOINT IS RECEIVED
C OR AN AIRCRAFT LIMITATION WHICH IS FATAL IS REACHED
C IN THE SUBSEQUENT INTERACTIVE SUBROUTINES. THE
C COORDINATE SYSTEM IS TERMED MAP, I.E., Y POINTS NORTH
C*****
      SUBROUTINE MVELO3
      COMMON /ABC4/ AG1,AH1,AI1,AJ1,AJ2
      COMMON /AEC3/ VELCN,VELOT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTMP,VOLD,
1 WNEW,WTMP,WOLD
      COMMON /AEE5/ FWLACC,AN,MCONT
      M=N
      IF (N.GT.0) GO TO 10
      UNEW=VELCN*(AG1/AJ1)
      VNEW=VELCN*(AH1/AJ1)
      WNEW=VELCN*(AI1/AJ1)
10  CONTINUE
      N=1
      RETURN
      END

```

```

C*****
C SUBROUTINE MVDOTS
C MVDOTS (MAP VELOCITY DOT COMPONENTS) COMPUTES THE
C LINEAR ACCELERATION COMPONENTS
C IN MAP COORDINATES. (Y POINTS NORTH)
C*****
      SUBROUTINE MVDOTS
      COMMON /AEC2/ XNEW,DELX,XTMP,XOLD,YNEW,DELY,YTMP,YOLD,ZNEW,DELZ,
1 ZTMP,ZOLD
      COMMON /AEC3/ VELCN,VELOT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTMP,VOLD,
1 WNEW,WTMP,WOLD
      COMMON /AEC4/ AG1,AH1,AI1,AJ1,AJ2
      COMMON /AEE1/ EDC1,VDOT,WDOT
      COMMON /AEE5/ FWLACC,AN,MCONT
      ACC=(VELCN**2-VELCC**2)/(2*AJ1)
      UDOT=ACC*(AG1/AJ1)
      VDOT=ACC*(AH1/AJ1)
      WDOT=ACC*(AI1/AJ1)
      RETURN
      END

```

```

C*****
C SUBROUTINE DELVEC
C      DELVEC (DELTA VECTORS) UTILIZES STANDARD DYNAMIC
C      EQUATIONS TO GENERATE LINEAR TRANSLATION INCREMENTS.
C      IT FURTHER LOOKS TO SEE WHETHER THESE INCREMENTS
C      EXCEED THE DISTANCE LEFT TO GO TO THE NEW WAYPOINT
C*****
C SUBROUTINE DELVEC
COMMON /ABC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1ZTEMP, ZOLD
COMMON /ABC3/ VELCN, VELOT, VELCC, N, UNEW, UTEMP, UOLD, VNEW, VTEMP, VOLD,
1VNEW, VTEMP, VOLD
COMMON /ABC4/ AG1, AH1, AI1, AJ1, AJ2
COMMON /ABD2/ VSIAL1, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTAZ
COMMON /ABE1/ CDCT, CDCT, WDOT
COMMON /ABE5/ FWLACC, AN, MCONT
DELX=XOLD*DELTEE+.5*WDOT*DELTEE**2
DELY=YOLD*DELTEE+.5*WDOT*DELTEE**2
DELZ=ZOLD*DELTEE+.5*WDOT*DELTEE**2
IF (ABS(DELX).GT.ABS(AG1)) DELX=AG1
IF (ABS(DELY).GT.ABS(AH1)) DELY=AH1
IF (ABS(DELZ).GT.ABS(AI1)) DELZ=AI1
RETURN
END

```

```

C*****
C SUBROUTINE TMPNT
C      TMPNT (TEMPORARY POINT) GENERATES A TEMPORARY
C      POSITION IN SPACE BASED UPON THE DELTA VECTORS
C*****
C SUBROUTINE TMPNT
COMMON /ABC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1ZTEMP, ZOLD
COMMON /ABC3/ VELCN, VELOT, VELCC, N, UNEW, UTEMP, UOLD, VNEW, VTEMP, VOLD,
1VNEW, VTEMP, VOLD
COMMON /ABC4/ AG1, AH1, AI1, AJ1, AJ2
COMMON /ABD2/ VSIAL1, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTAZ
COMMON /ABE5/ FWLACC, AN, MCONT
XTEMP=XOLD+DELX
YTEMP=YOLD+DELY
ZTEMP=ZOLD+DELZ
IF (DELX.EQ.AG1) XTEMP=XNEW
IF (DELY.EQ.AH1) YTEMP=YNEW
IF (DELZ.EQ.AI1) ZTEMP=ZNEW
RETURN
END

```

```

C*****
C SUBROUTINE TMPVEL TMEVEL (TEMPORARY VELOCITY COMPONENTS) GENERATES
C THE VELOCITY COMPONENTS ASSOCIATED WITH THE TEMPORARY
C POINT IN SPACE (MAP COORDINATES).
C*****

```

```

SUBROUTINE TMPVEL
COMMON /AEC2/ XNEW,DELX,XTEMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1 ZTEMP,ZOLD
COMMON /AEC3/ VELCN,VELOT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1 WNEW,WTEMP,WOLD
COMMON /AEC4/ AG1,AH1,AI1,AJ1,AJ2
COMMON /ABD2/ VSTALL,VMAX,VMAX1,VMAX2,DELTEE,DELTU,DELTAZ
COMMON /AEE1/ UDOT,VDOT,WDOT
COMMON /AEE5/ FWCACC,AN,MCONT
UTEMP=UOLD+UDOT*DELTEE
VTEMP=VOLD+VDOT*DELTEE
WTEMP=WOLD+WDOT*DELTEE
IF (ABS(UTEMP).GT.ABS(UNEW).AND.MCONT.EQ.1) UTEMP=UNEW
IF (ABS(VTEMP).GT.ABS(VNEW).AND.MCONT.EQ.1) VTEMP=VNEW
IF (ABS(WTEMP).GT.ABS(WNEW).AND.MCONT.EQ.1) WTEMP=WNEW
IF (DELX.EQ.AG1) UTEMP=UNEW
IF (DELY.EQ.AH1) VTEMP=VNEW
IF (DELZ.EQ.AI1) WTEMP=WNEW
IF (DELX.NE.0.) GC TO 10
UDOT=0
GC TO 20
CONTINUE
10 IF (UTEMP.EQ.UNEW) UDOT=(UTEMP**2-UOLD**2)/(2*DELX)
CONTINUE
20 IF (DELY.NE.0.) GC TO 30
VDOT=0
GC TO 40
CONTINUE
30 IF (VTEMP.EQ.VNEW) VDOT=(VTEMP**2-VOLD**2)/(2*DELY)
CONTINUE
40 IF (DELZ.NE.0.) GC TO 50
WDOT=0
GC TO 60
CONTINUE
50 IF (WTEMP.EQ.WNEW) WDOT=(WTEMP**2-WOLD**2)/(2*DELZ)
CONTINUE
60 VELOT=SQRT(UTEMP**2+VTEMP**2+WTEMP**2)
RETURN
END

```

```

C*****
C SUBROUTINE INBTRM INBTRM (INITIAL ROTATIONAL TRANSFORMATION) TRANSFORMS
C MAP COORDINATE COMPONENTS TO A SYSTEM USED BY FLIGHT
C DYNAMICISTS (Y POINTS SOUTH AND Z POINTS DOWN)
C*****

```

```

SUBROUTINE INBTRM
COMMON /AEC3/ VELCN,VELOT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1 WNEW,WTEMP,WOLD
COMMON /AEE1/ UDOT,VDOT,WDOT
COMMON /AEE5/ FWCACC,AN,MCONT
COMMON /AEE1/ U1,V1,W1,U2,V2,W2,U3,V3,W3
COMMON /AEE2/ UC1,VC1,WC1,UC2,VC2,WC2,UC3,VC3,WC3
U1=UTEMP
V1=-VTEMP
W1=-WTEMP
UC1=UDOT
VC1=-VDOT
WC1=-WDOT
RETURN
END

```

```

C*****
C SUBROUTINE ANGLES
C*****
C ANGLE COMPUTES THE ANGLE CHANGE INCREMENTS CAUSED
C BY MOVEMENT FORWARD TO THE TEMPORARY POINT. PSINEW
C IS THE LEADING CHANGE, REFERENCED TO THE X AXIS.
C THENEW IS THE PITCH CHANGE REFERENCED TO THE
C HORIZONTAL PLANE. PHINEW IS THE ROLL INCREMENT ABOUT
C THE X AXIS.
C*****

```

```

C SUBROUTINE ANGLES
C COMMON /AEC2/ XNEW, DELX, XTEMP, XCLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1 ZTEMP, ZOLD
C COMMON /AEC3/ VELON, VELOT, VELOC, V, UNEW, UTEMP, UOLD, VNEW, VTEMP, VOLD,
1 WNEW, WTEMP, WCLD
C COMMON /AEC4/ AG1, AH1, AI1, AJ1, AJ2
C COMMON /AED1/ AA1, AB1, AC1
C COMMON /AED2/ VSTALL, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTZ
C COMMON /AED4/ PSINEW, THENEW, PHINEW, PSICLD, THEOLD, PHIOLD
C COMMON /AEE5/ FWIACC, AN, MCONT
DS=SQRT(DELX**2+DELY**2+DELZ**2)
IF (DELX.NE.0.) GC TC 10
IF (DELY.EQ.0..AND.DELY.LT.0.) PSINEW=AA1
IF (DELX.EQ.0..AND.DELY.GT.0.) PSINEW=-AA1
GC TO 20
CONTINUE
PSINEW=-ATAN(DELY/DELX)
IF (DELX.GT.0..AND.DELY.EQ.0.) PSINEW=0.
IF (DELX.LT.0..AND.DELY.LT.0.) PSINEW=AB1+PSINEW
IF (DELX.LT.0..AND.DELY.EQ.0.) PSINEW=AB1
IF (DELX.LT.0..AND.DELY.GT.0.) PSINEW=PSINEW-AB1
20 CONTINUE
THENEW=ASIN(DELZ/DS)
TRNRAT=(PSINEW-PSICLD)/DELTEE
IF (PSINEW.GT.0.) PHINEW=ATAN(ABS(TRNRAT*VELOT/9.7953))
IF (PSINEW.LT.0.) PHINEW=-ATAN(ABS(TRNRAT*VELOT/9.7953))
IF (PSINEW.EQ.PSICLD) PHINEW=PHIOLD.
RETURN
END

```

```

C*****
C SUBROUTINE ROTRAT
C*****
C ROTRAT (ROTATIONAL RATES) COMPUTES THE ANGLE DOT
C INCREMENTS IN THE INERTIAL REFERENCE SYS. (THE ONE
C WITH Y POINTING SOUTH AND Z DOWN).
C*****

```

```

C SUBROUTINE ROTRAT
C COMMON /AEC2/ XNEW, DELX, XTEMP, XCLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1 ZTEMP, ZOLD
C COMMON /AED2/ VSTALL, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTZ
C COMMON /AED3/ PSIDOT, THEDOT, PHIDOT
C COMMON /AED4/ PSINEW, THENEW, PHINEW, PSICLD, THEOLD, PHIOLD
C COMMON /AEE5/ FWIACC, AN, MCONT
PSIDOT=(PSINEW-PSICLD)/DELTEE
THEDOT=(THENEW-THEOLD)/DELTEE
PHIDOT=(PHINEW-PHIOLD)/DELTEE
RETURN
END

```

```

C*****
C SUBROUTINE ACTRM1
C      ACTRM1 (AIRCRAFT TRANSFORMATION MATRIX #1) EFFECTS
C      ROTATION OF AIRCRAFT ABOUT THE Z1 AXIS (POS 2
C      POINTS DOWN TO EARTH).
C*****
C      SUBROUTINE ACTRM1
C      COMMON /ABD4/ PSINW,THENW,PHINW,PSICLD,THEOLD,PHIOLD
C      COMMON /AEE5/ EWACC,AW,ACONT
C      COMMON /ABF1/ U1,V1,W1,U2,V2,W2,U3,V3,W3
C      COMMON /AEF2/ UD1,VE1,WD1,UD2,VE2,WD2,UD3,VD3,WD3
C      ANG=PSINW
C      U2=COS (ANG)*U1+SIN (ANG)*V1
C      V2=-SIN (ANG)*U1+CCS (ANG)*V1
C      W2=W1
C      UD2=COS (ANG)*UD1+SIN (ANG)*VD1
C      VD2=-SIN (ANG)*UD1+CCS (ANG)*VD1
C      WD2=WD1
C      RETURN
C      END

```

```

C*****
C SUBROUTINE ACTRM2
C      ACTRM2 ROTATES THE AIRCRAFT ABOUT THE Y2 (RIGHT WING)
C      AXIS.
C*****
C      SUBROUTINE ACTRM2
C      COMMON /ABD4/ PSINW,THENW,PHINW,PSICLD,THEOLD,PHIOLD
C      COMMON /AEE5/ EWACC,AW,ACONT
C      COMMON /ABF1/ U1,V1,W1,U2,V2,W2,U3,V3,W3
C      COMMON /AEF2/ UD1,VE1,WD1,UD2,VE2,WD2,UD3,VD3,WD3
C      ANG=THENW
C      U3=COS (ANG)*U2-SIN (ANG)*W2
C      V3=V2
C      W3=SIN (ANG)*U2+CCS (ANG)*W2
C      UD3=COS (ANG)*UD2-SIN (ANG)*WD2
C      VE3=VD2
C      WD3=SIN (ANG)*UD2+CCS (ANG)*WD2
C      RETURN
C      END

```

```

C*****
C SUBROUTINE ACTRM3
C*****
C***** ROTATES AIRCRAFT ABOUT THE X3 (NOSE) AXIS *****
C*****
SUBROUTINE ACTRM3
COMMON /ABD4/ PSINEM,THENEM,PHINEM,PSIOLD,THEOLD,PHIOLD
COMMON /AEE5/ FWDACC,AN,MCONT
COMMON /ABF1/ U1,V1,W1,U2,V2,W2,U3,V3,W3
COMMON /AEE2/ UD1,VD1,WD1,UD2,VD2,WD2,UD3,VD3,WD3
COMMON /AEE3/ UAC,VAC,WAC,UDOTAC,VDOTAC,WDOTAC,P,Q,R
ANG=PHINEM
UAC=U3
VAC=U3*(ANG)*V3+SIN(ANG)*W3
WAC=-SIN(ANG)*V3+U3*(ANG)*W3
UDOTAC=UD3
VDOTAC=UD3*(ANG)*V3+SIN(ANG)*W3
WDOTAC=-SIN(ANG)*V3+UD3*(ANG)*W3
RETURN
END

```

```

C*****
C SUBROUTINE ACRVEL
C*****
C***** ACRVEL (AIRCRAFT ROTATIONAL VELOCITIES) COMPUTES THE *****
C***** ROTATIONAL VELOCITIES IMPOSED ON THE *****
C***** AIRCRAFT, IN THE ROTATIONAL OR AIRCRAFT COORDINATE *****
C***** SYSTEM. (X ALONG THE NOSE, Y OUT THE RIGHT WING, *****
C***** Z OUT THE BOTTOM OF THE AIRCRAFT.) *****
C*****
SUBROUTINE ACRVEL
COMMON /AED3/ PSIDOT,THEDOT,PHIDOT
COMMON /AED4/ PSINEM,THENEM,PHINEM,PSIOLD,THEOLD,PHIOLD
COMMON /AEE5/ FWDACC,AN,MCONT
COMMON /ABF3/ UAC,VAC,WAC,UDOTAC,VDOTAC,WDOTAC,P,Q,R
ANG1=THENEM
ANG2=PHINEM
F=PHIDOT-SIN(ANG1)*PSIDOT
Q=U3*(ANG2)*THEDOT+U3*(ANG1)*SIN(ANG2)*PSIDOT
W=-SIN(ANG2)*THEDOT+U3*(ANG1)*COS(ANG2)*PSIDOT
RETURN
END

```

```

C*****
C SUBROUTINE ACACC (AIRCRAFT ACCELERATIONS) PUTS TOGETHER THE LINEAR
C ACCELERATIONS RESULTING FROM TRANSLATION THROUGH
C SPACE AND THE ROTATIONAL ACCELERATIONS RESULTING
C FROM MANEUVERING. WHAT APPEARS BELOW IS THE LHS
C OF THE CLASSIC EQUATIONS OF MOTION FOR AN AIRCRAFT.
C*****

```

```

SUBROUTINE ACACC
COMMON /ABC2/ XNEW,DELX,XTMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DE LZ,
1 ZTEMP,ZOLD
COMMON /AEE3/ AX,AY,AZ
COMMON /AEE5/ FWLACC,AN,MCONT
COMMON /AEE3/ CAC,VAC,MAC,UDOTAC,7DOTAC,8DOTAC,P,Q,R
AX=UDOTAC-VAC*R+MAC*E
AY=VDOTAC+CAC*R+MAC*E
AZ=WDOTAC-UAC*Q+VAC*E
A=-VAC*R
E=MAC*Q
C=UAC*R
D=-WAC*P
E=-UAC*Q
F=VAC*P
RETURN
END

```

```

C*****
C SUBROUTINE ACLMIS (AIRCRAFT LIMITATIONS) COMPARES THE
C ACCELERATIONS RESULTING FROM A PROPOSED MOVE ALONG A
C FLIGHT-PAATH TRAJECTORY TO THE PHYSICAL LIMITATIONS OF
C THE AIRCRAFT. THIS IS ESSENTIALLY THE RHS OF THE
C EQUATIONS OF MOTION. IF THE TRAJECTORY ACCELERATIONS
C ARE LARGER THAN ALLOWABLE THEY ARE ADJUSTED DOWNWARD
C IN MAGNITUDE UNTIL THE RHS AND LHS OF THE EQUATIONS
C OF MOTION ARE EQUATED.
C*****

```

```

SUBROUTINE ACLMIS
COMMON /AEE3/ AX,AY,AZ
COMMON /AEE4/ THMAX,ANMAX,CLMAX,GEE,TO,SHOSSL,WL,CDO,CDX,AREA,DTDH
COMMON /AEE5/ FWLACC,AN,MCONT
CALL THRUST
IF (AN.LT.ANMAX.AND.FWLACC.LT.THMAX) CALL BOOSTR
C IF (AN.GT.ANMAX.OR.FWLACC.GT.THMAX) CALL REDUCR
RETURN
END

```



```

C*****
C SUBROUTINE BCCSTR
C          BCCSTR INCREASES THE LINEAR ACCELERATIONS UNTIL
C          MAXIMUM ALLOWABLE PERFORMANCE IS REACHED
C*****
SUBROUTINE BOOSTR
COMMON /ABC2/ XNEW,DELY,YTEMP,XCLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1ZTEMP,ZOLD
COMMON /ABC4/ AG1,AH1,AI1,AJ1,AJ2
COMMON /AEE1/ UDOT,VDOT,WDOT
COMMON /AEE3/ AX,AI,AZ
COMMON /AEE4/ THMAX,ANMAX,CLMAX,GEE,TO,RHOSL,AL,CDO,CDK,AREA,OTDH
COMMON /AEE5/ FWDACC,AN,MCONT
MCONT=1
CONTINUE
10 I=0
IF (AG1.EQ.DELEX.OR.AG1.EQ.0.) GO TO 20
IF (ABS(AG1).LT.AES(AH1).AND.AES(AG1).LT.ABS(AI1)) I=1
IF (I.NE.1) GO TO 20
UDOT=1.02*UDOT
CONTINUE
20 IF (AH1.EQ.DELY.OR.AH1.EQ.0.) GO TO 30
IF (ABS(AH1).LT.AES(AG1).AND.AES(AH1).LT.ABS(AI1)) I=2
IF (I.NE.2) GO TO 30
VDOT=1.02*VDOT
CONTINUE
30 IF (AI1.EQ.DELZ.OR.AI1.EQ.0.) GO TO 40
IF (ABS(AI1).LT.AES(AG1).AND.AES(AI1).LT.ABS(AH1)) I=3
IF (I.NE.3) GO TO 40
WDOT=1.02*WDOT
CONTINUE
40 IF (AG1.EQ.DELEX.OR.AG1.EQ.0.) GO TO 50
IF (ABS(AG1).EQ.AES(AI1).AND.AES(AG1).LT.ABS(AH1)) I=4
IF (I.NE.4) GO TO 50
UDOT=1.02*UDOT
WDOT=1.02*WDOT
CONTINUE
50 IF (AH1.EQ.DELY.OR.AH1.EQ.0.) GO TO 60
IF (ABS(AG1).EQ.AES(AH1).AND.AES(AG1).LT.ABS(AI1)) I=5
IF (I.NE.5) GO TO 60
VDOT=1.02*VDOT
WDOT=1.02*WDOT
CONTINUE
60 IF (AI1.EQ.DELZ.OR.AI1.EQ.0.) GO TO 70
IF (ABS(AH1).EQ.AES(AI1).AND.AES(AH1).LT.ABS(AG1)) I=6
IF (I.NE.6) GO TO 70
VDOT=1.02*VDOT
WDOT=1.02*WDOT
CONTINUE
70 CALL SBLCAL
CALL THUST
IF (AN.GE.ANMAX.OR.FWDACC.GZ.THMAX) GO TO 80
GO TO 10
CONTINUE
80 IF (AN.GT.ANMAX) AN=ANMAX
IF (FWDACC.GT.THMAX) FWDACC=THMAX
RETURN
END

```

```

C*****
C SUBROUTINE REDUCR
C      REDUCR IS CALL FROM ACLNTS AND REDUCES THE "NEW"
C      VELOCITY AND ULTIMATELY POSITION TO GET LOADS
C      ON THE AIRCRAFT WITHIN LIMITS.
C*****
SUBROUTINE REDUCR
COMMON /ABC3/ VELCN,VELOT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1VNEW,VTEMP,WOLD
COMMON /ABC4/ AG1,AH1,AI1,AJ1,AJ2
COMMON /AED2/ VSTALL,VMAX,VMAX1,VMAX2,DELTEE,DELTV,DELTZ
COMMON /AEE3/ AX,AY,AZ
COMMON /AEE4/ THEAX,ANMAX,CLMAX,GEE,TO,RHOSSL,WL,CDO,CDK,AREA,DTDH
COMMON /AEE5/ FWEACC,AN,MCONT
COMMON /LCC/ X1,Y1,Z1,V1,ITS,LTR2
MCCNT=1
CONTINUE
10 VELON=VELCN-DELTV
   A=VSTALL+2.*DELTV
   IF (VELON-GE-A) GO TO 20
   ANG=ACOS(AG1/AJ2)
   AJ2=1.1*AJ2
   AG1=COS(ANG)*AJ2
   AH1=SIN(ANG)*AJ2
   VELON=V1
20 CONTINUE
   N=0
   CALL MVELCS
   CALL MVDCTS
   CALL SMLCAL
   CALL THRUST
   IF (AN.LE.ANMAX.AND.FWDACC.LE.THEAX) GO TO 30
   GO TO 10
30 CONTINUE
   RETURN
   END

```

```

C*****
C SUBROUTINE SMLCAL (SMALL CALL) IS A SMALLER VERSION OF (BIG CALL) AND
C USED IN THE ITERATIVE LCOES OF (AIRCRAFT LIMITATIONS)
C*****
C SUBROUTINE SMLCAL
C CALL MVDOTS
C CALL DELVEC
C CALL TMPENT
C CALL TMPVEL
C CALL INETRM
C CALL ANGLES
C CALL ROTBAT
C CALL ACTRM1
C CALL ACTRM2
C CALL ACTRM3
C CALL ACRVEL
C CALL ACACC
C RETURN
C END

```

```

C*****
C SUBROUTINE THRUST THRUST IS USED BY (AIRCRAFT LIMITATIONS) TO COMPUTE
C THE AVAILABLE FORWARD ACCELERATION BASED UPON THRUST
C DRAG, G-LOADING, POSITION IN SPACE AND GRAVITY.
C*****
C SUBROUTINE THRUST
C COMMON /ABC2/ XNEW,DELX,XTEMP,ACLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
C ZTEMP,ZOLD
C COMMON /ABC3/ VELCN,VELCT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
C WNEW,WTEMP,WOLD
C COMMON /ABC4/ PSINew,THENew,PHINew,PSIOld,THEOld,PHIOld
C COMMON /AEE3/ AX,AY,AZ
C COMMON /AEE4/ THMAX,AMAX,SLMAX,GEE,IC,SHOSSL,WL,CDO,CBK,AREA,DTDH
C COMMON /AEE5/ FWDACC,AN,MCONT
C ANG=THENew
C THROD=AX/GEE
C AN=SQRT(AY**2+AZ**2)/GEE
C SIGMA=(1+ICDH*ZTEMP/IC)**4.257
C RHOALT=RHOSSL*SIGMA
C CL=(2.*AN*WL)/(RHOALT*VELCT**2)
C DRAG=AN*((CDO+CBK*CL**2)/CL)
C FWDACC=SIN(ANG)*THROD+DRAG
C RETURN
C END

```

```

C*****
C SUBROUTINE XCNGE
C      ONCE THE EQUATIONS OF MOTION ARE SATISFIED AT THE
C      PREVIOUS LOCATION (TEMP) THE TEMP LOCATION BECOMES
C      THE CURRENT LOCATION (OLD).
C*****
SUBROUTINE XCNGE
COMMON /AEC2/ XNEW,DELX,XTEMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1ZTEMP,ZOLD
COMMON /AEC3/ VELCN,VELOT,VELCC,N,JNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1VNEW,VTEMP,VOLD
COMMON /AED4/ PSINew,THENew,PHINew,PSIOld,THEOld,PHIOld
XOLD=XTEMP
YOLD=YTEMP
ZOLD=ZTEMP
UOLD=UTEMP
VOLD=VTEMP
WOLD=WTEMP
PSIOld=PSINew
THEOld=THENew
PHIOld=PHINew
VELO=VELCT
RETURN
END

```

```

C*****
C SUBROUTINE WAYPNT
C      THE RELEVANT PARAMETERS FOR THE CURRENT POINT ARE
C      ASSIGNED.
C*****
SUBROUTINE WAYPNT
COMMON /AEC1/ WX(1000),WY(1000),WZ(1000),WG(1000),WV(1000),WW(1000)
1,WH(1000),WP(1000),WS(1000),WG(1000),I(1000),ICT
COMMON /AEC2/ XNEW,DELX,XTEMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1ZTEMP,ZOLD
COMMON /AEC3/ VELCN,VELOT,VELCC,N,JNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1VNEW,VTEMP,VOLD
COMMON /AED2/ VSTALL,VMAX,VMAX1,VMAX2,DELTEE,DELTU,DELTAZ
COMMON /AED4/ PSINew,THENew,PHINew,PSIOld,THEOld,PHIOld
COMMON /AEE5/ FRLACC,AN,MCONT
WX(ICT)=XOLD
WY(ICT)=YOLD
WZ(ICT)=ZOLD
WG(ICT)=UOLD
WV(ICT)=VOLD
WW(ICT)=WOLD
WH(ICT)=PSINew
WP(ICT)=THENew
WS(ICT)=PHINew
WG(ICT)=AN
T(ICT)=T(ICT-1)+DELTEE
RETURN
END

```

```

C*****
C SUBROUTINE FILE
C THE CURRENT POINT IS IMMEDIATELY SAVED.
C*****
SUBROUTINE FILE
COMMON /ABC1/ WX(1000), WY(1000), WZ(1000), WU(1000), WV(1000), WW(1000)
1) ,WH(1000), WP(1000), WR(1000), WG(1000), T(1000), ICT
COMMON /ABC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1) ZTEMP, ZOLD
COMMON /ICC/ X1, Y1, Z1, V1, LTR, LTR2
IF (XOLD.NE.XNEW.OR.YOLD.NE.YNEW.OR.ZOLD.NE.ZNEW) GO TO 10
WRITE (11,20) T(ICT), WX(ICT), WY(ICT), WZ(ICT), WU(ICT), WV(ICT), WW(ICT)
1) ,WH(ICT), WP(ICT), WR(ICT), WG(ICT), LTR
RETURN
10 CONTINUE
LTR=0
WRITE (11,20) T(ICT), WX(ICT), WY(ICT), WZ(ICT), WU(ICT), WV(ICT), WW(ICT)
1) ,WH(ICT), WP(ICT), WR(ICT), WG(ICT), LTR
RETURN
20 FORMAT (11(210.4,1X),I3)
END

```

```

C*****
C SUBROUTINE GRAFIX
C THE CURRENT POINT ALONG THE TRAJECTORY TO THE
C DESIRED WAYPOINT IS PLOTTED.
C*****
SUBROUTINE GRAFIX
COMMON /ABC1/ WX(1000), WY(1000), WZ(1000), WU(1000), WV(1000), WW(1000)
1) ,WH(1000), WP(1000), WR(1000), WG(1000), T(1000), ICT
COMMON /MN1/ MINX, MAXX, MINY, MAXY, MINX1, MAXX1, MINX2, MAXX2
PX1=WX(ICT-1)
PX2=WX(ICT)
PY1=WY(ICT-1)
PY2=WY(ICT)
EZ=1.0
CALL MIN (MINX, MAXX, 18000., 12000., 0)
CALL GBVECT (0., PX1, PY1)
CALL GBVECT (1., PX2, PY2)
CALL GSFECE
RETURN
END

```

```

C*****
C SUBROUTINE ERRCHK
C      ERRCHK CHECKS THE DESIRED WAYPOINT AGAINST GAME
C      LIMITATIONS. WHENEVER POSSIBLE, CORRECTIONS ARE
C      AUTOMATIC.
C*****
      SUBROUTINE ERRCHK (IERR)
      COMMON /LOC/ X1,Y1,Z1,V1, LTR,LTR2
      COMMON /PAR/ APPMAX,HTMIN,HTMAX,POPMIN,BAAAT,BRMIN,BRMAX,BRMIN,B
1 BRMAX,RTD,AMTF
      COMMON /TAR/ TARGX,TARGY
      COMMON /ABC1/ WX(1000),WY(1000),WZ(1000),WU(1000),WV(1000),WW(1000
1),WH(1000),WP(1000),WR(1000),WG(1000),I(1000),ICT
      DX=TARGX-X1
      DY=TARGY-Y1
      DIST=SQRT(DX**2+DY**2)
      IF (DIST.LE.PCFMIN) GO TO 10
      IF (Z1.GT.APPMAX) Z1=APPMAX
      IF (Z1.LT.HTMIN) Z1=HTMIN
10      CONTINUE
      IF (LTR.NE.65.OR.LTR2.NE.65) GO TO 20
      IF (Z1.LT.BAAAT) Z1=BAAAT
20      CONTINUE
      IF (LTR.NE.66.OR.LTR2.NE.66) GO TO 60
      IF (Z1.LT.BRMIN) Z1=BRMIN
      IF (Z1.GT.BRMAX) Z1=BRMAX
      IF (DIST.LE.BRMAX.AND.DIST.GE.BRMIN) GO TO 30
      IF (DIST.GT.BRMAX) IERR=9
      IF (DIST.LT.BRMIN) IERR=13
      RETURN
30      CONTINUE
      TGTHDG=ATAN2(DY,DX)*RTD
      IF (TGTHDG.LT.0.) TGTHDG=TGTHDG+360.
      DX=X1-WX(ICT)
      DY=Y1-WY(ICT)
      ACHDG=ATAN2(DY,DX)*RTD
      IF (ACHDG.LT.0.) ACHDG=ACHDG+360.
      HGLMT=ABS(TGTHDG-ACHDG)
      IF (HGLMT.LT.5.) GO TO 40
      IERR=10
      RETURN
40      CONTINUE
      DIST=SQRT(DX**2+DY**2)
      SPEED=SQRT(WU(ICT)**2+WV(ICT)**2+WW(ICT)**2)
      DT=DIST/SPEED
      IF (DT.GE.2.33) GO TO 50
      IERR=11
      RETURN
50      CONTINUE
60      CONTINUE
      RETURN
      END

```

```

C*****
C SUBROUTINE AIMPT THIS SUBROUTINE MARKS A LINE FROM THE CURRENT
C AIRCRAFT POSITION TO THE TARGET AS A USER AID IN
C ALIGNING BOMB RELEASE POINT.
C*****
SUBROUTINE AIMPT
COMMON /AEC1/ *X(1000),*Y(1000),*Z(1000),*U(1000),*V(1000),*W(1000)
1) *H(1000),*P(1000),*R(1000),*G(1000),*I(1000),*CT
COMMON /TAR/ TARGX,TARGY
REAL*4 TX,TY,TX1,TY1
CALL WIN (MINX,MAXX,18000.,12000.,3)
TX=*X(ICI)
TY=*Y(ICI)
TX1=TARGX
TY1=TARGY
CALL GSLE (1)
-----
C MCVE AND DRAW DASHED LINE TO CURRENT WAYPT COORDINATES
C-----
CALL GBVECT (0.,TX,TY)
CALL GBVECT (1.,TX1,TY1)
CALL GSLE (0)
CALL GSFRCE
RETURN
END

```

```

C*****
C SUBROUTINE ELFIN
C      THIS SUBROUTINE REQUESTS THE USER OPTIONS AND CLOSES
C      THE GRAPHIC SUBROUTINES.
C*****
      SUBROUTINE ELFIN (LAST)
      COMMON /CFT/ IGUN,IPNCH,IEXT,ISAM,IMP,KEB,IMPZ
      COMMON /MNT/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
C-----
C CLOSE GRAPHICS ROUTINES
C-----
      CALL DSTERN
      IF (LAST.EQ.0) GO TO 20
      CONTINUE
      WRITE (6,40)
      READ (5,4) FIN
      CALL PRTCHS ('CLASCSN ')
      IF (FIN.GT.2.OB.FIN.LT.1) GO TO 10
20     CONTINUE
      WRITE (6,50)
      WRITE (6,60)
      READ (5,4) IPNCH
      CALL PRTCHS ('CLASCSN ')
      IF (IPNCH.EQ.3) RETURN
      IF (IPNCH.EQ.2) GO TO 30
      WRITE (6,70)
      READ (5,4) IEXT
      CALL PRTCHS ('CLASCSN ')
      IF (IPNCH.EQ.1) RETURN
30     CONTINUE
      WRITE (6,80)
      READ (5,4) ISAM
      CALL PRTCHS ('CLASCSN ')
      IF (ISAM.LT.1.OR.ISAM.GT.7) GO TO 30
      RETURN
40     FORMAT (51H ARE YOU FINISHED WITH THIS FLIGHTPATH: 0=NO; 1=YES)
50     FORMAT (43H OUTPUT FILE: 0=NO OUTPUT; 1=FOOT FILE ONLY)
60     FORMAT (51H 2=HICE FILE ONLY; 3=POJ1 & HICE FILES)
70     FORMAT (49H EXTENDED OUTPUT: 0=NOT WANTED; 1=EXTENDED OUTPUT)
80     FORMAT (29H MISSILE TYPE BETWEEN 1 AND 7)
      END

```



```

C*****
C SUBROUTINE PRESET
C      THIS SUBROUTINE WRITES THE POOI AND MICE II FILES
C      FOR THE USER.
C*****
C SUBROUTINE PRESET
COMMON /ABC1/ FX(1000), FY(1000), WZ(1000), WU(1000), WV(1000), WW(1000)
1) ,XH(1000), XZ(1000), XR(1000), XG(1000), I(1000), IC(1000)
COMMON /PAR2/ XGUN(7), YGUN(7), ZGUN(7), XSAM, YSAM, ZSAM, XJR(7)
COMMON /PAR4/ AFEMAX, HTMIN, HTMAX, FOPMIN, FAALT, SRMIN, SRMAX, BRBRMIN, B
1 BRMAX, STE, AMTF
COMMON /OPT/ IGUN, IENCH, IEXT, ISAM, IPE, KER, IMPZ
COMMON /NAM/ INA1(2), INA2(2), IUSR, IANR, IDEST
DIMENSION X10(200), Y10(200), V1(200)
DIMENSION RCSTAB(1000), TINK(10)
DIMENSION VAT1N2(200), VAT3(200), VAT5(200)

C-----
C VULNERABLE AREA TABLE VS TYPE 1 AND 2 WEAPONS
C-----
DATA VAT1N2/2*.4645,6*7.107,2*.6568,6*5.551,2*.6968,6*5.574,2*.656
18*.67,357,2*.6968,6*5.574,2*.6568,6*5.551,2*.6968,6*5.574,2*.656
26*.7357,2*.6968,6*5.574,2*.4645,6*7.107,2*.6568,6*5.551,2*.6968,6*5.574,2*.656
33*.298,2*.6568,6*2.858,2*.4645,6*7.107,2*.6568,6*5.551,2*.6968,6*5.574,2*.656
4298,2*.6568,6*2.858,2*.6568,6*5.551,2*.6968,6*5.574,2*.6568,6*7.35
57,2*.6968,6*5.574,2*.6568,6*5.551,2*.6968,6*5.574,2*.6568,6*7.357,
62*.6968,6*5.574,2*.4645,6*7.107/

C-----
C VULNERABLE AREA TABLE VS TYPE 3 WEAPONS
C-----
DATA VAT3/2*12.54,6*13.47,2*9.653,6*10.51,2*9.639,6*11.15,2*12.64,
16*14.79,2*9.639,6*11.15,2*9.653,6*10.51,2*9.639,6*11.15,2*12.64,6*
214.78,2*9.639,6*11.15,6*1.394,2*4.762,6*6.240,2*5.342,6*7.432,2*4.
3762,6*6.240,3*1.394,6*4.762,6*6.240,2*5.342,6*7.432,2*4.762,6*6.24
40*9.639,6*10.51,2*9.639,6*11.15,2*12.64,6*14.78,2*9.639,6*11.15,2*
52*9.653,6*10.51,2*9.639,6*11.15,2*12.64,6*14.78,2*9.639,6*11.15,2*
612.54,6*13.47/

C-----
C VULNERABLE AREA TABLE VS TYPE 5 WEAPONS
C-----
DATA VAT5/8*55.37,8*43.22,8*47.10,8*62.53,3*47.10,3*43.22,8*47.10,
18*62.53,8*47.10,3*5.761,3*27.45,8*33.07,3*27.45,8*5.761,3*27.45,8*
233.07,8*27.45,8*5.761,6*47.10,6*62.53,8*47.10,8*43.22,8*47.10,8*62
3.53,8*47.10,8*55.37/

C-----
C RADAR CROSS SECTION TABLE
C-----
DATA RCSTAB/19*1000.,19*100.,19*10.,19*10.,19*10.,19*100.,19*1000.
1,867*0.0/

C-----
C CALL ERRSET SUPPRESSES ANY POSSIBLE UNDERFLOW PROBLEMS THAT MAY
C RESULT FROM MANIPULATION OF SCENARIO PARAMETERS.
C-----
CALL ERRSET (200,50,-1,1,1)
JAM=0

C-----
C CARD 2 TIME INCREMENT CALCULATION
C-----
TINC=T(ICI)/1000.+C.0008

C-----
C CARD 6 TIME INCREMENT CALCULATIONS
C-----
TINKI=0
DO 10 I=1,9
TINK(I)=TINKI+T(ICT)/10
TINKI=TINK(I)
10 CONTINUE

C-----
C FOLLOWING GENERATES VELOCITY MAGNITUDE AT EACH POINT
C-----
DO 20 I=1,ICT
VEL(I)=SQRT(WU(I)**2+WV(I)**2+WW(I)**2)
20 CONTINUE

C-----
C *****PUNCH PROGRAM*****
C-----

```

```

C OPTION TO PUNCH THE P001 CARD DECK OR MICE-II CARD DECK
C-----
C IF (IPNCH.EQ.2) GC TC 40
C-----
C COMMENCE PUNCHED OUTPUT OF THE P001 CARD DECK.
C-----
C THE JCL CARDS.
C-----
C WRITE (18,70) INAM1(1),INAM1(2),IUNR,IAGB,INAM1(1),INAM1(2),IUNR
C IF (IDEST.EQ.2) WRITE (18,30) IUNR
C WRITE (18,90)
C WRITE (18,100)
C WRITE (18,110)
C WRITE (18,120)
C WRITE (18,130)
C WRITE (18,140)
C WRITE (18,150)
C WRITE (18,160)
C WRITE (18,170)
C-----
C LEADING BLANK DATA CARD SIGNIFIES RADAR MASKING ANGLE OF ZERO.
C-----
C THE OUTPUT TITLE CARD.
C-----
C WRITE (18,200)
C-----
C CARD 2
C-----
C WRITE (18,180)
C WRITE (18,210) 1(ICT),TINC
C-----
C THE 2A CARDS (MILESTONES).
C-----
C DO 30 I=1,ICT
C WU(I)=WU(I)*AMTF
C WV(I)=WV(I)*AMTF
C WW(I)=WW(I)*AMTF
C WRITE (18,220) T(I),WX(I),WY(I),WZ(I),WU(I),WV(I),WW(I),WH(I),WF(I)
C 1),WR(I)
C 30 CONTINUE
C-----
C CARD 3 (GUN EMPLACEMENT CARD).
C-----
C WRITE (18,240)
C WRITE (18,250) XGUN(1),YGUN(1),ZGUN(1)
C-----
C CARD 4 (GUN TYPE).
C-----
C WRITE (18,230)
C WRITE (18,260)
C-----
C CARD 5
C-----
C WRITE (18,190)
C WRITE (18,270)
C-----
C CARD 6
C-----
C WRITE (18,280)
C WRITE (18,290) (TINK(I),I=1,9)
C-----
C CARD 7 (VULNERABLE AREA TABLZ VS TYPE 1 AND 2 WEAPONS)
C-----
C WRITE (18,300)
C WRITE (18,310)
C WRITE (18,320) (VAT1N2(I),I=1,208)
C-----
C CARD 12 (EXECUTE RUN):
C EXTENDED OUTPUT OPTION
C-----
C WRITE (18,330)
C IF (ISXT.EQ.1) WRITE (13,350)
C IF (ISXT.EQ.1) WRITE (18,340)
C-----

```

C THE REMAINDER OF THE CARDS INTRODUCE NEW GUN LOCATIONS, GUN TYPES
C AND VULNERABLE AREA TABLES TO BE EXECUTED BY THE PROGRAM.

WRITE (18,240)
WRITE (18,250) XGUN (2), YGUN (2), ZGUN (2)

C EXTENDED OUTPUT OPTION

WRITE (18,330)
IF (TEXT.NE.1) WRITE (18,350)
IF (TEXT.EQ.1) WRITE (18,340)
WRITE (18,240)
WRITE (18,250) XGUN (3), YGUN (3), ZGUN (3)
WRITE (18,230)
WRITE (18,360)

C EXTENDED OUTPUT OPTION

WRITE (18,330)
IF (TEXT.NE.1) WRITE (18,350)
IF (TEXT.EQ.1) WRITE (18,340)
WRITE (18,240)
WRITE (18,250) XGUN (4), YGUN (4), ZGUN (4)

C EXTENDED OUTPUT OPTION

WRITE (18,330)
IF (TEXT.NE.1) WRITE (18,350)
IF (TEXT.EQ.1) WRITE (18,340)
WRITE (18,240)
WRITE (18,250) XGUN (5), YGUN (5), ZGUN (5)
WRITE (18,230)
WRITE (18,370)

C CARD 7 (VULNERABLE AREA TABLE VS TYPE 3 WEAPONS)

WRITE (18,300)
WRITE (18,410)
WRITE (18,320) (VAT3(I), I=1, 200)

C EXTENDED OUTPUT OPTION

WRITE (18,330)
IF (TEXT.NE.1) WRITE (18,350)
IF (TEXT.EQ.1) WRITE (18,340)
WRITE (18,240)
WRITE (18,250) XGUN (6), YGUN (6), ZGUN (6)
WRITE (18,230)
WRITE (18,380)

C EXTENDED OUTPUT OPTION

WRITE (18,330)
IF (TEXT.NE.1) WRITE (18,350)
IF (TEXT.EQ.1) WRITE (18,340)
WRITE (18,240)
WRITE (18,250) XGUN (7), YGUN (7), ZGUN (7)
WRITE (18,230)
WRITE (18,390)

C CARD 7 (VULNERABLE AREA TABLE VS TYPE 5 WEAPON)

WRITE (18,300)
WRITE (18,420)
WRITE (18,320) (VAT5(I), I=1, 200)

C EXTENDED OUTPUT OPTION

WRITE (18,330)
IF (TEXT.NE.1) WRITE (18,350)
IF (TEXT.EQ.1) WRITE (18,340)
WRITE (18,400)
IF (IPNCB.EQ. 1) RETURN

C FORMAT STATEMENTS

```

40 CONTINUE
C-----
C COMMENCE PUNCHED OUTPUT OF THE MICE-II CARD DECK
C-----
C CHECK FOR VALID MISSILE DESIGNATION NUMBER FOR MICE II
C-----
IF (ISAM.LE.7.AND.ISAM.GE.1) GO TO 50
RETURN
C-----
C THE JCL CARDS
C-----
50 WRITE (17,430) ISAM2(1),INAM2(2),IUNR,IANR,INAM2(1),INAM2(2),IUNR
IF (IDEST.EQ.2) WRITE (17,440) IUNR
WRITE (17,450)
WRITE (17,460)
WRITE (17,470)
WRITE (17,480)
C-----
C THE OUTPUT TITLE CARDS
C-----
WRITE (17,490)
WRITE (17,500)
C-----
C THE PROBLEM RUN INPUT CARDS, CHECKING FOR TYPE OF MISSILE
C-----
IF (ISAM.EQ.1) WRITE (17,510)
IF (ISAM.EQ.2) WRITE (17,560)
IF (ISAM.EQ.3) WRITE (17,590)
IF (ISAM.EQ.4) WRITE (17,700)
IF (ISAM.EQ.5) WRITE (17,710)
IF (ISAM.EQ.6) WRITE (17,720)
IF (ISAM.EQ.7) WRITE (17,730)
C-----
C THE PSSK CALCULATION CARDS
C-----
WRITE (17,520)
WRITE (17,530)
C-----
C THE RADAR CROSS SECTION TABLE
C-----
WRITE (17,540)
WRITE (17,550)
WRITE (17,560)
WRITE (17,570)
WRITE (17,580) (RCSTAB(I),I=1,133)
C-----
C THE SIMULATION TIME PARAMETERS
C-----
WRITE (17,590)
WRITE (17,600)
C-----
C THE MISSILE LAUNCHER LOCATION
C-----
WRITE (17,610)
IFSAM=XSAM*AMTF
YFSAM=YSAM*AMTF
ZFSAM=ZSAM*AMTF
WRITE (17,620) IFSAM,YFSAM,ZFSAM
C-----
C THE TARGET TRAJECTORY
C-----
WRITE (17,630)
WRITE (17,640) ICT
C-----
C THE MILESTONE CARDS
C-----
DO 60 I=1,ICT
WX(I)=WX(I)*AMTF
WY(I)=WY(I)*AMTF
WZ(I)=WZ(I)*AMTF
VEL(I)=VEL(I)*AMTF
WRITE (17,650) I(I),WX(I),WY(I),WZ(I),VEL(I),WP(I),WR(I),WH(I)
60 CONTINUE

```

```

C-----
C  END OF PUNCHED CARDS
C-----
      WRITE (17,660)
      WRITE (17,670)
C-----
      RETURN
C-----
C  /////***** FCHEAT STATEMENTS *****/////
C-----
70  FORMAT (2H//,2A4,6H JOB (,I4,1H, I4,2H) , ,1H',2A4,1H ,I4,2HP')
80  FORMAT (19H// *MAIN CRG=PGVM1.,I4,1HF)
90  FORMAT (16H// EXEC PGM=PIAD)
100 FORMAT (42H// STEPLIB DD DISP=SHR,DSN=MSS.F0559.2IPSAV)
110 FORMAT (47H// GC.FTC7F001 DD UNIT=SYSDA,SPACE=(CYL,(1,1)),)
120 FORMAT (41H// LCE=RECFM=VBS,RECL=404,BLASIZE=3230))
130 FORMAT (22H// GO.FTC9F001 DD DUMHY)
140 FORMAT (25H// GC.FTC6F001 DD SYSCUT=A)
150 FORMAT (18H// GC.FTC5F001 DD *)
160 FORMAT (11H1,1,0,0,J,J)
170 FORMAT (2H01)
180 FORMAT (2H02)
190 FORMAT (2H05)
200 FORMAT (42H AIRCRAFT COMBAT SURVIVABILITY SCENARIO)
210 FORMAT (7H0,12,0,,F7.2,9H,100000,,F7.4,1H/)
220 FORMAT (10(F7.1,1X))
230 FORMAT (2H04)
240 FORMAT (2H03)
250 FORMAT (3(1X,F7.0),1CH 0.2,360.0)
260 FORMAT (19H0,1,1,1,1,1,J,0,50.)
270 FORMAT (7H1,1,1,J)
280 FORMAT (2H06)
290 FORMAT (3H1,3,9(1X,F7.3))
300 FORMAT (2H07)
310 FORMAT (49H VULNERABLE AREA TABLE VS TYPE 1 AND 2 WEAPONS)
320 FORMAT (8F8.3)
330 FORMAT (2H12)
340 FORMAT (13H1,1,1,1,1,1,1,1)
350 FORMAT (13H0,0,0,0,1,1,1,1)
360 FORMAT (20H0,2,1,1,1,1,1,0,50.0)
370 FORMAT (20H0,3,4,4,1,1,1,0,50.0)
380 FORMAT (20H0,3,3,1,1,1,0,50.0)
390 FORMAT (20H0,5,3,2,1,1,0,50.0)
400 FORMAT (2H/*)
410 FORMAT (42H VULNERABLE AREA TABLE VS TYPE 3 WEAPONS)
420 FORMAT (42H VULNERABLE AREA TABLE VS TYPE 5 WEAPONS)
430 FORMAT (2H//,2A4,6H JOB (,I4,1H, I4,2H) , ,1H',2A4,1H ,I4,2HP')
440 FORMAT (19H// *MAIN CRG=PGVM1.,I4,1HF)
450 FORMAT (28H// EXEC PGM=4ICE,REGION=180K1)
460 FORMAT (44H// STEPLIB DD DSN=MSS.F0559.2ICESAV,DISP=SHR )
470 FORMAT (23H// FTC6F001 DD SYSCUT=A)
480 FORMAT (15H// FTC5F001 DD *)
490 FORMAT (2H01)
500 FORMAT (53H02 3251 *****SURVIVABILITY SCENARIO***** SAM ENCOUNTER)
510 FORMAT (2H02)
520 FORMAT (2H06)
530 FORMAT (9X,1H0,8X,2H0.,9X,1H0,4X,1H0,4X,1H0,3X,2H0.,8X,2H0.)
540 FORMAT (2H08)
550 FORMAT (7X,3H23.,3X,2H19,4X,1H7,4X,1H1)
560 FORMAT (8X,2H0.,7X,3H10.,7X,3H20.,7X,3H30.,7X,3H40.,7X,3H50.,7X,3H
160.1,7X,3H70.,7X,3H80.,7X,3H90.,8X,4H100.,8X,4H110.,5X,4H120.,6X,
24H130.,6X,4H140.,6X,4H150.,8X,3H160,6X,4H170.,8X,4H180.)
570 FORMAT (6X,4H-90.,8X,4H-60.,6X,4H-30.,8X,2H0.,7X,3H30.,7X,3H60.,7X
1,3H90.)
580 FORMAT (7F10.2,/,7F10.2,/,5F10.2)
590 FORMAT (2H09)
600 FORMAT (7X,3H0.5,7X,3H0.1,7X,3H8.0,7X,3H0.0,8X,2H0.,7X,3H30.,8X,2H
10.)
610 FORMAT (2H11)
620 FORMAT (2X,2F10.2,2F10.2)
630 FORMAT (2H12)
640 FORMAT (9X,1H1,2X,1,4X,1H1,4X,1H0,8X,2H0.,8X,2H0.,3X,2H0.)
650 FORMAT (F7.1,4F10.1,3F6.1,4X,2H0.,4X,2H0.)
660 FORMAT (2H20)
670 FORMAT (2H/*)
680 FORMAT (9X,1H1,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H0)

```

```

690  FORMAT (9X,1H2,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H3)
700  FORMAT (9X,1H3,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H3)
710  FORMAT (9X,1H4,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H3)
720  FORMAT (9X,1H5,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H3)
730  FORMAT (9X,1H6,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H3)
740  FORMAT (9X,1H7,4X,1H1,4X,1H4,4X,1H1,3X,2H10,4X,1H1,4X,1H3)
      END

```


C MAXIMUM THRUST OF THE AIRCRAFT (DIMENSIONLESS)
C DATA THMAX/0.40/
C MAXIMUM AIRCRAFT GEE-LOADING (DIMENSIONLESS)
C DATA ANMAX/6./
C RHOSL IS THE DENSITY AT STANDARD SEA-LEVEL CONDITIONS. IT HAS
C DIMENSIONS OF (N.S2/M4)
C DATA RHOSL/1.225/
C STANDARD SEA-LEVEL TEMPERATURE (DEGREES K)
C DATA TO/288.16/
C TEMPERATURE LAPSE RATE FOR THE TROPOSPHERE (DEG K/M)
C DATA DTDR/-0.5E-3/
C MAXIMUM WING LOADING (N/M2)
C DATA WL/4789./
C SPEED BRAKE AREA: DEFINED AS A PERCENTAGE OF TOTAL WING AREA
C DATA AREA/.05/
C MAXIMUM COEFFICIENT OF LIFT
C DATA CLMAX/1./
C COEFFICIENT OF DRAG AT ZERO ANGLE OF ATTACK
C DATA CD0/.015/
C PROFILE DRAG COEFFICIENT
C DATA CDK/0.1/
C MINIMUM ALTITUDE FOR THE GAME (M)
C DATA HTMIN/60./
C MAXIMUM ALTITUDE APPROACHING THE TARGET (M)
C DATA APPMAX/457./
C MAXIMUM ALTITUDE AFTER ENTERING POP-UP RANGE OF 6 KM. (M)
C DATA HTHAX/2050./
C MAXIMUM RANGE (METERS) A POP-UP MAY BE COMMENCED
C DATA PCPMIN/6000./
C MINIMUM ALLOWABLE POP-UP ALTITUDE (M)
C DATA BAALT/1000./
C BOMB RELEASE MAXIMUM ALTITUDE (M)
C DATA BRMAX/2000./
C BOMB RELEASE MINIMUM ALTITUDE (M)
C DATA BRMIN/100./
C MAXIMUM BOMB RELEASE RANGE (M)
C DATA BRMAX/1000./
C MINIMUM BOMB RELEASE RANGE (M)
C DATA BRMIN/100./


```

C-----
C MAXIMUM VELOCITIES BEFORE AND AFTER BOMB RELEASE (M/S)
C-----
C DATA VMAX1/260./,VMAX2/310./
C-----
C STALL VELOCITY (M/S)
C-----
C DATA VSTALL/90./
C-----
C INCREMENT OF VELOCITY CHANGE (5 KNCT INC CONVERTED TO M/S)
C-----
C DATA DELTV/3./
C-----
C THE FOLLOWING ARE TEMPORARY PARAMETERS FOR THE INITIAL CONDITIONS OF
C THE AIRCRAFT. LATER THIS WILL BE ENTERED INTERACTIVELY.
C-----
C DATA WX/0./,WY/6000./,WZ/200./,WD/200./,WV/0./,WW/0./
C DATA WH/1.5708./,WF/0./,WE/0./,WG/0./,1/0./
C-----
C INCREMENT OF TIME CHANGE (SECONDS)
C-----
C DATA DELTEE/1.00/
C-----
C INCREMENT OF ALTITUDE CHANGE (50 FT INC CONVERTED TO METERS)
C-----
C DATA DELTAZ/15.24/
C-----
C TEMPORARY PROGRAM INITIALIZATION
C-----
C DATA XOLD/0./,YOLD/6000./,ZOLD/200./
C DATA UOLD/200./,VOLD/0./,WOLD/0./
C DATA PSICLD/0./,PEOLD/0./,PHICLD/0./
C DATA VELCG/200./
C-----
C ENC

```

APPENDIX H

FLIGHTPATH GENERATOR WITHOUT THE GRAPHICS

```

C*****
C SUBROUTINE BIGCAL 16MAR84
C T11 IS SET UP AS A TROUBLE-SHOOTING CONVENIENCE.
C IT IS THE FLIGHTPATH GENERATOR PULLED FROM IBMPIP2.
C WHEN IN USE, EACH SUBROUTINE HAD A WRITE-TO-FILE
C STATEMENT IN IT FOR OBSERVATION PURPOSES.
C CHANGES AND COMMENTS ARE CURRENT THROUGH 16MAR84.
C *****
C THIS SUBROUTINE OPERATES AT A LEVEL BELOW MAIN
C PROGRAM AND ACTS AS A DRIVER FOR THE SUBROUTINES
C LISTED WITHIN.
C *****
SUBROUTINE BIGCAL
COMMON /ABC1/ WX(1000), WY(1000), WZ(1000), WU(1000), WV(1000), W(1000)
1) WH(1000), AR(1000), AG(1000), I(1000), ICT
COMMON /ABC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1) ZTEMP, ZOLD
COMMON /ABC3/ VELCN, VELOT, VELCC, N, UNEW, UTEMP, UOLD, VNEW, VTEMP, VOLD,
1) VNEW, VTEMP, VOLD
COMMON /ABC4/ AG1, AH1, AI1, AJ1, AJ2
COMMON /ABC5/ VSTALL, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTZ
COMMON /ABC6/ FWLACC, AN, MCONT
N=0
ICT=2
MCONT=0
10 CALL TENFRM
CALL NEWOLD
CALL MVELCS
CALL MVDCTS
CALL DELVEC
CALL TMPENT
CALL FMEVEL
CALL INETRM
CALL ANGLES
CALL ROT3AT
CALL ACTSM1
CALL ACTSM2
CALL ACTSM3
CALL ACTVEL
CALL ACACC
CALL ACLMIS
CALL XCHNGE
CALL WAYENT
CALL FILE
ICT=ICT+1
IF (ABS(UTEMP).GT.ABS(VTEMP).AND.DELX.EQ.AG1) GO TO 20
IF (ABS(VTEMP).GT.ABS(UTEMP).AND.DELY.EQ.AH1) GO TO 20
GO TO 10
CONTINUE
RETURN
STOP
END

```

```

C*****
C SUBROUTINE TRNFRM TRANSFORM TAKES THE REAL VALUE VARIABLES SUPPLIED
C BY THE GRAPHICS SUBROUTINES AND LOADS THEM INTO
C VARIABLES SPECIFIC TO THIS AIRCRAFT TRAJECTORY
C GENERATING PACKAGE.
C*****
SUBROUTINE TRNFRM
COMMON /LCC/ A1,Y1,Z1,V1,ITS,ITS2
COMMON /AEC2/ XNEW,DELY,XTEMP,XCLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1ZTEMP,ZOLD
COMMON /AEC3/ VELCN,VELOT,VELOC,N,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1VNEW,VTEMP,VCLD
COMMON /AEE5/ FDEACC,AN,MCONT
XNEW=X1
YNEW=Y1
ZNEW=Z1
VELCN=V1
RETURN
END

```

```

C*****
C SUBROUTINE NEWOLD NEWOLD GENERATES LENGTH VECTOR COMPONENTS BETWEEN
C THE CURRENT WAYPOINT (OLD) AND THE DESIRED WAYPOINT
C USER HAS JUST ENTERED (NEW).
C*****
SUBROUTINE NEWOLD
COMMON /AEC2/ XNEW,DELY,XTEMP,XCLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1ZTEMP,ZOLD
COMMON /AEC4/ AG1,AH1,AI1,AJ1,AJ2
COMMON /AEE5/ FDEACC,AN,MCONT
AG1=XNEW-XOLD
AH1=YNEW-YOLD
AI1=ZNEW-ZOLD
AJ1=SQRT(AG1**2+AH1**2+AI1**2)
AJ2=SQRT(AG1**2+AH1**2)
RETURN
END

```

```

C*****
C SUBROUTINE MVELOCS
C MVELOCS (MAP VELOCITY COMPONENTS) DETERMINES THE
C VELOCITY COMPONENTS BETWEEN CURRENT WAYPOINT (OLD)
C AND THE JUST ENTERED WAYPOINT (NEW). THE SUBROUTINE
C CONTAINS A FLAG (N) TO AVOID RESETTING THE VELOCITY
C COMPONENTS UNTIL EITHER A NEW WAYPOINT IS RECEIVED
C OR AN AIRCRAFT LIMITATION WHICH IS RAJAL IS REACHED
C IN THE SUBSEQUENT ITERATIVE SUBROUTINES. THE
C COORDINATE SYSTEM IS TERMED MAP, I.E., Y POINTS NORTH
C*****
SUBROUTINE MVELOCS
COMMON /ABC4/ AG1,AH1,AI1,AJ1,AJ2
COMMON /ABC1/ VELCN,VELOT,VELCC,N,JNEW,JTEMP,JOOLD,VNEW,VTEMP,VOLD,
1 WNEW,JTEMP,JOOLD
COMMON /AEE5/ FWDACC,AN,MCONT
N=N
IF (N.GT.0) GC TO 10
VNEW=VELCN*(AG1/AJ1)
VNEW=VELCN*(AH1/AJ1)
VNEW=VELCN*(AI1/AJ1)
10 CONTINUE
N=1
RETURN
END

```

```

C*****
C SUBROUTINE MVDOTS
C MVDOTS (MAP VELOCITY DOT COMPONENTS) COMPUTES THE
C LINEAR ACCELERATION COMPONENTS
C IN MAP COORDINATES. (Y POINTS NORTH)
C*****
SUBROUTINE MVDOTS
COMMON /ABC2/ XNEW,DELX,XTEMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1 ZTEMP,JOOLD
COMMON /ABC3/ VELCN,VELOT,VELCC,N,JNEW,JTEMP,JOOLD,VNEW,VTEMP,VOLD,
1 WNEW,JTEMP,JOOLD
COMMON /ABC4/ AG1,AH1,AI1,AJ1,AJ2
COMMON /AEE1/ UDOT,VDOT,WDOT
COMMON /AEE5/ FWDACC,AN,MCONT
ACC=(VELCN**2-VELCC**2)/(2*AJ1)
UDOT=ACC*(AG1/AJ1)
VDOT=ACC*(AH1/AJ1)
WDOT=ACC*(AI1/AJ1)
RETURN
END

```

```

C*****
C SUBROUTINE DELVEC
C DELVEC (DELTA VECTORS) UTILIZES STANDARD DYNAMIC
C EQUATIONS TO GENERATE LINEAR TRANSLATION INCREMENTS.
C IT FURTHER LOOKS TO SEE WHETHER THESE INCREMENTS
C EXCEED THE DISTANCE LEFT TO GO TO THE NEW POINT
C*****
SUBROUTINE DELVEC
COMMON /AEC2/ XNEW, DELX, XOLD, YNEW, DELY, YOLD, ZNEW, DELZ,
1 ZTEMP, ZOLD
COMMON /AEC3/ VELCN, VELOT, VELCC, N, UNEW, UTEMP, UOLD, VNEW, VTEMP, VOLD,
1 WNEW, WTEMP, WOLD
COMMON /AEC4/ AG1, AH1, AI1, AJ1, AJ2
COMMON /AED2/ VSTALL, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTZ
COMMON /AEE1/ UDCT, VDOT, WDOT
COMMON /AEE5/ FWDACC, AN, MCONT
DELX=XOLD+DELTEE*.5*UDOT+DELTEE**2
DELY=YOLD+DELTEE*.5*VDOT+DELTEE**2
DELZ=ZOLD+DELTEE*.5*WDOT+DELTEE**2
IF (ABS(DELX).GT.ABS(AG1)) DELX=AG1
IF (ABS(DELY).GT.ABS(AH1)) DELY=AH1
IF (ABS(DELZ).GT.ABS(AI1)) DELZ=AI1
RETURN
END

```

```

C*****
C SUBROUTINE TMPENT
C IMPEM (TEMPORARY POINT) GENERATES A TEMPORARY
C POSITION IN SPACE BASED UPON THE DELTA VECTORS
C*****
SUBROUTINE TMPENT
COMMON /ABC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1 ZTEMP, ZOLD
COMMON /ABC3/ VELCN, VELOT, VELCC, N, UNEW, UTEMP, UOLD, VNEW, VTEMP, VOLD,
1 WNEW, WTEMP, WOLD
COMMON /ABC4/ AG1, AH1, AI1, AJ1, AJ2
COMMON /AED2/ VSTALL, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTZ
COMMON /AEE5/ FWDACC, AN, MCONT
XTEMP=XOLD+DELX
YTEMP=YOLD+DELY
ZTEMP=ZOLD+DELZ
IF (DELX.EQ.AG1) YTEMP=YNEW
IF (DELY.EQ.AH1) ZTEMP=ZNEW
IF (DELZ.EQ.AI1)
RETURN
END

```

```

C*****
C SUBROUTINE TMFVEL
C      TMFVEL (TEMPORARY VELOCITY COMPONENTS) GENERATES
C      THE VELOCITY COMPONENTS ASSOCIATED WITH THE TEMPORARY
C      POINT IN SPACE (MAP COORDINATES).
C*****
      SUBROUTINE TMFVEL
      COMMON /ABC2/ XNEW,DELA,XTEMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1 ZTEMP,ZOLD
      COMMON /ABC3/ VELCN,VELOT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1 WNEW,WTEMP,WOLD
      COMMON /ABC4/ AG1,AH1,AI1,AJ1,AJ2
      COMMON /ABC2/ VSTALL,VMAX,VMAX1,VMAX2,DELTEE,DELTV,DELTAZ
      COMMON /ABC1/ UDOT,VDOT,WDOT
      COMMON /ABC5/ FWLACC,AN,MCONT
      UTEMP=UOLD+UDOT*DELTEE
      VTEMP=VOLD+VDOT*DELTEE
      WTEMP=WOLD+WDOT*DELTEE
      IF (ABS(UTEMP).GT.ABS(UNEW).AND.MCONT.EQ.1) UTEMP=UNEW
      IF (ABS(VTEMP).GT.ABS(VNEW).AND.MCONT.EQ.1) VTEMP=VNEW
      IF (ABS(WTEMP).GT.ABS(WNEW).AND.MCONT.EQ.1) WTEMP=WNEW
      IF (DELA.EQ.AG1) UTEMP=UNEW
      IF (DELY.EQ.AH1) VTEMP=VNEW
      IF (DELZ.EQ.AI1) WTEMP=WNEW
      IF (DELA.NE.0.) GC TC 10
      UDOT=0
      GO TO 20
10  CONTINUE
      IF (UTEMP.EQ.UNEW) UDOT=(UTEMP**2-UOLD**2)/(2*DELA)
20  CONTINUE
      IF (DELY.NE.0.) GC TC 30
      VDOT=0
      GO TO 40
30  CONTINUE
      IF (VTEMP.EQ.VNEW) VDOT=(VTEMP**2-VOLD**2)/(2*DELY)
40  CONTINUE
      IF (DELZ.NE.0.) GC TC 50
      WDOT=0
      GO TO 60
50  CONTINUE
      IF (WTEMP.EQ.WNEW) WDOT=(WTEMP**2-WOLD**2)/(2*DELZ)
60  CONTINUE
      VELOT=SQRT(UTEMP**2+VTEMP**2+WTEMP**2)
      RETURN
      END

```

```

C*****
C SUBROUTINE INRTRM
C      INRTRM (INITIAL RECTANGULAR TRANSFORMATION) TRANSFORMS
C      MAP COORDINATE COMPONENTS TO A SYSTEM USED BY FLIGHT
C      DYNAMICISTS (Y POINTS SOUTH AND Z POINTS DOWN)
C*****
      SUBROUTINE INRTRM
      COMMON /ABC3/ VELCN,VELOT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1 WNEW,WTEMP,WOLD
      COMMON /ABC1/ UDOT,VDOT,WDOT
      COMMON /ABC5/ FWLACC,AN,MCONT
      COMMON /ABC1/ U1,V1,W1,U2,V2,W2,U3,V3,W3
      COMMON /ABC2/ UC1,VC1,WC1,UD2,VD2,W2,UD3,VD3,W3
      U1=UTEMP
      V1=-VTEMP
      W1=-WTEMP
      UC1=UDOT
      VD1=-VDOT
      WC1=-WDOT
      RETURN
      END

```

```

C*****
C SUBROUTINE ANGLES
C      ANGLES COMPUTES THE ANGLE CHANGE INCREMENTS CAUSED
C      BY MOVEMENT FORWARD TO THE TEMPORARY POINT. PSINEM
C      IS THE LEADING CHANGE, REFERENCED TO THE X AXIS.
C      THENEW IS THE PITCH CHANGE REFERENCED TO THE
C      HORIZONTAL PLANE. PHINEM IS THE ROLL INCREMENT ABOUT
C      THE X AXIS.
C*****
SUBROUTINE ANGLES
COMMON /AEC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1ZTEMP, ZOLD
COMMON /AEC3/ VELCN, VELOT, VELCC, N, UNEW, UTEMP, UOLD, VNEW, VTEMP, VOLD,
1VNEW, VTEMP, VOLD
COMMON /AEC4/ AG1, AH1, AI1, AJ1, AJ2
COMMON /AED1/ AA1, AB1, AC1
COMMON /AED2/ VSTALL, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTZ
COMMON /AED3/ PSINEM, THENEW, PHINEM, PSICLD, THEOLD, PHIOLD
COMMON /AED4/ PSINEM, THENEW, PHINEM, PSICLD, THEOLD, PHIOLD
COMMON /AED5/ FWCACC, AN, MCONT
COMMON /AED6/ DS, DSE, DSEP
PS=SQR((DELX**2+DELY**2+DELZ**2))
IF (DELY.EQ.0.) AC=TC TO
IF (DELX.EQ.0.) AND (DELY.LT.0.) PSINEM=AA1
IF (DELX.EQ.0.) AND (DELY.GT.0.) PSINEM=-AA1
GO TO 20
CONTINUE
PSINEM=-ATAN(DELY/DELX)
IF (DELX.GT.0.) AND (DELY.EQ.0.) PSINEM=0.
IF (DELX.LT.0.) AND (DELY.LT.0.) PSINEM=AA1+PSINEM
IF (DELX.LT.0.) AND (DELY.EQ.0.) PSINEM=AA1
IF (DELX.LT.0.) AND (DELY.GT.0.) PSINEM=PSINEM-AB1
20 CONTINUE
THENEW=ASIN(DELZ/PS)
THEOLD=(PSINEM-PSICLD)/DELTEE
IF (PSINEM.GT.0.) PHINEM=ATAN(ABS(THNRAT*VELUT/9.7958))
IF (PSINEM.LT.0.) PHINEM=-ATAN(ABS(THNRAT*VELUT/9.7958))
IF (PSINEM.EQ.0.) PHINEM=PHIOLD
RETURN
END

```

```

C*****
C SUBROUTINE ROTRAT
C      ROTRAT (ROTATIONAL RATES) COMPUTES THE ANGLE DOT
C      COMPONENTS IN THE INERTIAL REFERENCE SYS. (THE ONE
C      WITH Y POINTING SOUTH AND Z DOWN).
C*****
SUBROUTINE ROTRAT
COMMON /AEC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1ZTEMP, ZOLD
COMMON /AED2/ VSTALL, VMAX, VMAX1, VMAX2, DELTEE, DELTV, DELTZ
COMMON /AED3/ PSIDOT, THEDOT, PHIDOT
COMMON /AED4/ PSINEM, THENEW, PHINEM, PSICLD, THEOLD, PHIOLD
COMMON /AED5/ FWCACC, AN, MCONT
PSIDOT=(PSINEM-PSICLD)/DELTEE
THEDOT=(THENEW-THEOLD)/DELTEE
PHIDOT=(PHINEM-PHIOLD)/DELTEE
RETURN
END

```

```

C*****
C SUBROUTINE ACTRM1
C      ACTRM1 (AIRCRAFT TRANSFORMATION MATRIX #1) EFFECTS
C      ROTATION OF AIRCRAFT ABOUT THE Z1 AXIS (POS Z
C      PCIMIS DWN TC EARTH).
C*****
      SUBROUTINE ACTRM1
      COMMON /AED4/ PSINew,THENew,PHINew,PSIOld,THEOld,PHIOld
      COMMON /AEE5/ FWDACC,AN,MCON
      COMMON /AEE1/ U1,V1,W1,U2,V2,W2,U3,V3,W3
      COMMON /AEE2/ UD1,VD1,WD1,UD2,VD2,WD2,UD3,VD3,WD3
      ANG=PSINew
      U2=cos(ANG)*U1+sin(ANG)*V1
      V2=-sin(ANG)*U1+cos(ANG)*V1
      W2=W1
      UD2=cos(ANG)*UD1+sin(ANG)*VD1
      VD2=-sin(ANG)*UD1+cos(ANG)*VD1
      WD2=WD1
      RETURN
      END

C*****
C SUBROUTINE ACTRM2
C      ACTRM2 ROTATES THE AIRCRAFT ABOUT THE Y2 (RIGHT WING)
C      AXIS.
C*****
      SUBROUTINE ACTRM2
      COMMON /AED4/ PSINew,THENew,PHINew,PSIOld,THEOld,PHIOld
      COMMON /AEE5/ FWDACC,AN,MCON
      COMMON /AEE1/ U1,V1,W1,U2,V2,W2,U3,V3,W3
      COMMON /AEE2/ UD1,VD1,WD1,UD2,VD2,WD2,UD3,VD3,WD3
      ANG=THENew
      U3=cos(ANG)*U2-sin(ANG)*W2
      V3=V2
      W3=sin(ANG)*U2+cos(ANG)*W2
      UD3=cos(ANG)*UD2-sin(ANG)*WD2
      VD3=VD2
      WD3=sin(ANG)*UD2+cos(ANG)*WD2
      RETURN
      END

C*****
C SUBROUTINE ACTRM3
C      ACTRM3 ROTATES AIRCRAFT ABOUT THE X3 (NOSE) AXIS
C*****
      SUBROUTINE ACTRM3
      COMMON /AED4/ PSINew,THENew,PHINew,PSIOld,THEOld,PHIOld
      COMMON /AEE5/ FWDACC,AN,MCON
      COMMON /AEE1/ U1,V1,W1,U2,V2,W2,U3,V3,W3
      COMMON /AEE2/ UD1,VD1,WD1,UD2,VD2,WD2,UD3,VD3,WD3
      COMMON /AEE3/ UAC,VAC,WAC,UDOTAC,VDOTAC,WDOTAC,P,Q,R
      ANG=PHINew
      UAC=U3
      VAC=cos(ANG)*V3+sin(ANG)*W3
      WAC=-sin(ANG)*V3+cos(ANG)*W3
      UDOTAC=UD3
      VDOTAC=cos(ANG)*VD3+sin(ANG)*WD3
      WDOTAC=-sin(ANG)*VD3+cos(ANG)*WD3
      RETURN
      END

```



```

C*****
C SUBROUTINE ACRVEL
C      (AIRPLANE ROTATIONAL VELOCITIES) COMPUTES THE
C      ROTATIONAL VELOCITIES IMPOSED ON THE
C      AIRCRAFT, IN THE ROTATIONAL OR AIRCRAFT COORDINATE
C      SYSTEM. (X ALONG THE NOSE, Y OUT THE RIGHT WING,
C      Z OUT THE BOTTOM OF THE AIRCRAFT.)
C*****

```

```

SUBROUTINE ACRVEL
COMMON /AED3/ ESIDCT,THEEDCT,PHIDOT
COMMON /AED4/ PSINEM,THEEM,PHINE,PSIOLD,THEOLD,PHIOLD
COMMON /AED5/ FWDACC,AN,MCONT
COMMON /AED6/ UAC,VAC,AC,UDOTAC,VDOTAC,WDOTAC,P,Q,R
ANG1=THEEM
ANG2=PHINE
P=PHIDOT-SIN(ANG1)*ESIDCT
Q=PSINEM-COS(ANG1)*PSIOLD
R=-SIN(ANG2)*THEEDCT+COS(ANG1)*COS(ANG2)*PSIDOT
RETURN
END

```

```

C*****
C SUBROUTINE ACACC
C      (AIRPLANE ACCELERATIONS) PUTS TOGETHER THE LINEAR
C      ACCELERATIONS RESULTING FROM TRANSLATION THROUGH
C      SPACE AND THE ROTATIONAL ACCELERATIONS RESULTING
C      FROM MANEUVERING. (WHAT APPEARS BELOW IS THE LHS
C      OF THE CLASSIC EQUATIONS OF MOTION FOR AN AIRCRAFT.)
C*****

```

```

SUBROUTINE ACACC
COMMON /AED2/ XN=X,DELTA,XTEMP,XOLD,YN=Y,DELT,YTEMP,YOLD,ZN=Z,DELTA,ZTEMP,ZOLD
COMMON /AED3/ AX,AY,AZ
COMMON /AED4/ FWDACC,AN,MCONT
COMMON /AED5/ UAC,VAC,AC,UDOTAC,VDOTAC,WDOTAC,P,Q,R
AX=UDOTAC-VAC*R+AC*Q
AY=VDOTAC+UAC*R-AC*P
AZ=WDOTAC-UAC*Q+VAC*P
A=-VAC*R
B=AC*Q
C=UAC*R
D=-VAC*P
E=-UAC*Q
F=VAC*P
RETURN
END

```

```

C*****
C SUBROUTINE ACLMNTS
C      (AIRPLANE LIMITATIONS) COMPARES THE
C      ACCELERATIONS RESULTING FROM A PROPOSED MOVE ALONG A
C      FLIGHT-PATH TRAJECTORY TO THE PHYSICAL LIMITATIONS OF
C      THE AIRCRAFT. THIS IS ESSENTIALLY THE RHS OF THE
C      EQUATIONS OF MOTION. IF THE TRAJECTORY ACCELERATIONS
C      ARE LARGER THAN ALLOWABLE THEY ARE ADJUSTED DOWNWARD
C      IN MAGNITUDE UNTIL THE RHS AND LHS OF THE EQUATIONS
C      OF MOTION ARE EQUATED.
C*****

```

```

SUBROUTINE ACLMNTS
COMMON /AED3/ AX,AY,AZ
COMMON /AED4/ THMAX,ANMAX,CLMAX,GEE,TO,RHOSSL,WL,CDO,CDK,AREA,DTER
COMMON /AED5/ FWDACC,AN,MCONT
CALL PRST
IF (AN.LT.ANMAX.AND.FWDACC.LT.THMAX) CALL BOOSTR
IF (AN.GT.ANMAX.OR.FWDACC.GT.THMAX) CALL REDUCR
RETURN
END

```

```

C*****
C SUBROUTINE BCCSTR
C*****
C***** ECCSTR INCREASES THE LINEAR ACCELERATIONS UNTIL
C***** MAXIMUM ALLOWABLE PERFORMANCE IS REACHED
C*****
SUBROUTINE BOOSTR
COMMON /AEC2/ XNEW, DELX, XTEMP, XCLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1 ZTEMP, ZOLD
COMMON /AEC4/ AG1, AH1, AI1, AJ1, AJ2
COMMON /AEE1/ UDOT, VDOT, WDOT
COMMON /AEE3/ AX, AY, AZ
COMMON /AEE4/ IHMAX, ANMAX, CLMAX, GEE, TO, BHOS3L, WL, CDO, CDK, AREA, JTEH
COMMON /AEE5/ FWDACC, AN, MCONT
MCONT=1
CONTINUE
10 I=0
IF (AG1.EQ.DELX.OR.AG1.EQ.0.) GO TO 20
IF (ABS(AG1).LT.AES(AH1).AND.AES(AG1).LT.ABS(AI1)) I=1
IF (I.NE.1) GO TO 20
UDOT=1.02*UDOT
CONTINUE
20 IF (AH1.EQ.DELY.OR.AH1.EQ.0.) GO TO 30
IF (ABS(AH1).LT.AES(AG1).AND.AES(AH1).LT.ABS(AI1)) I=2
IF (I.NE.2) GO TO 30
VDOT=1.02*VDOT
CONTINUE
30 IF (AI1.EQ.DELZ.OR.AI1.EQ.0.) GO TO 40
IF (ABS(AI1).LT.AES(AG1).AND.AES(AI1).LT.ABS(AH1)) I=3
IF (I.NE.3) GO TO 40
WDOT=1.02*WDOT
CONTINUE
40 IF (AG1.EQ.DELX.OR.AG1.EQ.0.) GO TO 50
IF (ABS(AG1).EQ.AES(AI1).AND.AES(AG1).LT.ABS(AH1)) I=4
IF (I.NE.4) GO TO 50
UDOT=1.02*UDOT
WDOT=1.02*WDOT
CONTINUE
50 IF (AH1.EQ.DELY.OR.AH1.EQ.0.) GO TO 60
IF (ABS(AG1).EQ.AES(AH1).AND.AES(AG1).LT.ABS(AI1)) I=5
IF (I.NE.5) GO TO 60
UDOT=1.02*UDOT
VDOT=1.02*VDOT
CONTINUE
60 IF (AI1.EQ.DELZ.OR.AI1.EQ.0.) GO TO 70
IF (ABS(AH1).EQ.AES(AI1).AND.AES(AH1).LT.ABS(AG1)) I=6
IF (I.NE.6) GO TO 70
VDOT=1.02*VDOT
WDOT=1.02*WDOT
CONTINUE
70 CALL SMLCAL
CALL THRUST
IF (AN.GE.ANMAX.OR.FWDACC.GE.IHMAX) GO TO 80
GO TO 10
CONTINUE
80 IF (AN.GT.ANMAX) AN=ANMAX
IF (FWDACC.GT.IHMAX) FWDACC=IHMAX
RETURN
END

```

```

C*****
C SUBROUTINE REDUCR REDUCR IS CALL FROM ACLETS AND REDUCES THE "NEW"
C VELCCITY AND ULTIMATELY POSITION TO SET LOADS
C ON THE AIRCRAFT WITHIN LIMITS.
C*****
SUBROUTINE REDUCR
COMMON /AEC3/ VELCN,VELOT,VELCC,N,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1WNEW,VTEMP,VOLD
COMMON /AEC4/ AG1,AH1,AI1,AJ1,AJ2
COMMON /AED2/ VSTALL,VMAX,VMAX1,VMAX2,DELTEE,DELTV,DELTZ
COMMON /AEE3/ AX,AY,AZ
COMMON /AEE4/ THMAX,ANMAX,CLMAX,GEE,TO,SHOSSL,AL,CDO,COK,AREA,DTCH
COMMON /AEE5/ FWLACC,AN,ICONT
COMMON /LCC/ X1,Y1,Z1,V1,ITB,ITRD
NCONT=1
10 CONTINUE
VELON=VELCN-DELTV
A=VSTALL+2.*DELTV
IF (VELON.GE.A) GO TO 20
ANG=ACOS(AG1/AJ2)
AJ2=1./AJ2
AG1=COS(ANG)*AJ2
AH1=SIN(ANG)*AJ2
20 VELON=V1
CONTINUE
N=N+1
CALL MVELCS
CALL AVDCIS
CALL SMLCAL
CALL THRUST
IF (AN.LE.ANMAX.AND.FWLACC.LE.IHMAX) GO TO 30
GO TO 10
30 CONTINUE
RETURN
END

C*****
C SUBROUTINE SMLCAL (SMALL CALL) IS A SMALLER VERSION OF (BIG CALL) AND
C USED IN THE ITERATIVE LOOPS OF (AIRCRAFT LIMITATIONS)
C*****
SUBROUTINE SMLCAL
CALL DELVEC
CALL TBPENT
CALL TBPVEL
CALL INRTM
CALL ANGLES
CALL ROTRAT
CALL ACTRM1
CALL ACTRM2
CALL ACTRM3
CALL ACBVEL
CALL ACACC
RETURN
END

```

```

C*****
C SUBROUTINE THRUST
C*****
C THRUST IS USED BY (AIRCRAFT LIMITATIONS) TO COMPUTE
C THE AVAILABLE FORWARD ACCELERATION BASED UPON THRUST
C DRAG, G-LOADING, POSITION IN SPACE AND GRAVITY.
C*****
C SUBROUTINE THRUST
COMMON /ABC2/ XNEW,DELX,XTEMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1ZTEMP,ZOLD
COMMON /ABC3/ VELCN,VELOT,VELCC,N,JNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1WNEW,WTEMP,WOLD
COMMON /ABC4/ PSINW,THNEW,PHINW,PSICLD,THEOLD,PHIOLD
COMMON /ABC5/ AX,AY,AZ
COMMON /ABC6/ THMAX,AMAX,CLMAX,GEE,TC,RHOSSL,AL,CDO,CDK,AREA,DTCH
COMMON /ABC7/ FWLACC,AN,ACONT
ANG=THNEW
THEQU=AX/GEE
AN=SQRT(AY**2+AZ**2)/GEE
SIGMA=(1+CTDH*ZTEMP/TO)**4.257
RHOALT=RHOSSL*SIGMA
CL=(2.*AN*WL)/(RHOALT*VELCT**2)
DRAG=AN*((CDO+CDK*CL**2)/CL)
FWDAcc=SIN(ANG)+THEQU+DRAG
RETURN
END

```

```

C*****
C SUBROUTINE XCHANGE
C*****
C ONCE THE EQUATIONS OF MOTION ARE SATISFIED AT THE
C PROPOSED LOCATION (TEMP) THE TEMP LOCATION BECOMES
C THE CURRENT LOCATION (OLD).
C*****
C SUBROUTINE XCHANGE
COMMON /ABC2/ XNEW,DELX,XTEMP,XOLD,YNEW,DELY,YTEMP,YOLD,ZNEW,DELZ,
1ZTEMP,ZOLD
COMMON /ABC3/ VELCN,VELOT,VELCC,N,JNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1WNEW,WTEMP,WOLD
COMMON /ABC4/ PSINW,THNEW,PHINW,PSICLD,THEOLD,PHIOLD
COMMON /ABC5/ AC1,AC2,AF1,AF2
XOLD=XTEMP
YOLD=YTEMP
ZOLD=ZTEMP
UOLD=UTEMP
VOLD=VTEMP
WOLD=WTEMP
PSIOLD=PSINW
THEOLD=THNEW
PHIOLD=PHINW
VELOO=VELCT
RETURN
END

```

AD-A144 819

IMPROVEMENTS TO IBMPIP(U) NAVAL POSTGRADUATE SCHOOL
MONTEREY CA D A MILTON MAR 84


3/3

UNCLASSIFIED

F/G 9/2

NL





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963-A

```

C*****
C SUBROUTINE WAYPNT THE SELEVANT PARAMETERS FOR THE CURRENT POINT ARE
C ASSIGNED.
C*****
SUBROUTINE WAYPNT
COMMON /AEC1/ WX(1000), WY(1000), WZ(1000), WU(1000), WV(1000), WW(1000)
1) /AH(1000), WP(1000), WR(1000), WG(1000), T(1000), ICT
COMMON /AEC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1) ZTEMP, ZOLD
COMMON /AEC3/ VELCN, VELOT, VELCC, N, UNEW, UTEMP, UOLD, VNEW, VTEMP, VOLD,
1) WNEW, WTEMP, WOLD
COMMON /AEC4/ ISTALL, VMAX, VMAX1, VMAX2, DELTEE, DELTY, DELTAZ
COMMON /AEC5/ PSINEN, THENEN, PHINEN, PSOLD, THEOLD, PHIOLD
COMMON /AEC6/ FALACC, AN, MCON
WX(ICT) = XOLD
WY(ICT) = YOLD
WZ(ICT) = ZOLD
WU(ICT) = UOLD
WV(ICT) = VOLD
WW(ICT) = WOLD
WH(ICT) = -PSINEN
WP(ICT) = -THENEN
WR(ICT) = -PHINEN
WG(ICT) = AN
T(ICT) = T(ICT-1) + DELTEE
RETURN
END

```

```

C*****
C SUBROUTINE FILE THE CURRENT POINT IS IMMEDIATELY SAVED.
C*****
SUBROUTINE FILE
COMMON /AEC1/ WX(1000), WY(1000), WZ(1000), WU(1000), WV(1000), WW(1000)
1) /AH(1000), WP(1000), WR(1000), WG(1000), T(1000), ICT
COMMON /AEC2/ XNEW, DELX, XTEMP, XOLD, YNEW, DELY, YTEMP, YOLD, ZNEW, DELZ,
1) ZTEMP, ZOLD
COMMON /LCC/ X1, Y1, Z1, V1, ITB, ITS2
IF (XOLD.NE.XNEW.OR.YOLD.NE.YNEW.OR.ZOLD.NE.ZNEW) GO TO 10
WRITE (11,20) T(ICT), WX(ICT), WY(ICT), WZ(ICT), WU(ICT), WV(ICT), WW(IC
1T), WH(ICT), WP(ICT), WR(ICT), WG(ICT), LIR
RETURN
10 CONTINUE
ITS=0
WRITE (11,20) T(ICT), WX(ICT), WY(ICT), WZ(ICT), WU(ICT), WV(ICT), WW(IC
1T), WH(ICT), WP(ICT), WR(ICT), WG(ICT), LIR
RETURN
20 FORMAT (11(E10.4, 1X), I3)
END

```

```

*****
BLOCK DATA
*** CAUTION ** THIS BLOCK DATA IS AN ABBREVIATED
VERSION. -- D. A. M. -- 16MAR84
*****
BLOCK DATA
COMMON /LCC/ J1,J1,Z1,V1,IT5,IT2
COMMON /MIN/ MINX,MAXX,MINY,MAXY,MINX1,MAXX1,MINX2,MAXX2
COMMON /MN/ IBAUD
COMMON /PAR2/ XGUN(7),YGUN(7),ZGUN(7),XSAM,YSAM,ZSAM,GR(7)
COMMON /PAR4/ AFEMAX,HTMIN,HTMAX,FOPMIN,EAALT,BRMIN,ERMAX,BRMIN,B
188MAX,ZTE,MTF
COMMON /ABC1/ WX(1000),WY(1000),WZ(1000),WU(1000),WV(1000),WW(1000
1),WR(1000),WP(1000),WR(1000),WG(1000),I(1000),ICT
COMMON /ABC2/ YNEW,DELT,XTEMP,XOLD,YNEW,DELT,YTEMP,YOLD,ZNEW,ZEL2,
1ZTEMP,ZOLD
COMMON /ABC3/ VELCN,VELOT,VELCC,M,UNEW,UTEMP,UOLD,VNEW,VTEMP,VOLD,
1VNEW,VTEMP,VOLD
COMMON /AED1/ AA1,AB1,AC1
COMMON /AED2/ VSTALL,VMAX,VMAX1,VMAX2,DELTEE,DELTU,DELTAZ
COMMON /AED3/ PSICOT,THEDOT,PHIDOT
COMMON /AED4/ PSINEW,THENEW,PHINEW,PSIOLD,THEOLD,PHIOLD
COMMON /AED5/ AC1,AE1,AF1,AF2
COMMON /AED6/ THMAX,AMMAX,CLMAX,GEE,TO,PHCSSL,AL,CDO,CEK,AREA,DTEH
COMMON /TAR/ TARGX,TARGY
-----
C FLASH DRIVER
C-----
C DATA IBAUD/1/
C-----
C MAX WINDOW X COORDINATES
C-----
C DATA MINX/100/
C DATA MAXX/3700/
C-----
C ALTIMETER WINDOW X COORDINATES
C-----
C DATA MINX1/3725/
C DATA MAXX1/3925/
C-----
C FREIGHTING WINDOW X COORDINATES
C-----
C DATA MINX2/3950/
C DATA MAXX2/4000/
C-----
C COMMON Y COORDINATES FOR THE THREE WINDOWS
C-----
C DATA MINY/400/
C DATA MAXY/2800/
C-----
C PREDETERMINED WEAPON EMPLACEMENT PARAMETERS
C-----
C DATA XGUN/14800.,16200.,17600.,18400.,11300.,15000.,12300./
C DATA YGUN/9000.,3200.,7200.,8000.,3700.,10900.,7500./
C DATA ZGUN/40.,40.,20.,20.,50.,90.,20./
C DATA XSAM/12300./,YSAM/6000./,ZSAM/50./
C DATA GR/1000.,1000.,1400.,1400.,2500.,2500.,2500./
C-----
C TARGET COORDINATES
C-----
C DATA TARGX/14000./,TARGY/7220./
C-----
C CONVERSION FACTORS: RADIAN TO DEGREE
C METERS TO FEET
C-----
C DATA RTD/57.29578/
C DATA AMTF/3.28084/
C-----
C GRAVITATIONAL CONSTANT (M/S2)
C-----
C DATA GEE/9.807/
C-----
C SIMULATION PARAMETERS
C-----
C-----
C CARDINAL COMPASS HEADINGS (RADIAN)

```


C----- DATA AA1/1.570796/,AE1/3.141592/,AC1/4.7124/
 C----- PITCH ROLL AND YAW PARAMETERS
 C----- DATA AD1/.5236/,AE1/.0524/,AF1/.6503/,AF2/2.0944/
 C----- MAXIMUM THRUST OF THE AIRCRAFT (DIMENSIONLESS)
 C----- DATA THMAX/0.40/
 C----- MAXIMUM AIRCRAFT GEE-LOADING (DIMENSIONLESS)
 C----- DATA ANMAX/6./
 C----- RHCSL IS THE DENSITY AT STANDARD SEA-LEVEL CONDITIONS. IT HAS
 C----- DIMENSIONS OF (M.S2/M4)
 C----- DATA RHCSL/1.225/
 C----- STANDARD SEA-LEVEL TEMPERATURE (DEGREES K)
 C----- DATA TO/288.16/
 C----- TEMPERATURE LAPSE RATE FOR THE TROPOSPHERE (DEG K/M)
 C----- DATA DTDR/-0.5E-3/
 C----- MAXIMUM WING LOADING (N/M2)
 C----- DATA WL/4788./
 C----- SPEED BRAKE AREA: DEFINED AS A PERCENTAGE OF TOTAL WING AREA
 C----- DATA AREA/.05/
 C----- MAXIMUM COEFFICIENT OF LIFT
 C----- DATA CLMAX/1./
 C----- COEFFICIENT OF DRAG AT ZERO ANGLE OF ATTACK
 C----- DATA CDO/.015/
 C----- PROFILE DRAG COEFFICIENT
 C----- DATA CDK/0.1/
 C----- MINIMUM ALTITUDE FOR THE GAME (M)
 C----- DATA HTMIN/60./
 C----- MAXIMUM ALTITUDE APPROACHING THE TARGET (M)
 C----- DATA APPMAX/457./
 C----- MAXIMUM ALTITUDE AFTER ENTERING POP-UP RANGE OF 6 KM. (M)
 C----- DATA HTMAX/2050./
 C----- MAXIMUM VELOCITIES BEFORE AND AFTER BOMB RELEASE (M/S)
 C----- DATA VMAX1/260./,VMAX2/310./
 C----- STALL VELOCITY (M/S)
 C----- DATA VSTALL/90./
 C----- MAXIMUM RANGE (METERS) A POP-UP MAY BE COMMENCED
 C----- DATA PCPHIN/6000./
 C----- THE FOLLOWING ARE TEMPORARY PARAMETERS FOR THE INITIAL CONDITIONS OF
 C----- THE AIRCRAFT. LATER THIS WILL BE ENTERED INTERACTIVELY.
 C----- DATA RX/0./,RY/6000./,RZ/200./,RU/200./,RV/0./,RW/0./

```

DATA #R/1.5708//, #P/0.//, #E/0.//, #G/0.//, I/0.//
C-----
C INCREMENT OF VELOCITY CHANGE (5 KNCT INC CONVERTED TO M/S)
C-----
DATA DELTV/3.//
C-----
C INCREMENT OF TIME CHANGE (SECONDS)
C-----
DATA DELTEE/1.00//
C-----
C INCREMENT OF ALTITUDE CHANGE (50 FT INC CONVERTED TO METERS)
C-----
DATA DELTAZ/15.24//
C-----
C TEMPCBAY PROGRAM INITIALIZATION
C last data line simulates input from the graphics buffer through
C the ibapip subroutines xypt and zvpt.
C-----
DATA X0L1/0.//, Y0L1/6000.//, Z0L1/200.//
DATA U0L1/200.//, V0L1/0.//, W0L1/0.//
DATA PSICL1/0.//, TEZOL1/0.//, PHIOL1/0.//
DATA VELCC/200.//
DATA X1/6000.//, Y1/8000.//, Z1/300.//, V1/260.//
END

```

LIST OF REFERENCES

1. Johns, E.R., Creation of a Transportable Interactive User Interface for Improved AAA Simulation Computer Program, Master's Thesis, Naval Postgraduate School, Monterey, California, 1982.
2. International Business Machines Corporation, IBM 3277 Graphics Attachment Support (Programming RPO P09013): Program Reference and Operations Manual SA20-2137-1, pp. 208-213, 123.
3. Meriam, J.L., Dynamics, 2nd ed., pp.17-20, Wiley, 1971.
4. Hurt, H.H. Jr., Aerodynamics for Naval Aviators, pp.176-178, U.S. Government Printing Office, 1980.
5. Bell, R.W., Performance and Static Stability (AE2036), class notes for course at Naval Postgraduate School, Monterey, California, 12 July 1982.
6. Roskam, J., Airplane Flight Dynamics and Automatic Flight Controls, part 1, pp. 9-33, Roskam Aviation and Engineering Corporation, 1979.

INITIAL DISTRIBUTION LIST

	No. Copies
1. Defense Technical Information Center Cameron Station Alexandria Va 22314	2
2. Library, Code 0142 Naval Postgraduate School Monterey Ca 93943	2
3. Professor R.E. Ball Code 67Bp Department of Aeronautics Naval Postgraduate School Monterey, Ca 93943	2
4. LT E.A. Milton FAWFRA Box 58 FPO San Francisco, Ca 96654	1
5. Combat Data Information Center AFWAL/FIES/CDIC Wright-Patterson AFB, Ohio 45433	1
6. Mr. Martin Lentz ASD/ENFTV Wright-Patterson AFB, Ohio 45433	1

